


# Bailey

SECTION  
P91-3

## PRODUCT INSTRUCTIONS

MINI-LINE\* 500 HAND/AUTOMATIC STATION  
WITH ADJUSTABLE SET POINT



\*REG. U.S. PAT. OFF.

**BAILEY METER COMPANY • WICKLIFFE, OHIO 44092**

00 36 22 04 11 07

**INDEX**

	Page
<b>INSTALLATION</b>	4
Pre-Service Adjustment Check	4
Mounting H/A Station on Panel	4
Installing Connecting Piping	4
Cleaning Scale Cover	4
<b>OPERATION</b>	6
Transfer from AUTO to HAND	6
Transfer from HAND to AUTO	6
Alternate HAND to AUTO Transfer	6
<b>ROUTINE MAINTENANCE</b>	7
<b>CORRECTIVE MAINTENANCE</b>	9
Vertical Gage Unit Adjustment	9
Hand Relay Disassembly	10
Hand Relay Adjustment	10
Front Plate Disassembly	10
Shut-Off Valve Disassembly	11
Valve Operator Lever and Shaft Disassembly	11
Drive Shaft Disassembly (Control Knob to Relay)	11
<b>SCHEMATIC OPERATION</b>	12
Typical Application of Set Point Station	12
Hand Relay	12
<b>REPLACEMENT PARTS</b>	13
Spare Parts Kits	13
Ordering Individual Parts	13
<b>EXPLANATION OF NOMENCLATURE</b>	13




FIGURE 1 Removing Vertical Gage Unit from H/A Station




FIGURE 2 Vertical Gage Unit Zero Adjustment Screws

## INSTALLATION

### Pre Service Adjustment Check

**IMPORTANT** Before placing H/A Station in service, check adjustment of vertical gage unit as outlined below to insure that factory calibration was not disturbed in transit. For convenience, perform this check at a test bench before the H/A Station is installed in the panel.

1 With H/A Station mounted or positioned at angle at which it will be mounted in service, check that indicating pointers read minimum scale. If pointers read correctly, proceed to step 5.

2 If pointers do not read minimum scale, remove vertical gage unit from H/A Station as outlined in Figure 1.

3 Remove snapout cover (Figure 2) and turn zero adjustment screw until pointer reads correctly.

4 Apply midrange and maximum range input pressures to gage unit. If pointer readings correspond to applied inputs, proceed to step 5. If readings are incorrect, refer to "Vertical Gage Unit Adjustment", page 9.

### Mounting H/A Station on Panel

Hand Automatic Stations with Adjustable Set Point are designed for plug-in mounting in a panel-mounted enclosure (Figure 3). Install enclosure as follows:

5 Make panel cutout in accordance with Figure 3.

6 Loosen mounting screws on front plate which secure H/A Station to enclosure and remove Station.

7 Slide enclosure thru cutout from front of panel.

8 Place mounting clips (in bag tied to enclosure) in position on enclosure. Tighten clip securely against panel.

9 Slide H/A Station into enclosure and secure with mounting screws in front plate.

### Installing Connecting Piping

10 Connect external tubing to manifold connections on rear of enclosure (Figure 3). Connection ports are 1/4 13 NPT female. Use 1/4 inch O.D. copper, aluminum, or plastic tubing.

### Cleaning Scale Cover

11 Remove protective tape from scale cover. Clean cover with toothpaste or "Plastar" plastic cover cleaner and polish (obtainable from Bailey Meter Company in 10 ounce jar, specify Part Number 199274-1).

**CAUTION** Do not use a solvent which will scratch cover finish or react with plastic cover.

H/A Station with Adjustable Set Point




FIGURE 3 H/A Station Mounting Dimensions

## OPERATION

Before transfer, conditions within the control system must be set so there is little or no variation in control pressure to the power unit as transfer takes place. Procedures for transferring from AUTO to HAND and from HAND to AUTO are outlined below. Refer to Figures 4 and 5.

### Transfer from AUTO to HAND

1 With HAND control knob, set transfer pressure (gauge C) equal to control pressure (gauge D).

2 Turn transfer switch to HAND.

### Transfer from HAND to AUTO

1 With HAND control knob, slowly set control pressure (gauge D) equal to transfer pressure (gauge C).

2 Turn transfer switch to AUTO.

### Alternate HAND to AUTO Transfer

The procedure above for transferring from HAND to AUTO may not always be practical. In this case, the alternate method given below may be followed. NOTE: This alternate procedure should be used only where the set point may be changed without endangering the process.

1 With SET POINT control knob, adjust set point until transfer pressure (gauge C) is equal to control pressure (gauge D).

2 Turn transfer switch to AUTO.

3 Return set point to desired value.




FIGURE 4 H/A Station Controls and Gauges




FIGURE 5 Schematic of H/A Station

## ROUTINE MAINTENANCE

1 Maintain a clean air supply, free of oil or moisture

2 Check filter in the supply inlet port on the housing assembly connecting manifold shortly after installation. If replacement is necessary, remove wire mesh disc, felt pad, and second wire mesh disc. Install new filter, making certain wire mesh disc is inserted in inlet port before inserting felt pad.


3. Periodically depress orifice clean-out plunger (Figure 6) on rear of hand relay to insure that the orifice remains open and clean. **CAUTION** This operation should only be performed when relay is being bench tested since depressing the plunger while relay is in service may disrupt the process.

4 Whenever necessary, clean plastic scale cover as follows:


a. Remove (and replace) scale cover as shown in Figure 7.

b. Clean cover with a soft cloth which will not scratch the plastic surface. Use tooth-paste or "Plastar" plastic cover cleaner and

polish (obtainable from Bailey Meter Company in 10-ounce jar - specify Part No 199274-1). **Do not use a solvent which will scratch cover finish or react with plastic cover.**

FIGURE 6 - Rear View of H/A Station  
(Removed from Enclosure)

T REM E WLE EF




FE 1 VE - DE  
.EF REW AIL



EHT  
REV I  
T W P P H L L  
N U P P I




T R I RE F A H  
E I G H L R T T A H  
T F L L V E R N L F  
T F L T H  
B T T M F A L E O V E R




↓ V N B O T T M F V E R  
T I T L L P I T F  
E F S L O T C O E N A G E  
F L L V E R F F


T I N S T A L L C A L E EF



↑ E R T T F L L E F . E F  
W A L E W H V B E T L E  
W L E C A E L H  
W F A W F S E L E  
V L W E R E L T A A F L  
W E T E I W L E L F  
T F F R L T



↑ F H E T T L L E  
W F A W F B L E  
W L E W L E



↑ T H J R E T F P R I C  
L F S L L V I L P T O  
E I J A E W T H R T T M O V E R  
L T

FIGURE 7 Removing and Replacing Vertical Gage Unit Scale Cover



**CORRECTIVE MAINTENANCE****Vertical Gage Unit Adjustment**

If operational faults occur which are traced to the vertical gage units, make the following adjustment checks.

- 1 Remove gage unit from H/A Station as shown in Figure 1. Pry off snapout cover and remove side cover for access to gage unit adjustments (see Figure 2).
- 2 Apply pressure to Bourdon tube and check block assembly for leakage with a soap-suds solution. If a leak is found, replace entire gage unit. The damaged unit may be returned to the factory for repair.
- 3 Check all links to see that they are properly connected and that they move freely with Bourdon tube movement.
4. Make certain that indicating pointer does not rub against side or face of scale. If necessary, bend pointer slightly until it clears scale.
- 5 Check pointer adjustment as outlined below
  - a Apply pressure to gage equivalent to first major scale division above 0% scale. If

pointer does not read correctly, turn zero adjustment screw (Figure 8) until desired reading is obtained.

- b. Apply pressure to gage equivalent to first major scale division below 100% scale. If pointer does not read correctly, turn range adjustment screw (Figure 8) until desired reading is obtained.

- c. Repeat steps 5 a and 5b until pointer reads correctly at both scale divisions.

- d. Apply pressure to gage equivalent to midscale division. If pointer does not read correctly, but does read correctly in steps 5a and 5b above, alter the shape of U link at free end of Bourdon tube as follows

- (1) If midscale pointer reading is low, spread link slightly

- (2) If midscale pointer reading is high, close link slightly

- e. Repeat steps 5a thru 5d until pointer reads correctly over full scale.

- 6 To return gage unit to service, reverse the order of operations outlined in step 1 above.




FIGURE 8 - Vertical Gage Unit Adjustments

Hand Relay Disassembly

To disassemble the Hand Relay (Part Number 5321995 □) for cleaning or replacement of parts, proceed as follows

- 1 Refer to Figure 11. Disconnect tubing and remove two screws (26) holding gage support (13) to support bracket assembly (30).
- 2 Remove two fillister head screws (39) holding manifold to Relay and slide manifold and support bracket rearward
- 3 Remove two socket head screws (36) holding Relay to support bracket (30) and remove Relay
- 4 Refer to Figure 12. Unscrew valve cap (7) and remove valve stem (11), inlet valve seat (13), and valve seat spring (15). CAUTION Do not disturb setting of relay adjustment screw (Figure 6) at center of valve cap. This setting is factory set and should not be disturbed unless control bellows has been removed or replaced (see "Hand Relay Adjustment")
- 5 Unscrew orifice clean out assembly (4) and orifice (14)
- 6 Relieve spring compression by rotating center adjustment gear (27) counterclockwise until it turns easily
- 7 Remove four nuts (at corners of valve housing face) and screws securing spring housing (23) to valve housing (9) and separate housings
- 8 Pull control bellows assembly (16) from valve housing (9). Control bellows assembly is held by exhaust valve diaphragm which snaps into place around valve seat )
- 9 If desired, unscrew loading spring assembly (19) from adjustment shaft (left hand thread)
- 10 To reassemble, reverse above procedure, observing the following precautions
  - a When replacing control bellows assembly (16), make certain exhaust valve diaphragm (29) is properly snapped into place around exhaust valve seat
  - b When replacing orifice clean out assembly (4) make certain that clean out wire is not bent and passes cleanly thru the orifice

- c Make certain that all O rings are undamaged and properly installed. Apply lubricant to O rings when reassembling relay

Hand Relay Adjustment

- 1 Connect output pressure line of Relay, thru a petcock, to a volume chamber equipped with a suitable pressure gage (0-30 psig) for indicating chamber pressure. Volume chamber may be any pressure tight container with volume of about 300 cubic inches
- 2 Open petcock and adjust H/A Station control knob to obtain 3 psig pressure in volume chamber
- 3 Close petcock and adjust control knob to obtain 27 psig (for 3-27 range) or 15 psig (for 3-15 range) output pressure from Relay (read output pressure on H/A Station gage).
4. Open petcock and note time rate of pressure increase in volume chamber
- 5 Close petcock and adjust control knob to obtain 3 psig output pressure from Relay
- 6 Open petcock and note time rate of pressure decrease in volume chamber
- 7 If inlet valve seat is properly adjusted, the time rate of pressure increase as noted in step 4 will be equal to the time rate of pressure decrease as noted in step 6. If these rates are not equal (or if the control bellows or nozzle bellows has been replaced), it will be necessary to make the following adjustment

a If time rate of pressure increase is greater than the rate of pressure decrease, turn adjustment screw (Figure 6) counterclockwise

b If time rate of pressure decrease is greater than the rate of pressure increase, turn adjustment screw clockwise. NOTE: By turning the relay adjustment screw (Figure 6) on the rear of the H/A Station, the inlet valve seat position can be changed with respect to the neutral position of the exhaust valve seat, in effect, controlling the relative openings of the inlet valve and exhaust valve for a given position of the control bellows

Front Plate Disassembly

- 1 Remove vertical gage units as shown in Figure 1

H/A Station with Adjustable Set Point

2 Refer to Figure 11. Remove HAND control knob (27) by driving out steel lockpin (28) and pulling knob off shaft. Remove SET POINT control knob by inserting a small screw driver in slot behind knob and pushing outward (from front plate) on spring holding knob on shaft. Then slide knob off shaft. AUTO-HAND transfer switch need not be removed.

3. Remove two screws (15) at rear of front plate (17) which secure plate to H/A Station frame.

4. To reassemble, reverse the above procedure, observing the following precautions

a When placing front plate (17) on H/A Station frame, fit pins at top and bottom of plate into corresponding slots in frame, and align transfer switch and valve operator lever (22) so that transfer switch pin fits into hole at top of lever (22)

b When replacing control knobs, slide knobs on respective shafts. Replace lockpin in HAND control knob shaft

Shut Off Valve Disassembly

1. Refer to Figure 11. Disconnect tubing at vertical gage units and remove screws (39) at Relay.

2. Remove screws (12) and (14) (two at front end of plate and two at rear end next to name plate) which secure shut-off valve mounting plate (top of H/A Station) to frame. Do not disturb screws holding valve to plate.

3. Set transfer switch (23) (or valve operator lever (22) if front plate has been removed) in vertical position between AUTO and HAND

4. Slide shut-off valve assembly (10) (plate, valves, and tubing) to rear to disengage valve

stems from valve operator shaft. When disengaged, assembly can be lifted from H/A Station

5. To disassemble individual shut-off valve, unscrew plug (10E) at bottom of valve and remove spring (10D), stem (10B), and diaphragm (10F). To reassemble, reverse the above procedure. Valve stems must be in alignment to engage valve operator shaft.

Valve Operator Lever and Shaft Disassembly

1 Remove vertical gage units (shown in Figure 1), front plate (see above), and shut-off valve assembly (see above)

2 Refer to Figure 11. Remove hex nut (25) at front end of shaft and slide valve operator lever off shaft

3. Unscrew bearing (9) which supports end of shaft.

4 Slide shaft to rear until front end clears supporting bearing. Remove shaft from frame.

5. To reassemble, reverse the above procedure

Drive Shaft Disassembly (Control Knob to Relay)

1 Remove vertical gage units (as shown in Figure 1) and front plate (see above)

2 Refer to Figure 11. Remove retaining ring (34) at rear end of shaft.

3. Back off cone point set screw (32) in perimeter of gear (33) until gear is free of shaft

4 Slide shaft out thru front of unit and remove gear.

5. To reassemble, reverse the above procedure




FIGURE 9 Typical Application of H/A Station

**SCHEMATIC OPERATION**

Typical Application of Set Point Station

Figure 9 shows a typical control application. A signal pressure, proportional to the measured variable, is applied to the A bellows of the Proportional plus Integral Controller (indicated on page A). Output pressure of the Controller (from D bellows) is transmitted thru the H/A Station to the power unit.

Set point pressure from connection 1 is applied to the B bellows of the Controller. Since the Controller is balanced when the pressures in the A and B bellows are equal, the set point of the system is established by the H/A Station SET POINT control. Comparison of readings on gages A and B indicates whether the system is at set point.

When the H/A Station is in the HAND position, the back pressure is provided from con-

nection 4, thru connection 5, shut off valve V5 and connection 3, to the C bellows of the Controller. On HAND operation, the tie back pressure holds the Controller output pressure approximately equal to the control pressure, facilitating smooth transfer to automatic operation. Where tie back pressure is not required, connection 4 is plugged and connections 3 and 5 are left open to atmosphere.

Hand Relay

Hand and Set Point pressures are established by the Hand Relay (Figure 10). Compression of the loading springs is opposed by pressure in the control bellows so that forces due to spring compression and output pressure are always equal when the unit is balanced. Pressure in the control bellows is regulated by the inlet exhaust valve assembly. At balance, the inlet valve is held closed by the difference between

## H/A Station with Adjustable Set Point

supply pressure and control bellows (output) pressure. Leakage of supply air thru the bleed orifice maintains the exhaust valve in a floating position.

Turning the control knob (HAND or SET POINT) in the "increase" direction compresses the loading spring, compressing the control bellows, closing the exhaust valve, opening the inlet valve, and admitting supply air to the control bellows. Control bellows pressure increases until bellows expansion is sufficient to restore the inlet exhaust mechanism to its original position (inlet valve closed, exhaust valve floating). Output pressure is then proportional to the increased loading spring compression.

Turning the control knob in the "decrease" direction reverses the operation described above.




FIGURE 10 - Schematic of Hand Relay

## REPLACEMENT PARTS

## Spare Parts Kits

The Spare Parts Kits shown in Figures 11, 12, and 13 should be carried in stock. Specify the Spare Parts Kit part number to order a complete kit.

## Ordering Individual Parts

Figures 11, 12, and 13 are Parts Drawings of Set Point Stations. Normally these drawings apply to the unit furnished. However, there may

be individual differences in specific units because of

- a Design changes made since the printing of this Instruction Section, or
- b Special design of the Set Point Stations to make them suitable for a special application.


Therefore, when ordering parts, assure the receipt of correct replacements by specifying the H/A Station Module Part Number.

## EXPLANATION OF NOMENCLATURE

H/A STATION MODULE PART NO.	H/A STATION NOMENCLATURE*	RANGE (PSIG)	LEFT GAGE SCALE LEGEND	
			LEFT INDICATOR	RIGHT INDICATOR
5321865 1	AJ02A10	3-27	METER	SET POINT
5321865 2	AJ02A50	3-27	DIRECT READING**	SET POINT
5321865 3	AJ01A10	3-15	METER	SET POINT
5321865 4	AJ01A50	3-15	DIRECT READING**	SET POINT

\*NOMENCLATURE appears only on the H/A Station Specification Sheet included in Instruction Books furnished on system or contract jobs. A "5" in the third position of the Nomenclature indicates that the H/A Station module is complete with enclosure, Part No. 5322407 2. An "X" in any Nomenclature position indicates that the instrument is special.

\*\*SCALE LEGEND engraved in terms of variable, such as, FLOW, LEVEL, PRESSURE




ITEM	PART NO	NAME	ITEM	PART NO	NAME	ITEM	PART NO	NAME
1	461431	2 DESIGNATION PLATE	4F	53 45 4 1	AIR VALVE D APH 4 REQD	31	5222 1	DRIVE SHAFT
3	532243	2 ENCLOSURE INCLUDES	0	531476 1	4 AIR VALVE BODY	32	535111	HEN SOP HD OY P TSS 3 REQD
3A	5321474	1 CONNECTOR MANIFOLD	1	531444 1	VALVE OPERATING SHAFT	33	53 4793 1	ADJ STMENT KEAR 4 REQD
3B	532 414 1	FELT PAD 2 REQD	2	1 723 3	PAN HD SEMS INT 6 REQD	34	48173	RETAIN NUT 2 REQD
3	532 413 1	W RE MESH DIS 4 REQD	3	531613	JAC S PPORT BRKT 3 REQD	35	3 30	SHAKEPROT LA WASH 6 BRQF
3D	3 325 1b	PA HD SEMS INT 4 REQD	4	10 42 8	FILL HD SEMS 4T 3 REQD	36	0 2343 8	HEN SOP HD S REV 4 REQD
3E	531444	MOUNTING CLP 4 REQD	5	10 152 8	FAN HD SEMS EXT 2 REQD	37	532398	SPACER MAN FOLD
3F	NAMEPLAT	SPECIFY TYPE AND MODEL FOR CORRECT ENGRAVING	6	532389	SPECIAL MTC SCREW 3 REQD	38	531424 3	CRIMP WASH RT 14 REQD
4	SEE TABLE	HAND ADJUST STATION ASSY W/L TEM 5 THRU 71	7	522974 1	FRONT PLATE	39	0 382 2 1	FILL HD S REV 2 REQD
1	531197 1	HAND RELAY ASSEMBLY*	8	532083	ENOB SHAFT ASSEMBLY	40	532 78 1	DRIVE SHAFT
5	531445 1	VALVE OPERATOR	9	0 6 25	SPRING GUIDE ASSEMBLY	41	10 32 2	HEN HD SEMS EXT 2 REQD
6	243 4	FAN HD SEMS INT 5 REQD	10	531465 1	VALVE OPERATOR SPRING	42	531497 9	HAND RELAY ASSEMBLY*
7	531198 1	HAND RELAY ASSEMBLY*	11	0 4661 1	SPRING HOLDER	43	532 43	ADJ STMENT KNOB
8	196235 1	NAMEPLATE	12	531451 1	VALVE OPERATOR LEVER	44	SEE TABLE	VERTICAL CALIBR HT**
9	531494 1	VALVE SHAFT BEAR NG	13	5322844	SELECTOR PLATE	45	1 324 1	PA HD SEMS INT 2 REQD
10	5321612 1	P PIN ASSEMBLY INFL DES	14	5 21 4	FAN HD SEMS INT 4 REQD	46	53 45 1	SCALE ASSEMBLY SEE TABLE
10A	531487	DIAPHRAGM WASHER 5 REQD	15	532 71 1	CONTROL KNOB	47	53435 1	FRT NT PLATE ASSEMBLY
10B	531487 1	VALVE STEM 5 REQD	16	1 163 4	ROLL PIN	48	0 3 2	TA HD SEMS EXT 3 REQD
10C	53148 1	THRUST WASHER 5 REQD	17	531519 1	BRACKET ASSEMBLY			
10D	531492 1	SPRING 4 REQD	18	532353	4 PPORT BRACKET ASSEMBLY			
10E	531486 1	AIR VALVE PLU 5 REQD						

\*FOR DETAILS OF HAND RELAY SET NO 512194-D SEE PART DRAWING P9 7  
 \*\*FOR DETAILS OF VERTICAL CALIBR HT SEE PARTS DRAWING P 2 5

ITEM 4	NAME	ITEM 44	ITEM 45	ITEM 47
531196 1	3 2	314945 24	531494 23	OMIT REQD
531197 2	3 6	3 4945 24	531494 22	1 REQD
531198 3	3 15	531 1 7	0 18134 20	OMIT REQD
532 262 4	3 5	531 2 5 11	531814 14	

KIT PART NO	TEMP
3	3B
4	3
5	1 E 1B
4	1B

FIGURE 11 Parts Drawing, P91 9, Hand/Automatic Station with Adjustable Set Point




ITEM	PART NO	NAME
1	CODE LABEL	SPECIFY NO ON LABEL WHEN ORDERING PARTS
2	5311428 2	O RING GASKET
3	5311428 11	O RING GASKET
4	5316478 1	ORIFICE CLEANOUT
5	10 32x2 1 4	FIL HD SCREW 4 REQD
6	5311428 7	O RING GASKET
7	5316009 1	VALVE CAP
8	5316808 1	VALVE ADJ SCREW
9	5321892 1	VALVE HOUSING
10	5311428 20	O RING GASKET
11	5316811 1	VALVE STEM
12	5311428 23	O RING GASKET
13	5316977 1	VALVE SEAT ASSY
14	5316464 1	ORIFICE ASSEMBLY
15	5316844 1	VALVE SEAT SPRING

ITEM	PART NO	NAME
16	5316802 1	CONTROL BELLOWS ASSY
17	5311428 24	O RING GASKET
18	5316817 1	SPRING SUPPORT
19	5316819 1	LOADING SPRING
20	5316816 1	GUIDE & SPRING SUPPORT
21	198173 3	RETAINING RING
22	5316814 1	ADJUSTMENT SCREW
23	5323245 2	SPRING HOUSING
24	5316998 1	ADJUSTMENT GEAR
25	NO 10	PL PATT MED LK WASH 4 REQD
26	5316815 1	ADJUSTMENT SHAFT
27	5316793 2	ADJUSTMENT GEAR
28	661617 1	CONE PT SET SCR
29	5316812 1	EXHAUST VALVE DIAPHRAGM
30	5316813 1	DIAPHRAGM CLAMP
31	10 32	MED HEX NUT 4 REQD

\*FOR HAND RELAY PT NO 5321995 2 ROTATE ITEM (24) 180° TO POSITION SHOWN BY DASHED LINES

SPARE PARTS KIT NO 256127 1  
INCLUDES (TEMS 2 4, 6, 10, 12 15 17, 19, 21 29

FIGURE 12 - Parts Drawing P91 7, Hand Relay, Part No. 5321995 □



ITEM	PART NO	NAME
1	CODE LABEL	SPECIFY NO WHEN ORDERING PARTS
2	SEE TABLE	MINIMUM STOP
3	SEE TABLE	MAXIMUM STOP
5	SEE NOTE	MECHANISM ASSY INCLUDES ITEMS 5A & 5B
5A	SEE NOTE	BOURDON TUBE & BLOCK ASSY
5B	SEE NOTE	POINTER SEE TABLE
6	SEE NOTE	SCALE ASSY
7	#3 48x3 1/8	PAN HD STL NCR 4 REQD
8	NO 1203	SHK LK WASH 4 REQD
9	5314456 1	WASHER 2 REQD
10	5314337 1	FASTENER 2 REQD
11	5314336 1	COVER PLATE ASSY
12	6 32x7 8	PAN HD EXT SEMS 3 REQD
13	SEE NOTE	COVER
14	6 32x1 4	PAN HD EXT SEMS 4 REQD
15	5314294 1	SCALE WINDOW
16	SEE TABLE	GASKET
17	5322355 1	GASKET
18	SEE NOTE	CASE ASSY
19	5320314 2	TUBING ADAPTER ASSY (REQD FOR PM MULTI POINT GAGES ONLY FOR TUBING FOR OTHER INSTRUMENTS SEE APPLI CABLE PARTS DRAWING )

SPARE PARTS KIT NO 256028 1	
QUANTITY	ITEM NO
2	15

	POINTER	GAGE UNIT RANGE	ITEM 2	ITEM 3	ITEM 16
	DOUBLE	3 2T OR 5 75 PSIG	5315411 1	5315411 2	5322195 2
	SINGLE	3 2T OR 5 25 PSIG	5315411 1	5315411 2	5322195 1
	SINGLE	3 15 OR TYPE PM MODEL DO*	5315701 1	5319411 1	5322195 1
	DOUBLE	3 15 OR TYPE PV MODEL DC*	5315701 1	5315411 1	5322195 2
	SINGLE	TYPE PM MODEL V ONLY*	5315411 1	5315701 1	5322195 1

\*RANGE PER ENGINEERING DATA (SEE NOTE)

NOTE SPECIFY TYPE MODEL SERIAL NUMBER AND RANGE OF INSTRUMENT  
 ALSO FOR POINTER (ITEM 5B) SPECIFY WHETHER LEFT RIGHT OR BOTH LEFT AND RIGHT ARE DESIRED  
 ALSO FOR SCALE (ITEM 6 SPECIFY LEGEND AND RANGE FIGURES

FIGURE 13 Parts Drawing P12 5, Vertical Gage Unit