


### *MINI-LINE 520\** Manual Loading Station Type FL



**WARNING**INSTRUCTION MANUALS

DO NOT INSTALL, MAINTAIN OR OPERATE THIS EQUIPMENT WITHOUT READING, UNDERSTANDING AND FOLLOWING PROPER Babcock & Wilcox Bailey Meter Co USA INSTRUCTIONS AND MANUALS OTHERWISE INJURY OR DAMAGE MAY RESULT

**ATTENTION**MANUELS D'OPERATION

NE PAS METTRE EN PLACE, RÉPARER OU FAIRE FONCTIONNER CE MATÉRIEL SANS AVOIR LU, COMPRIS ET SUIVI LES INSTRUCTIONS RÉGLEMENTAIRES DE Babcock & Wilcox Bailey Meter Company, U S A TOUTE NÉGLIGENCE À CET ÉGARD POURRAIT ÊTRE UNE CAUSE D'ACCIDENT OU DE DÉFAILLANCE DU MATÉRIEL

**TABLE OF CONTENTS**

	<u>Page</u>
INSTALLATION	2
PLACING IN SERVICE	5
ROUTINE MAINTENANCE	7
CALIBRATION	7
TROUBLESHOOTING	7
OPERATION	9
THEORY OF OPERATION	10
NOMENCLATURE	10
SPECIFICATIONS	11
REPLACEMENT PARTS	12

**INSTALLATION**Unpacking and Storage

- 1 Check for any obvious damage to shipping carton or contents Report any damage to carrier
- 2 Make certain that unit is correct range for intended service (refer to identification label).
- 3 If station is to be stored, repack in original container and store within temperature limits 20° to 120°F (-7° to 49°C)

Pre-Service Adjustment Check

**CAUTION** Before placing Manual Station in service, check adjustment of vertical gage units as outlined below Also check calibration of gage units as outlined under "Troubleshooting", "Vertical Gage Unit Assembly" It is recommended that this check be performed at a test bench before the station is installed in the panel or placed in operation

**ATTENTION** Avant de mettre la station manuelle en service, vérifier le réglage des éléments de jauges verticales de la façon indiquée ci-dessous Vérifier également le calibrage des éléments de jauge comme il est indiqué dans le chapitre "Dépannage" sous le titre "Ensemble des jauges verticales" Il est recommandé d'effectuer cette vérification sur un banc d'essai avant d'installer la station sur le tableau ou de la mettre en service

Position station at the angle at which it will be mounted in service and check that the indicating pointers of both vertical gages read slightly below minimum scale (0) If they do not, proceed as follows

1. Remove scale cover by prying outward on lip at top of cover.
- 2 Apply 3 psig (20.7 kPa) and adjust zero adjustment screws (Figure 3) through holes in scale using 5/64 inch Allen wrench until both pointers read minimum scale




FIGURE 1 – External and Mounting Dimensions, Manual Loading Station, Type FL

Also check calibration by performing the procedures listed under "Troubleshooting", "Vertical Gage Unit Assembly"

After the calibration check is complete the station is ready for panel mounting and external connections as follows:

1 Slide station through panel from front (Refer to Figure 1 for correct panel cutout dimensions.)

2 Place mounting clips (Figure 1) in position and tighten securely against panel

3 Make external connections to rear of station with 1/8" -27 NPT pipe fittings as follows (Figure 2)

Connection #1 - FL1□□ Input  
FL4□□ Bias Input

Connection #2 - Station Output

Connection S - Station Air Supply

(For selection and installation of pneumatic connecting tubing or process connecting piping, refer to Bailey Product Instruction G18-1 or G18-2 )

4 Remove protective tape from plastic scale covers. Use a cleaning solvent (e.g. lighter fluid or kerosene) to remove any excess adhesive on scale cover. Wipe off solvent with a damp cloth.

**CAUTION** Apply solvent to scale covers only, making certain fluid does not run or drip over trim pieces or station front plate. Also, do not use solvents which will scratch cover finish or react with plastic cover (e.g. ketones, esters and aromatic or chlorinated solvents such as carbon tetra chloride, chloroethene or tri chloroethylene)

**ATTENTION** N'appliquer des dissolvants que sur les couvercles des graduations en faisant attention que le liquide ne coule pas ni ne déborde sur les garnitures ou le panneau avant de la station. Ne pas utiliser non plus de dissolvants qui risqueraient de decaper le vernis des couvercles ou d'attaquer les boîtiers en plastique (Dissolvants tels que les cétones, esters, dissolvants aromatiques ou chlorés, comme le tétra chlorure de carbone, le chloroéthène ou le tri chloroéthylène)

5 Adjust air supply to

18 to 20 psig (124 to 140 kPa) for 3 to 15 psig (20.7 to 103 kPa) range

30 to 35 psig (20.6 to 241.3 kPa) for 3 to 27 psig (20.7 to 186 kPa) range




FIGURE 2 – External Connection and Tubing Diagram, Manual Loading Station, Type FL




FIGURE 3 – Vertical Gage Unit Range, Linearity and Zero Adjustments

## PLACING IN SERVICE

After the Manual Station has been installed in the control panel

- 1 Turn on supply pressure to station
- 2 Check all external tubing connections for leakage with a soapsuds solution
- 3 Adjust manual control knob on front plate (Figure 4) until desired output is indicated on vertical gage

NOTE See Figures 5 through 8 and refer to applicable heading below for typical applications

### Basic Manual Station (Figure 5)

Output pressure from the Basic Manual Station is normally applied to a power unit (control drive, valve, etc ) for remote control. The output pressure is produced by a regulator (Figure 10) which is manually adjusted by a knob on the station front plate. A double pointer vertical gage unit indicates Manual Station output pressure and the input pressure to the Controller (measured variable).

### Set Point Manual Station (Figure 6)

Output pressure from the Set Point Manual Station is normally applied to a Controller to establish the control set point. The output pressure is produced by a regulator (Figure 10) which is manually adjusted by the knob on the station front plate. A double pointer vertical gage unit indicates Manual Station output (set point) pressure and input pressure to the Controller.

### Tie-Back Manual Station (Figure 7)

Output pressure from the Tie-Back Manual Station is normally applied to a Manual/Auto Transfer Station to control the output pressure of a Controller. The Manual Station output pressure is produced by a regulator (Figure 10) which is




FIGURE 4 – Type FL Manual Loading Station

manually adjusted by the knob on the station front plate. A double pointer vertical gage unit indicates Manual Station output (tie-back) pressure and Controller output pressure.

### Bias Manual Station (Figure 8)

Output pressure from the Bias Manual Station is normally applied to a power unit (control drive, valve, etc ) for remote control. The output pressure is produced by a regulator (Figure 10) which is manually adjusted by a knob on the station front plate. A double pointer vertical gage unit indicates input (loading) pressure from a Controller and Manual Station output (bias) pressure.




FIGURE 5 – Typical Application of Basic Manual Station




FIGURE 6 – Typical Application of Set Point Manual Station




FIGURE 7 – Typical Application of Tie-Back Manual Station




FIGURE 8 – Typical Application of Bias Manual Station

## ROUTINE MAINTENANCE

1 Maintain a clean air supply, free of oil or moisture

2 Check filter in supply inlet port in rear of station, shortly after installation (Figure 9). If replacement is necessary, remove wire mesh disc, felt pad and second wire mesh disc. Install new wire disc, felt pad and second wire mesh disc. Make certain wire mesh disc is inserted in inlet port before inserting felt pad.

Whenever necessary, clean the acrylic scale cover as described under "Installation", "Pre-Service Adjustment Check".




FIGURE 9 – Supply, Input and Output Ports for Manual Loading Station, Type FL

## CALIBRATION

Calibration procedures for the Vertical Gage Unit Assembly are found under "Troubleshooting" in this manual. Calibration of the Pressure Regulator Assembly is performed at the factory. If any adjustment is necessary or the unit becomes

inoperative, the entire assembly should be removed from the station and returned to the factory. Follow the procedure outlined under "Troubleshooting", "Pressure Regulator Assembly".

## TROUBLESHOOTING

If operational faults occur which are traced to the following assemblies, make the listed adjustment checks found under the particular assembly.

### Vertical Gage Unit Assembly (Figure 3)

1 Remove side covers from station by removing retaining screws and sliding covers to rear.

2 Remove rear snapout cover, side cover and scale cover (refer to PDP91-10-2) from vertical gage unit assembly for access to adjustments.

3. Position station at angle at which it will be mounted in service and check adjustment of input and output pointers as follows.

a Apply regulated input pressure with  $\pm 1\%$  input gage accuracy to port 1 to check left hand (input) pointer reading. Check for leakage by applying a soapsuds solution to connection points.

b To check right hand (output) pointer, apply supply pressure to port S and install a test gage ( $\pm 1\%$  accuracy) in port 2. Adjust regulator knob and compare vertical pointer gage to test gage. Check for leakage by applying a soapsuds solution to connection points.

NOTE If a pressure leak is discovered, replace entire gage unit. Unit may be returned to factory for repair. Refer to section titled "Removal and Replacement of Vertical Gage Unit Assembly", for this procedure.

4 Check links to make sure they are properly connected and move freely with bellows beam movement.

5 Make certain indicating pointers do not rub against side or face of scale. If necessary, bend pointer slightly.

6 Apply pressure to gage unit equal to first major scale division above 0% scale. If pointer

does not read correctly turn zero adjustment screw (Figure 3) until desired reading is obtained. Zero adjustment is accessible from front of station by removing scale cover and inserting a 5/64 inch Allen wrench thru hole in scale.

7 Apply pressure to gage unit equal to first major scale division below 100% scale. If pointer does not read correctly, turn range adjustment screw (Figure 3) until desired reading is obtained.

8 Repeat steps 6 and 7 until pointer reads correctly at both scale divisions.

9 Apply pressure to gage unit equal to mid-scale division. If pointer does not read correctly, but does read correctly in steps 6 and 7 above, adjust angularity pivot shaft (linearity adjustment) to bring pointer reading to midscale (Figure 3).

10 Repeat steps 6 thru 9 until pointer reads correctly over full scale.

11 Apply pressure to gage unit equal to maximum scale value plus 0.25 psig (1.7 kPa). (Pointer will read slightly above maximum scale mark). Loosen maximum stop screws, position over travel stop bracket against range spring retaining nut and retighten screws.

12 Apply 2.8 psig (19.3 kPa) to gage unit. (Pointer will read slightly below maximum scale mark). Turn elastic stop nut against over travel stop bracket.

13 Replace scale cover, gage side cover, rear snapout cover and station side covers.

#### Removal and Replacement of Vertical Gage Unit Assembly

1 Remove vertical gage scale cover, regulator knob and six flat head screws (PDP91-10-1, Item 33).

2 Remove front plate (5).

3 Remove two screws (34).

4 Disconnect tubing from vertical gage fittings and remove unit from station.

5 Install new gage by reversing above procedure. New tubing and clamps are supplied with new vertical gage unit.

#### Pressure Regulator Assembly

The pressure regulator assembly (Figure 10) includes a cleanout screw. Periodically, remove the screw and clean the orifice by inserting a wire, .008 inches (2 mm) or less in diameter, through screw hole in regulator body. If the pressure regulator becomes inoperative, the entire assembly should be removed from the station and returned to the factory.

Procedure for removal of the regulator is as follows:

1 Remove side cover from station by removing retaining screws (PDP91-10-1) and sliding covers to rear.

2 While holding shaft extender (Item 11), loosen jam nut (30).

3 Remove four screws (32) which hold regulator in place.

4 While holding elastic stop nut, rotate shaft extension by turning control knob on front of station.

5. When regulator adjustment shaft is free of shaft extension, remove tubing from end of regulator and remove regulator from station.

6 Install new regulator by reversing above procedure. New tubing and clamps are supplied with new regulator.



## OPERATION

The Type FL Manual Station provides a means of manually adjusting a pneumatic output signal for remote manual operation of pneumatic control elements, or generation of set point or tie-back signals and positive or negative biasing of an input signal

The station consists of a double pointer vertical indicator gage and a pressure regulator assembly. The vertical indicator gage uses a spring opposed bellows assembly to convert pneumatic signals to pointer positions.

### Left Gage Pointer

In basic, set point, tie back stations this pointer displays an input or measured variable. In bias stations the left gage pointer displays a bias input which is also applied to the station's bias regulator.

### Right Gage Pointer

In bias, basic, set point and tie back stations this pointer displays the station's output.

To effect an output change the regulator knob on the station front plate is rotated while observing the right hand gage pointer. The operation of the pressure regulator assembly is explained below.

### Pressure Regulator Assembly (Figure 10)

Basic, Set Point and Tie-Back Manual Station input force against the diaphragm is variable as

the regulator knob is turned and the spring assembly is compressed or depressed.

An unbalance between the input pressure provided by the spring assembly and the output pressure in the feedback chamber moves the diaphragm. Movement of the diaphragm is transmitted to the vane, of the vane and nozzle assembly through the vane stem. Movement of the vane against the nozzle changes the amount of air venting through the nozzle. As vane resistance varies, pressure in the nozzle backpressure chamber varies which allows the nozzle assembly to shift position permitting more supply air into the output chamber by lifting the valve stem off the seat. It reduces output pressure in the output chamber by allowing the nozzle assembly to move off the valve stem and vent through the center of the nozzle assembly and through the exhaust chamber to atmosphere. Pressure remaining in the output chamber is the output pressure and is tied to the feedback chamber. For Basic, Set Point and Tie-Back Stations

$$\text{Output} = \text{Spring Force}$$

Bias Manual Station operation is identical to the other Manual Stations except that force against the diaphragm is the bias input pressure plus or minus the tension on the spring assembly. For Bias Manual Stations

$$\text{Output} = \text{Bias Chamber Pressure} \pm \text{Spring Force.}$$




FIGURE 10 – Pressure Regulator Assembly

## THEORY OF OPERATION

A Bailey Type PS Double Pointer Gage displays the actual signal magnitude. The left pointer displays either bias input or a measured variable. The right hand gage displays station output or, set point, tie back or bias signals. The gage itself, employs a spring-opposed bellows assembly to convert pneumatic signals to pointer positions. Access to zero adjustments is provided through the front of the station, by removing the gage scale cover and inserting an Allen wrench through the holes provided in the scale.

The regulator is a miniature, multi-stage, precision pressure regulator. A force balance system compares the input with a feedback force produced by the output. The input may be the result of loading by the range spring assembly or from a bias input pressure in the bias chamber, or a combination of both. An unbalance between the input(s) at the output causes deflection which is transmitted to the second stage by the vane stem.

The nozzle assembly may be considered an "operator" for the second stage. The vane stem deflects the vane which seals off the nozzle. The resulting change in back pressure moves the nozzle assembly and the output valve stem. This "power assist" effect of the moving vane and nozzle assembly provides greater capacity and better accuracy of the output pressure with respect to the input(s).

Operation of the output valve stem supplies or exhausts output air until the output pressure feedback to the first stage brings the unit to balance at an output pressure which corresponds to the new input.

The ability of the nozzle to move with the second stage provides a minor feedback loop which provides for greater regulator stability.

## NOMENCLATURE

Digit	1	2	3	Description
FL	↓	↓	↓	Manual Loading Station Universal (Basic, Setpoint, Tie Back)
	1	↓	↓	Bias
	4	↓	↓	3 to 15 PSIG (20.7 to 108 kPa) output
		1	↓	3 to 27 PSIG (20.7 to 186 kPa) output
		2	↓	Standard 0-100% scale
			0	Direct reading scale
			5	

## SPECIFICATIONS

<b>Accuracy†</b>	
<b>Bias Regulator</b>	±2% of span
<b>Vertical Gage</b>	±1% of span
<b>Input/Output Signal Range</b>	3 to 15 PSIG (20.7 to 103 kPa) 3 to 27 PSIG (20.7 to 186 kPa)
<b>Air Supply</b>	For 3 to 15 PSIG (20.7 to 103 kPa) signal range 18 to 20 PSIG (124 to 138 kPa) recommended 25 PSIG (172 kPa) maximum For 3 to 27 PSIG (20.7 to 186 kPa) signal range 30 PSIG (207 kPa) recommended 35 PSIG (241 kPa) maximum
<b>Air Consumption (Steady State)</b>	0.1 scfm (4.72 x 10 <sup>-4</sup> m <sup>3</sup> /S), maximum
<b>Regulator Supply Capacity</b>	0.5 scfm (2.36 x 10 <sup>-4</sup> m <sup>3</sup> /S) for 1 PSIG decrease in output pressure minimum at mid range
<b>Regulator Exhaust Capacity</b>	>0.25 scfm (1.42 x 10 <sup>-4</sup> m <sup>3</sup> /S) for 1 PSIG increase in output pressure minimum at mid range
<b>Supply Pressure Effect</b>	0.1 for 1 PSIG change in supply pressure, maximum
<b>External Connections</b>	1/8 inch - 27 NPT female
<b>Operating Temperature Ranges</b>	Normal 40° to 140°F (4.4° to 60°C) Maximum - 20° to 140°F (-4.4° to 60°C)
<b>Temperature Effect</b>	±2.0% per 100°F (37.8°C)
<b>Mounting</b>	Mounts directly into panel cutout
<b>Indicating Scale</b>	Length 3-3/16" (81 mm) Standard Marking white divisions and figures on black styrene plastic Standard Range 0-100%
<b>Service Legend</b>	1 or 2 rows, 13 characters, 0.1" high
<b>Weight</b>	Net 3.19 lbs (1.45 kg) Shipping 3.94 lbs (1.79 kg)
<b>Size</b>	1.46" W (37 mm) x 6.25" H (159 mm) x 11.25" D (286 mm)

†As defined by SAMA Standard PMC20.1

**REPLACEMENT PARTS****Ordering Individual Parts**

The following Parts Drawings represent the Type FL Manual Station and internal assemblies. Normally, these drawings apply to the unit furnished. However, there may be individual differences in specific units because of

a design changes made since the printing of this *Instruction Section*, or

b special design of the station to make it suitable for a special application.


Therefore, when ordering parts, assure the receipt of correct replacements by specifying the station type and the parts drawing number on which the part is illustrated.

**Recommended Spare Parts**

The following listed spare parts should be stocked in the quantities listed.

Part No	Name	Quantity
5320414-2	Felt Pad (PDP91-10-1, Item 26)	1
5320413-2	Mesh Disc (PDP91-10-1, Item 18)	4
5327220-1	Scale Cover (PDP91-10-2, Item 6)	2
198494-5	Knob (PDP91-10-1, Item 9)	1

## TYPE FL MANUAL LOADING STATION PART NO 5327100-□



ITEM	PART NO	NAME	ITEM	PART NO	NAME	ITEM	PART NO	NAME
1	1962851 2	NAMEPLATE	17	1962859 1	TUBING DIAGRAM, BASIC SET POINT, TIE-BACK	31	1210-00	STL SHKPF LKWASH
2	5327099-1	FRAME PLATE, 2 REQD	1962859 3	TUBING DIAGRAM, BIAS	32	112-40x 250	LG HEX HD STL CAP SCR, 4 REQD	
3	5327103 1	SUPPORT BRACKET	18	5320413 2	WIRE MESH DISC, 4 REQD	33	112-40x 25	LG PHILLIPS FLAT HD STN STL MACH SCR, 6 REQD
4	5328379-1	TRIM PACKAGE, 1 REQD PER HORIZONTAL ARRAY	19	1951409 1	CAP OMIT ON BIAS UNITS	34	190 32x 375	LG PAN HD STL SEMS EXT, 2 REQD
5	5327101-1	FRONT PLATE	20*	1951423-1	COMPRESSION CLIP, 6 REQD	35	190-32x 375	LG PHILLIPS FLAT HD STN STL MACH SCR, 4 REQD
6	5327079-1	SIDE COVER, 2 REQD	21	1962939-1	NAMEPLATE	36	112-40x 188	LG PAN HD STL SEMS EXT, 2 REQD
7	5327894-1	DOUBLE POINTER GAGE, 3 15 PSIG	22	SEE TABLE	SCALE	37	112	HELICAL SPR STN STL LKWASH, 8 REQD
	5327894 2	DOUBLE POINTER GAGE, 3-27 PSIG	23	SEE TABLE	SCALE RIB	38	112-40	STN STL HEX NUT, 4 REQD
8	1962851-2	LOGO NAMEPLATE	24	1962941-1	STYLEPLATE	39	138	STN STL FLAT WASHER, 4 REQD
9	198494 5	KNOB	25	1951533-1	FITTING TUBE, 2 REQD	40	112-40x 3125	LG FLAT HD STN STL MACH SCR, SEE TABLE
10	5314614-1	MOUNTING CLIP, 2 REQD	26	5320414 2	FELT PAD	41	SEE TABLE	STATION MANUAL LOADING
11	5327104 1	SHAFT, EXTENDER	27*	R9025-0426	094IDX 156 OD CLEAR POLYUR TUBING			
12	67125 2	RUBBER GROMMET	28*	R9025-0410	172 IDX 297 OD CLEAR POLYUR TUBING (SEE TABLE)			
13	5327770 2	REGULATOR, 3 15 PSIG	29	112-40x 375	LG PHILLIPS FLAT HD STN STL MACH SCR, 4 REQD			
	5327770-1	REGULATOR, 3 27 PSIG	30	190-32	STN STL HEX NUT			
14	5327692 1	CONNECTOR BODY ASSY						
15	1951049-3	COMPRESSION CLIP, 4 REQD						
16	1945750 2	PULL PLUG, 3 REQD						


\*NOTE These items are not shown on drawing

TYPE NO	PSIG	SCALE	ITEM 22	*ITEM 23	ITEM 28	ITEM 40	ITEM 41
FL110	3 15	0-100%	5327722 1	*5327369-37 (10 major 20 minor divisions)	6"	4 Reqd per horizontal array	5327100-1
FL410	3 15		5327722-2		12"		2
FL120	3 27				6"		3
FL420	3-27				12"		-4
FL115	3-15	ENG UNITS	5327370-14	See note 2	6"		-1
FL415	3-15		See note 1		12"		-2
FL125	3-27				6"		-3
FL425	3 27				12"		-4

\*Black rib with white lines

- Notes 1 Blank scale (part no 5327370 14) engraved or silkscreened per customer request
- 2 Scale rib (part no 5327369-38, 39, -40, -41, -42) provided as required

PART NO	MAJOR DIVISIONS	MINOR DIVISIONS
5327369-38	5	25
5327369-39	4	20
5327369-40	8	40
5327369-41	6	30
5327369-42		

DOUBLE POINTER GAGE  
PART NO. 5327894-□

ITEM	PART NO	NAME
1	SEE NOTE	EDGEWISE INDICATOR, PER ENG DATA
2	5327221A2	REFLECTOR
3	5327218A1	SCALE HOLDER
4	PER ENG DATA	SCALE
5	PER ENG DATA	SCALE RIB
6	5327220A1	SCALE COVER
10		NAMEPLATE
11		STYLEPLATE
12	5314336A1	SNAPOUT COVER
16	112-40x3/8	PAN HD SCR, TYPE I

SPARE PARTS KIT NO 256028 1	
QUANTITY	ITEM NO
2	6


NOTE TO ORDER REPLACEMENT INDICATORS INCLUDE ALL DATA ON NAMEPLATE (ITEM 10)

5327894 1 (3 to 15 psig)  
5327894-2 (3 to 27 psig)





## REGULATOR ASSEMBLY PART NO. 5327770-□



ITEM	PART NO	NAME
1	5327750 1	SHAFT, ADJUST- MENT
3	6618445 2	WASHER, NYLON
4	5311428 2	O RING
5	35305 1	WASHER, LATCH
6	197146-6	RING, RETAINING
7	5327744-1	SPRING
8	SEE TABLE	SPRING ASSY
9	5327753 1	STEM, VANE
11	5327766-1	NOZZLE ASSY
13	5327769 1	NOZZLE
14	5327898 1	GASKET
15	5327768 1	CUP, SEAL
16	197622-1	SCREW, SEALING, 4 REQD
17	5327746 1	SPRING, FINGER
18	5327761 1	VANE ASSY
19	5327899-1	VALVE ASSY
20	#1106-A5	SPACER, ROLLED SPLIT, 6 REQD
21	197120-14	NUT, ELASTIC STOP

RANGE	PART NO	ITEM 8
3-27 PSIG	5327770 1	5327765 1
3 15 PSIG	5327770-2	5327765 2

