


E96-425

Bailey®  
**infi 90**®

Instruction

## Analog Input Calibration Module (NIAC03)



**Bailey**

Process Control and  
Automation Solutions  
from Elsag Bailey Group

**WARNING** notices as used in this instruction apply to hazards or unsafe practices that could result in personal injury or death.

**CAUTION** notices apply to hazards or unsafe practices that could result in property damage.

**NOTES** highlight procedures and contain information that assists the operator in understanding the information contained in this instruction.

## **WARNING**

### **INSTRUCTION MANUALS**

DO NOT INSTALL, MAINTAIN, OR OPERATE THIS EQUIPMENT WITHOUT READING, UNDERSTANDING, AND FOLLOWING THE PROPER **Elsag Bailey** INSTRUCTIONS AND MANUALS; OTHERWISE, INJURY OR DAMAGE MAY RESULT.

### **RADIO FREQUENCY INTERFERENCE**

MOST ELECTRONIC EQUIPMENT IS INFLUENCED BY RADIO FREQUENCY INTERFERENCE (RFI). CAUTION SHOULD BE EXERCISED WITH REGARD TO THE USE OF PORTABLE COMMUNICATIONS EQUIPMENT IN THE AREA AROUND SUCH EQUIPMENT. PRUDENT PRACTICE DICTATES THAT SIGNS SHOULD BE POSTED IN THE VICINITY OF THE EQUIPMENT CAUTIONING AGAINST THE USE OF PORTABLE COMMUNICATIONS EQUIPMENT.

### **POSSIBLE PROCESS UPSETS**

MAINTENANCE MUST BE PERFORMED ONLY BY QUALIFIED PERSONNEL AND ONLY AFTER SECURING EQUIPMENT CONTROLLED BY THIS PRODUCT. ADJUSTING OR REMOVING THIS PRODUCT WHILE IT IS IN THE SYSTEM MAY UPSET THE PROCESS BEING CONTROLLED. SOME PROCESS UPSETS MAY CAUSE INJURY OR DAMAGE.

## **AVERTISSEMENT**

### **MANUELS D'OPÉRATION**

NE PAS METTRE EN PLACE, RÉPARER OU FAIRE FONCTIONNER L'ÉQUIPEMENT SANS AVOIR LU, COMPRIS ET SUIVI LES INSTRUCTIONS RÉGLEMENTAIRES DE **Elsag Bailey**. TOUTE NÉGLIGENCE À CET ÉGARD POURRAIT ÊTRE UNE CAUSE D'ACCIDENT OU DE DÉFAILLANCE DU MATÉRIEL.

### **PERTURBATIONS PAR FRÉQUENCE RADIO**

LA PLUPART DES ÉQUIPEMENTS ÉLECTRONIQUES SONT SENSIBLES AUX PERTURBATIONS PAR FRÉQUENCE RADIO. DES PRÉCAUTIONS DEVONT ÊTRE PRISES LORS DE L'UTILISATION DU MATÉRIEL DE COMMUNICATION PORTATIF. LA PRUDENCE EXIGE QUE LES PRÉCAUTIONS À PRENDRE DANS CE CAS SOIENT SIGNALÉES AUX ENDROITS VOULUS DANS VOTRE USINE.

### **PERTURBATIONS DU PROCÉDÉ**

L'ENTRETIEN DOIT ÊTRE ASSURÉ PAR UNE PERSONNE QUALIFIÉE EN CONSIDÉRANT L'ASPECT SÉCURITAIRE DES ÉQUIPEMENTS CONTRÔLÉS PAR CE PRODUIT. L'AJUSTEMENT ET/OU L'EXTRAC-TION DE CE PRODUIT PEUT OCCASIONNER DES À-COUPS AU PROCÉDÉ CONTRÔLE LORSQU'IL EST INSÉRÉ DANS UNE SYSTÈME ACTIF. CES À-COUPS PEUVENT ÉGALEMENT OCCASIONNER DES BLESSURES OU DES DOMMAGES MATÉREELS.

## **NOTICE**

The information contained in this document is subject to change without notice.

Elsag Bailey, its affiliates, employees, and agents, and the authors and contributors to this publication specifically disclaim all liabilities and warranties, express and implied (including warranties of merchantability and fitness for a particular purpose), for the accuracy, currency, completeness, and/or reliability of the information contained herein and/or for the fitness for any particular use and/or for the performance of any material and/or equipment selected in whole or part with the user of/or in reliance upon information contained herein. Selection of materials and/or equipment is at the sole risk of the user of this publication.

This document contains proprietary information of Elsag Bailey, Elsag Bailey Process Automation, and is issued in strict confidence. Its use, or reproduction for use, for the reverse engineering, development or manufacture of hardware or software described herein is prohibited. No part of this document may be photocopied or reproduced without the prior written consent of Elsag Bailey.

---

## Preface

---

The NIAC03 Analog Input Calibration Module provides a means to calibrate 100 ohm resistance temperature detector (RTD) inputs for the IMASM03 Analog Slave Module.

This manual explains how to install and use the NIAC03 module on the INFI 90® Strategic Process Management System. It has sections that describe the setup and cabling. The appendix contains information about the IMASM03 module.

---

® INFI 90 is a registered trademark of Elsag Bailey Process Automation.

## List of Effective Pages

---

Total number of pages in this manual is 20, consisting of the following:

| <b>Page No.</b>         | <b>Change Date</b> |
|-------------------------|--------------------|
| Preface                 | Original           |
| List of Effective Pages | Original           |
| iii through v           | Original           |
| 1-1 through 1-5         | Original           |
| 2-1 through 2-5         | Original           |
| 3-1                     | Original           |
| 4-1                     | Original           |
| 5-1                     | Original           |
| A-1                     | Original           |
| Index-1                 | Original           |

**NOTE:** On an updated page, the changed text or table is indicated by a vertical bar in the outer margin of the page at the changed area. A changed figure is indicated by a vertical bar in the outer margin next to the figure caption. The date the update was prepared will appear beside the page number.

---

## Safety Summary

---

**GENERAL  
WARNINGS****Equipment Environment**

All components, whether in transportation, operation or storage, must be in a noncorrosive environment.

**Electrical Shock Hazard During Maintenance**

Disconnect power or take precautions to insure that contact with energized parts is avoided when servicing.

**SPECIFIC  
CAUTIONS**

Remove modules from their module mounting unit slots before installing or removing a cable assigned to that slot. Failure to do so could result in damage to the module. (p. 2-4, 4-1)

---

## Sommaire de Sécurité

---

**AVERTISSEMENTS  
D'ORDRE  
GÉNÉRAL****Environnement de l'équipement**

Ne pas soumettre les composants à une atmosphère corrosive lors du transport, de l'entreposage ou l'utilisation.

**Possibilité de chocs électriques durant l'entretien**

Débrancher l'alimentation ou prendre les précautions pour éviter tout contact avec des composants sous tension durant l'entretien.

**ATTENTIONS  
D'ORDRE  
SPÉCIFIQUE**

Retirer le module de son emplacement dans le chassis de montage des modules avant d'installer ou de retirer un cable assigné à cet emplacement. Un manquement à cette procédure pourrait endommager le module. (p. 2-4, 4-1)

---

---

# Table of Contents

|  | <i>Page</i> |
|--|-------------|
| <b>SECTION 1 - INTRODUCTION.....</b>                       | <b>1-1</b>  |
| OVERVIEW .....   | 1-1         |
| INTENDED USER.....   | 1-1         |
| MODULE DESCRIPTION .....                                   | 1-1         |
| HARDWARE APPLICATION.....                                  | 1-1         |
| FEATURES.....  | 1-1         |
| INSTRUCTION CONTENT .....                                  | 1-3         |
| HOW TO USE THIS MANUAL .....                               | 1-3         |
| REFERENCE DOCUMENTS.....                                   | 1-3         |
| GLOSSARY OF TERMS AND ABBREVIATIONS .....                  | 1-4         |
| NOMENCLATURE .....   | 1-4         |
| SPECIFICATIONS.....  | 1-4         |
| <b>SECTION 2 - INSTALLATION.....</b>                       | <b>2-1</b>  |
| INTRODUCTION.....  | 2-1         |
| SPECIAL HANDLING .....                                     | 2-1         |
| UNPACKING AND INSPECTION .....                             | 2-2         |
| SETUP/PHYSICAL INSTALLATION .....                          | 2-2         |
| Jumper Settings .....                                      | 2-2         |
| Cable Installation.....                                    | 2-2         |
| Module Installation .....                                  | 2-5         |
| <b>SECTION 3 - MAINTENANCE.....</b>                        | <b>3-1</b>  |
| INTRODUCTION.....  | 3-1         |
| MAINTENANCE SCHEDULE .....                                 | 3-1         |
| <b>SECTION 4 - REPAIR/REPLACEMENT PROCEDURES .....</b>     | <b>4-1</b>  |
| INTRODUCTION.....  | 4-1         |
| REPLACEMENT PROCEDURES.....                                | 4-1         |
| <b>SECTION 5 - SUPPORT SERVICES.....</b>                   | <b>5-1</b>  |
| INTRODUCTION .....   | 5-1         |
| REPLACEMENT PARTS AND ORDERING .....                       | 5-1         |
| TRAINING .....   | 5-1         |
| TECHNICAL DOCUMENTATION .....                              | 5-1         |
| <b>APPENDIX A - IMASM03 ANALOG SLAVE INPUT MODULE.....</b> | <b>A-1</b>  |
| INTRODUCTION.....  | A-1         |

---

## List of Figures

| <i>No.</i> | <i>Title</i>                                    | <i>Page</i> |
|------------|---|-------------|
| 1-1.       | Application Example for the NIAC03 Module ..... | 1-2         |
| 2-1.       | NIAC03 Module Jumper Locations .....            | 2-3         |
| 2-2.       | Cable Connections for the NIAC03 Module .....   | 2-3         |
| A-1.       | Address Select Switch (SW1) .....               | A-1         |

---

## List of Tables

| <i>No.</i> | <i>Title</i>                              | <i>Page</i> |
|------------|---|-------------|
| 1-1.       | Reference Documents .....                 | 1-4         |
| 1-2.       | Glossary of Terms and Abbreviations ..... | 1-4         |
| 1-3.       | Nomenclature .....                        | 1-4         |
| 1-4.       | Specifications .....                      | 1-5         |
| 2-1.       | NIAC03 Module Cable Applications .....    | 2-3         |
| 3-1.       | Maintenance Schedule.....                 | 3-1         |
| A-1.       | Address Switch Settings (SW1) .....       | A-1         |

---

# SECTION 1 - INTRODUCTION

---

## OVERVIEW

The NIAC03 Analog Input Calibration Module is required to calibrate the IMASMO3 Analog Slave Module (100 ohm resistance temperature detector (RTD)). Calibration resistances are read from the NIAC03 module through the IMASMO3 slave module. Calibration values are read across the slave expander bus and processed by the IMAMM03 master module.

This manual explains the purpose, setup, handling precautions and steps to install the NIAC03 module. Calibrate the slave according to the IMAMM03 product instruction. Refer to the table of contents to find the information. Refer to the **HOW TO USE THIS MANUAL** entry in this section to get started.

---

## INTENDED USER

System engineers and technicians should read this manual before installing and using the termination module. Put the module into operation only after reading and understanding this instruction.

---

## MODULE DESCRIPTION

The NIAC03 module is a single printed circuit board that uses one slot in a NTMU01 or NTMU02 Termination Mounting Unit. The module has one card edge connector (P1) that connects to a slave module mounted in a dedicated calibration slot, through a cable. Jumpers on the NIAC03 module select one input at a time to be calibrated for zero or span.

---

## HARDWARE APPLICATION

The NIAC03 module has on-board precision resistors on the termination module that are used to calibrate the zero and span of the slave inputs. The IMASMO3 module must be physically moved to the dedicated calibration slot. The associated IMAMM03 module issues the calibration commands to the IMASMO3 module. Figure 1-1 shows an application example for the NIAC03 module.

---

## FEATURES

The design of the NIAC03 module, as with all INFI 90 devices, allows for flexibility in creating a process management system. Refer to the **NOMENCLATURE** entry of this section for the list




Figure 1-1. Application Example for the NIAC03 Module

of devices that can be used with the calibration module in an INFI 90 system.

- A standard factory-wired cable connects the calibration module to the slave module.
- Each calibration module fits in a standard termination mounting unit.
- Resistance temperature detector input calibration for the 100 ohm RTD inputs on the IMASM03 module.
- Individual channel precision calibration resistors.
- Jumpers select correct resistance for zero or span calibration for each channel.

---

**INSTRUCTION CONTENT**

This manual has five sections and an appendix.

- |                                      |   |
|--------------------------------------|---|
| <b>Introduction</b>                  | Is an overview of the features, description and specifications and a description of the NIAC03 module.                                    |
| <b>Installation</b>                  | Describes cautions to observe when handling the calibration module. It shows the steps required to install the module and connect cables. |
| <b>Maintenance</b>                   | Provides a maintenance schedule.  |
| <b>Repair/Replacement Procedures</b> | Details how to replace an NIAC03 module.  |
| <b>Support Services</b>              | Describes the support services (repair parts, training, documentation, etc.) available from Bailey Controls Company.                      |
| <b>Appendix A</b>                    | Provides a quick reference of dipswitch settings for the IMASM03 Analog Slave Module.   |

---

**HOW TO USE THIS MANUAL**

Read this manual before handling the calibration module. Refer to the sections in this list as needed for more information.

1. Read **Section 2** before connecting the NIAC03 module.
2. Refer to **Appendix A** for the IMASM03 slave module.
3. Refer to **Section 3** for the maintenance schedule.
4. Refer to **Section 4** and **Section 5** when needed.

---

**REFERENCE DOCUMENTS**

Table 1-1 contains the reference documents for the NIAC03 module.

*Table 1-1. Reference Documents*

| Number    | Description  |
|-----------|--|
| I-E96-205 | Analog Master Module and Analog Slave Modules (IMAMM03 and IMASM01/02/03/04) |

---

**GLOSSARY OF TERMS AND ABBREVIATIONS**

Table 1-2 contains the glossary of terms for this manual.

*Table 1-2. Glossary of Terms and Abbreviations*

| Term         | Definition  |
|--------------|---|
| Analog       | Continuously variable as opposed to discretely variable.  |
| RTD          | Resistance temperature detector. A sensing device that changes resistance within a temperature range.                 |
| Slave Module | One of a series of modules designed to perform high or low level operations as directed by a master module.           |
| TMU          | Termination mounting unit. A card cage that provides housing for INFI 90/Network 90 <sup>®</sup> termination modules. |

---

**NOMENCLATURE**

Table 1-3 contains the modules and equipment that can be used with the NIAC03 module:

*Table 1-3. Nomenclature*

| Nomenclature | Description  |
|--------------|--|
| IMASM03      | Analog Slave Module  |
| NKTM01       | Cable, Termination Module (Ribbon)   |
| NKTU02       | Cable, Termination Module (PVC)  |
| NKTU12       | Cable, Termination Module (non-PVC)  |
| NTMU01       | Termination Mounting Unit (Rear Mount)   |
| NTMU02       | Termination Mounting Unit (Front Mount)  |
| 258436_1     | Cable retaining kit used when a round cable connects to the termination mounting unit. |

---

**SPECIFICATIONS**

Table 1-4 contains the specifications for the NIAC03 module.

*Table 1-4. Specifications*

| Property                  | Characteristic/Value   |
|---------------------------|--|
| <b>Power Requirements</b> | No power is required by the NIAC03 module.   |
| <b>Mounting</b>           | Slides into a single slot in the NTMU01 Termination Mounting Unit or NTMU02 Termination Mounting Unit. |

---

<sup>®</sup> Network 90 is a registered trademark of Elsag Bailey Process Automation.

*Table 1-4. Specifications (continued)*

| Property                                      | Characteristic/Value   |
|---|--|
| <b>Environmental</b>                          |  |
| Electromagnetic/ Radio Frequency Interference | No values available at this time. Keep cabinet doors closed. Do not use communication equipment closer than two meters from the cabinet. |
| Ambient Temperature                           | 0° to 70°C (32° to 158°F)  |
| Relative Humidity                             | 5% to 90% ±5% up to 55°C (131°F) (noncondensing)<br>5% to 40% ±5% up to 70°C (158°F) (noncondensing)                                     |
| Atmospheric Pressure                          | Sea level to 3 km (1.86 mi)  |
| Air Quality                                   | Noncorrosive   |
| <b>Cooling Requirements</b>                   | No cooling is necessary when used in Bailey Controls cabinets and operated within stated limits.   |
| <b>Certification</b>                          | CSA certified for use as process control equipment in an ordinary (nonhazardous) location.   |

SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

---

## SECTION 2 - INSTALLATION

---

### INTRODUCTION

This section explains how to install the NIAC03 Analog Input Calibration Module. Read, understand, and complete the steps in the order they appear before using the NIAC03 module.

---

### SPECIAL HANDLING

Observe these steps when handling electronic circuitry:

**NOTE:** Always use the Bailey Controls Field Static Kit (part number 1948385A1 - consisting of two wrist straps, ground cord assembly, alligator clip, and static dissipating work surface) when working with modules. The kit is designed to connect the technician and the static dissipating work surface to the same ground point to prevent damage to the modules by electrostatic discharge.

Use the static grounding wrist strap when installing and removing modules. Static discharge may damage MOS devices on modules in the cabinet. Use grounded equipment and static safe practices when working with modules.

1. **Use Static Shielding Bag.** Keep the modules in static shielding bag until you are ready to install them in the system. Save the bag for future use.
2. **Ground Bags Before Opening.** Before opening a bag containing an assembly with CMOS devices, touch it to the equipment housing or ground to equalize charges.
3. **Avoid Touching Circuitry.** Handle assemblies by the edges; avoid touching the circuitry.
4. **Avoid Partial Connection of CMOS Device.** Verify that all devices connected to the modules are properly grounded before using them.
5. **Ground Test Equipment.**
6. **Use an Antistatic Field Service Vacuum.** Remove dust from the module if necessary.
7. **Use a Grounded Wrist Strap.** Connect the wrist strap to the appropriate grounding plug on the power entry panel. The grounding plug on the power entry panel is connected to the cabinet chassis ground.
8. **Do Not Use Lead Pencils to Set Dipswitches.** To avoid contamination of switch contacts that can result in circuit board malfunction, do not use a lead pencil to set a dipswitch.

---

**UNPACKING AND INSPECTION**

These are steps to follow for general handling:

1. Examine the module to make sure that no damage has occurred in transit.
2. Notify the nearest Bailey Controls sales office of any damage.
3. File a claim for any damage with the shipping company that handled the shipment.
4. Use the original packing material or container to store the module.
5. Store the module in a place with clean air; free of extremes of temperature and humidity.

---

**SETUP/PHYSICAL INSTALLATION**

This section explains how to configure and install the NIAC03 module. The required procedures are installing the module into the TMU card rack and connecting the cable.

---

**Jumper Settings**


There are eight jumpers on the NIAC03 module, one for each input. Each jumper selects zero or span for its respective input. The IMAMM03 master module issues the calibration commands to the IMASM03 slave module being calibrated. To calibrate the zero, place the jumper over the lower and middle pins on the input being calibrated. To calibrate the span, place the jumper over the upper and middle pins on the input being calibrated. Zero and span must be calibrated separately for each input. Refer to the IMAMM03 module product instruction for calibration instructions. Figure 2-1 shows the calibration jumper locations on the NIAC03 circuit board.

---


**Cable Installation**

The NKTU02, NKTU12, or NKTU01 cable connects the NIAC03 module to the IMASM03 module. The NKTU02 cable is a round, shielded cable with PVC jacket. The NKTU12 cable is a round, shielded cable with non-PVC jacket.

Figure 2-2 shows the cabling from the NIAC03 module to the IMASM03 module. Table 2-1 lists the NIAC03 module cable connections.



*Figure 2-1. NIAC03 Module Jumper Locations*



*Figure 2-2. Cable Connections for the NIAC03 Module*

Table 2-1. NIAC03 Module Cable Applications

| Nomenclature/<br>Description | Application                | Connector  | Maximum<br>Length |
|------------------------------|----------------------------|--|-------------------|
| NKTU02<br>(PVC Jacket)       | Connects NIAC03 to IMASM03 | P1 on NIAC03 to calibration slot on MMU backplane. | 61 m<br>(200 ft)  |
| NKTU12<br>(non-PVC Jacket)   |                            |  |                   |
| NKTM01<br>(ribbon)           | Connects NIAC03 to IMASM03 | P1 on NIAC03 to calibration slot on MMU backplane. | 30 m<br>(100 ft)  |

To install the cable to an IMASM03 slave module, follow these steps.

**CAUTION**

**Remove modules from their module mounting unit slots before installing or removing a cable assigned to that slot. Failure to do so could result in damage to the module.**

**ATTENTION**

**Retirer le module de son emplacement dans le chassis de montage des modules avant d'installer ou de retirer un cable assigne a cet emplacement. Un manquement a cette procedure pourrait endommager le module.**

1. If round type cables are already installed in the TMU card rack, remove the cable retaining bracket (Bailey Controls part number 258436\_1). Use NKTU02, NKTU12 or NKTM01 cables.
2. Insert the J2 end of the cable into the multibus module mounting unit backplane slot assigned to calibrate slave modules. The cable should latch securely in place. Card edge connector P3 of the slave module to be calibrated will connect to this end of the cable.
- NOTE:** Locate the slave calibration slot as close as possible to the master module.
3. If NKTU02 or NKTU12 cables are used, connect the shield wire extending from the J2 end of the cable to the shield bar.
4. Insert the J1 end of the cable into the TMU backplane slot assigned to the NIAC03 module. The cable should latch securely in place. Card edge connector P1 of the NIAC03 module connects to this end of the cable.
5. Replace or add the cable retaining bracket if round type cables are installed in the TMU card rack.

---

***Module Installation***

The NIAC03 module inserts into a standard INFI 90 system termination mounting unit (TMU) and occupies one slot. To install:

1. Verify slot assignment of the NIAC03 module.
2. Align the NIAC03 module with the guide rails in the TMU card rack and insert the module.

The NIAC03 module is ready for operation if:

1. Jumpers for each channel are set for zero or span.
2. The circuit board is mounted in the termination mounting unit.
3. The required cable is connected to the calibration module.

---

## SECTION 3 - MAINTENANCE

---

### INTRODUCTION

The NIAC03 Analog Input Calibration Module requires limited maintenance. This section contains a maintenance schedule.

---

### MAINTENANCE SCHEDULE

Execute the tasks in Table 3-1 at the specified intervals.

*Table 3-1. Maintenance Schedule*

| Task  | Interval   |
|---|--|
| Clean and tighten all power and grounding connections.  | Every 6 months or during plant shutdown, whichever occurs first. |
| Use a static safe vacuum cleaner to remove dust from:<br>Field Termination Panel<br>Termination Units |  |

---

## SECTION 4 - REPAIR/REPLACEMENT PROCEDURES

---

### INTRODUCTION

This section explains the replacement procedures for the NIAC03 Analog Input Calibration Module. No special tools are required to replace the module.

---

### REPLACEMENT PROCEDURES

If an NIAC03 module is faulty, replace it with a new one. **Do not** try to repair the module. Replacing components may affect performance and certification.

**CAUTION**

**Remove modules from their module mounting unit slots before installing or removing a cable assigned to that slot. Failure to do so could result in damage to the module.**

**ATTENTION**

**Retirer le module de son emplacement dans le chassis de montage des modules avant d'installer ou de retirer un cable assigne a cet emplacement. Un manquement a cette procedure pourrait endommager le module.**

To replace an NIAC03 calibration module:

1. Remove (pull straight off) the calibration module front cover.
2. Slide the calibration module out of the cabinet.
3. Slide the new calibration module into the same slot as the module that was removed.
4. Verify that cabling to the calibration module is correct.
5. Fully insert the calibration module into the TMU card cage.
6. Replace (snap on) the calibration module front cover.

---

## **SECTION 5 - SUPPORT SERVICES**

---

### **INTRODUCTION**

Bailey Controls Company is ready to help in the use, application and repair of its products. Contact the nearest sales office to make requests for sales, applications, installation, repair, overhaul and maintenance contract services.

---

### **REPLACEMENT PARTS AND ORDERING**

When making repairs, order replacement parts from a Bailey Controls sales office. Provide this information:

1. Part description, part number and quantity.
2. Model and serial numbers (if applicable).
3. Bailey instruction manual number, page number and reference figure that identifies the part.

Order parts without commercial descriptions from the nearest Bailey Controls Company sales office.

---

### **TRAINING**

Bailey Controls Company has a modern training facility available for training your personnel. On-site training is also available. Contact a Bailey Controls sales office for specific information and scheduling.

---

### **TECHNICAL DOCUMENTATION**

Additional copies of this manual, or other Bailey Controls Company manuals, can be obtained from the nearest Bailey Controls Company sales office at a reasonable charge.

# APPENDIX A - IMASM03 ANALOG SLAVE INPUT MODULE

## INTRODUCTION

The IMASM03 Analog Slave Module uses an NIAC03 module to calibrate the RTD inputs. This appendix contains a figure and table that show the dipswitch location on the IMASM03 module and its settings. This information is provided as a quick reference guide for personnel installing the NIAC03 module. Figure A-1 shows the IMASM03 module address select switch (SW1). Table A-1 lists the binary addresses for setting SW1. Refer to the IMAMM03 instruction for more detailed information to install and configure the slave.




Figure A-1. Address Select Switch (SW1)

Table A-1. Address Switch Settings (SW1)

| Address Example | Switch Position |     |   | Address Example | Switch Position |     |   |
|-----------------|-----------------|-----|---|-----------------|-----------------|-----|---|
|                 | MSB             | LSB |   |                 | MSB             | LSB |   |
|                 | 1               | 2   | 3 |                 | 1               | 2   | 3 |
| 0               | 0               | 0   | 0 | 4               | 1               | 0   | 0 |
| 1               | 0               | 0   | 1 | 5               | 1               | 0   | 1 |
| 2               | 0               | 1   | 0 | 6               | 1               | 1   | 0 |
| 3               | 0               | 1   | 1 | 7               | 1               | 1   | 1 |

NOTE: open = OFF = 1, closed = ON = 0.

---

# Index

---

|  |     |
|--|-----|
| <b>A</b>                                   |     |
| Address Select Switch (SW1).....           | A-1 |
| Address Switch Settings (SW1).....         | A-1 |
| Application example for NIAC03 module..... | 1-2 |
| <b>F</b>                                   |     |
| Features .....                             | 1-1 |
| <b>G</b>                                   |     |
| Glossary of terms and abbreviations .....  | 1-4 |
| <b>H</b>                                   |     |
| How to use this manual .....               | 1-3 |
| <b>I</b>                                   |     |
| IMASM03 analog slave input module .....    | A-1 |
| Instruction content .....                  | 1-3 |
| Intended user .....                        | 1-1 |
| <b>M</b>                                   |     |
| Maintenance schedule .....                 | 3-1 |
| Module description .....                   | 1-1 |
| <b>N</b>                                   |     |
| NIAC03                                     |     |
| Cable Applications .....                   | 2-4 |
| <b>O</b>                                   |     |
| Cable Connections .....                    | 2-3 |
| Jumper Locations .....                     | 2-3 |
| Nomenclature.....                          | 1-4 |
| <b>R</b>                                   |     |
| Overview .....                             | 1-1 |
| <b>S</b>                                   |     |
| Setup/physical installation.....           | 2-2 |
| Cable installation .....                   | 2-2 |
| Jumper settings .....                      | 2-2 |
| Module installation .....                  | 2-5 |
| Special handling.....                      | 2-1 |
| Specifications.....                        | 1-4 |
| Support services .....                     | 5-1 |
| <b>T</b>                                   |     |
| Technical documentation .....              | 5-1 |
| Training .....                             | 5-1 |
| <b>U</b>                                   |     |
| Unpacking and inspection.....              | 2-2 |

*Visit Elsag Bailey on the World Wide Web at <http://www.bailey.com>*

---

Our worldwide staff of professionals is ready to meet *your* needs for process automation.  
For the location nearest you, please contact the appropriate regional office.

**AMERICAS**

29801 Euclid Avenue  
Wickliffe, Ohio USA 44092  
Telephone 1-216-585-8500  
Telefax 1-216-585-8756

**ASIA/PACIFIC**

152 Beach Road  
Gateway East #20-04  
Singapore 189721  
Telephone 65-391-0800  
Telefax 65-292-9011

**EUROPE, AFRICA, MIDDLE EAST**

Via Puccini 2  
16154 Genoa, Italy  
Telephone 39-10-6582-943  
Telefax 39-10-6582-941

**GERMANY**

Graefstrasse 97  
D-60487 Frankfurt Main  
Germany  
Telephone 49-69-799-0  
Telefax 49-69-799-2406