









E96-105

Instruction

Operator Interface Station (IIOIS20) Hardware Manual



WARNING notices as used in this manual apply to hazards or unsafe practices which could result in personal injury or death

CAUTION notices apply to hazards or unsafe practices which could result in properly damage

NOTES highlight procedures and contain information which assist the operator in understanding the information contained in this manual

WARNING

INSTRUCTION MANUALS

DO NOT INSTALL MAINTAIN OR OPERATE THIS EQUIPMENT WITHOUT READING UNDERSTANDING AND FOLLOWING THE PROPER **Bailey Controls** INSTRUCTIONS AND MANUALS OTHERWISE INJURY OR DAMAGE MAY RESULT

RADIO FREQUENCY INTERFERENCE

MOST ELECTRONIC EQUIPMENT IS INFLUENCED BY RADIO FREQUENCY INTERFERENCE (RF) CAUTION SHOULD BE EXERCISED WITH REGARD TO THE USE OF PORTABLE COMMUNICATIONS EQUIPMENT IN THE AREA AROUND SUCH EQUIPMENT PRUDENT PRACTICE DICTATES THAT SIGNALS SHOULD BE POSTED IN THE VICINITY OF THE EQUIPMENT CAUTIONING AGAINST THE USE OF PORTABLE COMMUNICATIONS EQUIPMENT

POSSIBLE PROCESS UPSETS

MAINTENANCE MUST BE PERFORMED ONLY BY QUALIFIED PERSONNEL AND ONLY AFTER SECURING EQUIPMENT CONTROLLED BY THIS PRODUCT ADJUSTING OR REMOVING THIS PRODUCT WHILE THE SYSTEM MAY UPSET THE PROCESS BEING CONTROLLED SOME PROCESS UPSETS MAY CAUSE INJURY OR DAMAGE

AVERTISSEMENT

MANUELS D'OPERATION

NE PAS METTRE EN PLACE REPARER OU FAIRE FONCTIONNER CE MATERIEL SANS AVOIR LU COMPRENS ET SUIVRE LES INSTRUCTIONS REGLEMENTAIRES DE **Bailey Controls** TOUTE NEGLIGENCE A CET EGARD POURRA ETRE UNE CAUSE D'ACCIDENT OU DE DEFALLANCE DU MATERIEL

PERTURBATIONS DE LA FREQUENCE RADIOPHONIQUE

LA PLUPART DES EQUIPEMENTS ELECTRONIQUES SONT SENSIBLES AUX PERTURBATIONS DE LA FREQUENCE RADIO DES PRECAUTIONS DEVRAIENT ETRE PRISES LORS DE L'INSTALLATION DE MATERIEL DE COMMUNICATION PORTATIF LA PRUDENCE EXIGE QUE LES PRECAUTIONS A PRENDRE DANS CE CAS SOIENT SUGGEREES AUX ENDROITS VOULUS DANS VOTRE USINE

PERTES ROCEDE RENVERSEMENTS

L'ENTRETIEN DOIT ETRE ASSURE PAR UNE PERSONNE QUALIFIEE ET EN CONSIDERATION DE L'ASPECT SECURITAIRE DES EQUIPEMENTS CONTROLES PAR CE PRODUIT L'ADJUSTMENT ET/OU L'EXTRACTION DE CE PRODUIT LORSQU'IL EST INSERE A UN SYSTEME ACTIF PEUT OCCASIONNER DES ACOUPS AU PROCEDURE CONTROLE SUR CERTAINS PROCEDES CES ACOUPS PEUVENT EGLEMENT OCCASIONNER DES DOMMAGES OU BLESSURES

NOTICE

The information contained in this document is subject to change without notice

Bailey Controls Company, its affiliates, employees and agents, and the authors of and contributors to this publication specifically disclaim all warranties, express and implied (including warranties of merchantability and fitness for a particular purpose) for the accuracy, currency, completeness and/or reliability of the information contained herein and/or for the fitness for any particular use and/or for the performance of any material and/or equipment selected in whole or part with the user of or reliance upon information contained herein. Selection of material and/or equipment is at the sole risk of the user of this publication.

This document contains proprietary information of Bailey Controls Company. Except by license and issued in strict confidence, its use or reproduction for use for the reverse engineering, development or manufacture of hardware or software described herein is prohibited. No part of this document may be photocopied or reproduced without the prior written consent of Bailey Controls Company.

Preface

The Operator Interface System (IIOIS20) provides the INFI 90® Strategic Process Management System with integrated operations interface, data acquisition and reporting capabilities. The OIS monitors and controls the process through dynamic, interactive color graphics displays.

This manual explains how to install and maintain the OIS through supportive text, diagrams and drawings. It provides introductory material and specific instructions for installation, maintenance and troubleshooting for the system.

List of Effective Pages

Total number of pages in this manual is 285, consisting of the following

Page No.	Change Date
Preface	15 JUL 93
List of Effective Pages	15 JUL 93
iii through xv	15 JUL 93
1 1 through 1 25	Original
2 1 through 2 4	Original
3 1 through 3 34	Original
3 35 through 3 59	15 JUL 93
4 1 through 4 7	Original
4 8	15 JUL 93
4 9 through 4 14	Original
4 15 through 4 16	15 JUL 93
4 17 through 4 24	Original
4 25 through 4 26	15 JUL 93
4 27 through 4 61	Original
5 1 through 5 3	Original
5 4 through 5 5	15 JUL 93
5 6	Original
5 6A through 5 6B	15 JUL 93
5 7 through 5 12	Original
5 13 through 5 14B	15 JUL 93
5 15 through 5 18	Original
5 19	15 JUL 93
5 20 through 5 53	Original
6 1 through 6 8	Original
6 9 through 6 10	15 JUL 93
6 11 through 6 23	Original
7 1 through 7 2	Original
8 1 through 8 2	Original
8 3	15 JUL 93
8 4 through 8 27	Original
9 1	Original
9 2	15 JUL 93
A-1 through A 6	Original
Index 1 through Index 5	Original

NOTE On an updated page, the changed text or table is indicated by a vertical bar in the outer margin of the page at the changed area. A changed figure is indicated by a vertical bar in the outer margin next to the figure caption. The date the update was prepared will appear beside the page number.

Table of Contents

	<i>Page</i>
SECTION 1 - INTRODUCTION	1-1
OVERVIEW	1 1
INTENDED USER	1 1
APPLICATIONS	1 1
IIOIS20 HARDWARE OVERVIEW	1 2
OIS Console Hardware	1 3
OIS Console Component Locations	1-4
OIS Driver Cabinet Hardware	1 5
OIS Driver Cabinet Components Location	1 6
IIOIC20 OPERATOR INTERFACE CONSOLE	1 7
IIOIC20 HARDWARE OVERVIEW	1 7
OIC Tabletop (19 Inch) Hardware	1 9
OIC Console Hardware	1 9
OIC Console Component Locations	1-10
OIC Environmental Cabinet Hardware	1-10
OIC Environmental Cabinet Component Locations	1-11
OIC Panel Mounted Hardware	1-11
OIC Panel Mounted Component Locations	1-12
OIC Tabletop (33 Inch) Hardware	1 12
STANDARD AND OPTIONAL HARDWARE	1 14
INSTRUCTION CONTENT	1 15
REFERENCE DOCUMENTS	1 16
RELATED EQUIPMENT	1-16
INSTALLATION SUMMARY	1 16
GLOSSARY OF TERMS AND ABBREVIATIONS	1 18
NOMENCLATURE	1 20
SPECIFICATIONS FOR OPERATOR INTERFACE CONSOLE (IIOIS20)	1-22
SPECIFICATIONS FOR OPERATOR INTERFACE CONSOLE (IIOIC20)	1 24
SECTION 2 - DESCRIPTION AND OPERATION	2-1
INTRODUCTION	2-1
OIS FUNCTIONAL OPERATION	2-1
OIC FUNCTIONAL OPERATION	2 3
LOGIC POWER	2-4
MULTIBUS	2 4
SECTION 3 - INSTALLATION	3-1
INTRODUCTION	3 1
SPECIAL HANDLING	3 1
HARDWARE SETUP ELECTROSTATIC DISCHARGE (ESD) CONTROL	3 1
UNPACKING AND INSPECTION	3-2
PLANNING AN INSTALLATION	3 2
SAFETY CONSIDERATIONS	3-3
IIOIS202 PHYSICAL DESCRIPTION	3-3
IIOIS202 SETUP AND PHYSICAL INSTALLATION	3-3
IIOIS20A/D PHYSICAL DESCRIPTION	3-6
IIOIS20A/D SETUP AND PHYSICAL INSTALLATION	3-6
IIOIS20 WIRING CONNECTIONS AND CABLING	3-7
Communication Loop Connections	3 11
Peripheral Device Connections	3 13

Table of Contents (continued)

	<i>Page</i>
SECTION 3 - INSTALLATION (<i>continued</i>)	
AC Power	3 13
Setup for 24C VAC	3 13
AC Outlets	3 14
AC Wiring	3 14
IIOIC201 PHYSICAL DESCRIPTION	3 16
IIOIC201 SETUP AND PHYSICAL INSTALLATION	3 16
IIOIC201 WIRING CONNECTIONS AND CABLING	3 17
IIOIC202 PHYSICAL DESCRIPTION	3 17
IIOIC202 SETUP AND PHYSICAL INSTALLATION	3 17
IIOIC203 PHYSICAL DESCRIPTION	3 20
IIOIC203 SETUP AND PHYSICAL INSTALLATION	3 20
IIOIC204 PHYSICAL DESCRIPTION	3 21
IIOIC204 SETUP AND PHYSICAL INSTALLATION	3 21
IIOIC201 WIRING CONNECTIONS AND CABLING	3 22
IIOIC202 WIRING CONNECTIONS AND CABLING	3 22
AC POWER	3 25
Setup for 240 VAC	3 25
AC Outlets	3 25
AC Wiring	3 26
IIOIC203 WIRING CONNECTIONS AND CABLING	3 28
IIOIC201/4 WIRING CONNECTIONS AND CABLING	3 30
AC POWER	3 34
PREOPERATING ADJUSTMENTS	3 35
SOFTWARE UPGRADE	3 36
SOFTWARE RELEASE E 2	3 36
Full Load OIS B 1 to OIS E 2	3 37
Partial Load OIS B 1 to OIS E 2	3 38
SOFTWARE RELEASE E 2 MAINTENANCE	3 39
New Load Procedure	3 40
Full Load Procedure	3 40
Reload Procedure	3 41
RESTORING B 1 CONFIGURATIONS AND FILES	3 42
Restore OIS B 1 Configurations	3 42
Restore OIS B 1 Files	3 42
SAVING AND RESTORING AN E 2 TAG DATABASE	3 43
Saving a Tag Database	3 44
Restoring a Tag Database	3 45
SAVING SITE SPECIFIC CONFIGURATIONS	3 45
Saving Software Release E 2 User Displays	3 45
Saving Trend Data Files	3 46
Saving Log Report Definition and Retention Files	3 47
Saving Sequence of Events Log Configuration Files	3 49
Saving Trend Pen Files	3 50
RESTORING SITE SPECIFIC CONFIGURATIONS	3 50
Restoring User Display Files	3 50
Restoring Trend Data Files	3 51
Restoring Logging Files	3 51
Restoring Sequence of Events Log Files	3 51
Restoring Trend Pen Files	3 51
USING THE UTILITY	3 52
Monitor 68K Terminal	3 52
DDT Terminal	3 52

Table of Contents (continued)

	<i>Page</i>
SECTION 3 - INSTALLATION (continued)	
Starting Off Line Utility	3 52
Logging Into Off-Line Utility	3 53
MANDATORY CONVERSIONS	3-54
Explanation of Conversions	3 54
Log Configuration Files	3 56
Configurable Text File Conversion	3 56
SVCFG CN AND LDCFG CN	3 57
ALMDESC CF FILE	3 58
RESTORING THE ALMDESC CF FILE	3 58
ASCII DATABASE	3 59
<hr/>	
SECTION 4 - STANDARD HARDWARE	4-1
INTRODUCTION	4 1
STANDARD HARDWARE	4 1
MULTI BUS HARDWARE	4-2
Multibus Card Cage	4-3
Multibus Module Installation	4 6
Multibus Module Removal	4-7
Multibus Graphics Controller Module	4 8
Multibus Keyboard Module	4 9
Multibus Reset Module	4 11
Multibus Serial Interface Module	4-12
SASI Disk Bus Interface Adapter	4-14
Multibus Processor Module	4-15
Multibus Loop Module	4-16
Multibus Communication Processor Module	4-18
Multibus Communication Loop Module	4-21
SYSTEM HARDWARE	4-22
Keyboard Interface Panel	4-22
Operator Keyboard	4-24
Color Monitor	4-25
Disk Drive Controller Board	4-27
Annunciator Display Panel (ADP)	4 28
Floppy Disk Drive TEAC	4-31
Floppy Disk Drive - NEC	4-32
Hard Disk Drive PRIAM V185A 85 Megabyte	4 33
Hard Disk Drive CONTROL DATA 85 Megabyte	4 34
Hard Disk Drive SEAGATE 85 Megabyte	4 35
Hard Disk Drive MAXTOR 85 Megabyte	4 36
IIOIS20 and IIOIC202 Power Entry Panel	4 37
IIOIS20A/D Power Entry Panel	4-41
IIOIC202 Connector Panel for the Slide In Power Supply	4 45
IIOIS20 and IIOIS20A/D Main Power Supply	4 49
IIOIC202 Main Power Supply	4 54
IIOIC202 Slide In Power Supply	4 58
AC POWER	4-61
<hr/>	
SECTION 5 - OPTIONAL HARDWARE	5-1
INTRODUCTION	5 1
OPTIONAL HARDWARE	5 2
Tabletop Annunciator Display Panel (ADP)	5-2

Table of Contents (continued)

	<i>Page</i>
SECTION 5 - OPTIONAL HARDWARE (continued)	
Second Color Graphics Module	5 4
Color Monitor	5 5
Engineering Keyboard	5 7
Printer	5 8
Setup	5 8
GENICOM 3410 XLS	5 9
GENICOM 3410 XCQ	5 10
Color Video Copier System	5 11
Operation Summary	5 11
Installation	5 11
Operation	5 14
Gammadata Color Video Copier System	5 14A
Operation Summary	5 14A
Installation	5 15
Operation	5 16
Streaming Tape Drive	5 19
Backup and Restore Operation	5 19
Nine Track Reel to Reel Tape Transport	5 21
Reel to Reel Tape Unpacking	5 22
Reel to Reel Tape Preparation	5 22
SCSI Interface Unit, CSC 100	5 24
Reel to Reel Tape Setup	5 24
Reel to Reel Tape System Connections	5 24
Optical Disk Storage	5 27
IIDOP01 Unpacking	5 27
IIDOP01 Features	5 28
IIDOP01 Installation	5 31
IIDOP01 Configuration	5 32
IIDOP01 Power Settings	5 34
IIDOP01 Wiring and Cabling	5 35
IIDOP01 Operation	5 35
IIDOP01 Troubleshooting	5 38
IIDOP01 Maintenance	5 38
Optical Disk Storage	5 39
IIDOP02 Unpacking	5 39
IIDOP02 Features	5 40
IIDOP02 Disk Drive Setup	5 43
IIDOP02 Wiring and Cabling	5 44
IIDOP02 Operation	5-44
IIDOP02 Troubleshooting	5 47
IIDOP02 Maintenance	5 47
Touch Screen	5 48
Touch Screen Controller Card Installation	5 48
Touch Screen Installation	5 49
Touch Screen Calibration	5 51
Trackball	5 52
Mouse	5 53

Table of Contents (continued)

	<i>Page</i>
SECTION 6 - TROUBLESHOOTING	6-1
INTRODUCTION	6 1
TROUBLESHOOTING	6 1
DIAGNOSTIC POWER UP TESTS	6-3
AC Power Test	6 3
DC Power Test	6-4
MULTIBUS CARD CAGE AND SUBASSEMBLY TESTS	6 5
Initial Setup	6 7
Test Multibus Processor Module (IIMPM0)	6 7
Test Multibus Graphics Controller Module (IIMGC01)	6 8
Test Multibus Graphics Controller Module One (IIMGC01)	6 8
Test Optional Multibus Graphics Controller Module Two (IIMGC01)	6 9
Test Multibus Serial Interface Module (IIMSM01)	6 10
Test Disk System Functions	6 10
EPROM DIAGNOSTICS	6 12
Command Syntax	6 13
Command Mode	6 13
Optical Disk Unit Troubleshooting	6 23
SECTION 7 - MAINTENANCE	7-1
INTRODUCTION	7 1
PREVENTIVE MAINTENANCE	7 1
Optical Disk Unit Maintenance	7 1
Filter Maintenance	7 2
Additional Maintenance	7 2
SECTION 8 - REPLACEMENT PROCEDURES	8-1
INTRODUCTION	8-1
MODULE REPLACEMENT	8-1
PART REPLACEMENT	8-3
Color Monitor for IIOIS20/IIOIC202	8-3
Color Monitor for IIOIC203	8-5
Disk Drive Controller Card for IIOIS20	8-6
Disk Drive Controller Card for IIOIS20A	8-7
Hard Disk Drive for IIOIS20	8-8
Hard Disk Drive for IIOIS20A	8-9
Fan Assembly for IIOIS20/IIOIC202	8 10
Fan Assembly for IIOIS20A	8-12
Floppy Disk Drive for IIOIS20	8-14
Floppy Disk Drive for IIOIS20A	8-16
Multibus Card Cage for IIOIS20/IIOIC202	8 17
Multibus Card Cage for IIOIS20A	8-18
Power Entry Panel for IIOIS20/IIOIC202	8 19
Power Entry Panel for IIOIS20A	8 20
Power Entry Panel for IIOIC203	8 22
Main Power Supply for IIOIS20/IIOIC202	8 24
Slide In Power Supply for IIOIC202	8-25
Main Power Supply for IIOIS20A	8 26
Main Power Supply for IIOIC203	8 27

Table of Contents (continued)

	<i>Page</i>
SECTION 9 - SUPPORT SERVICES	9-1
INTRODUCTION	9 1
REPLACEMENT PARTS AND ORDERING INSTRUCTIONS	9 1
TRAINING	9 1
TECHNICAL DOCUMENTATION	9 1
SPARE PARTS	9 1
APPENDIX A - QUICK REFERENCE INFORMATION	A-1
INTRODUCTION	A 1
IIOIS20/IIOIC20 WIRING CONNECTIONS AND CABLING	A 1

List of Figures

<i>No</i>	<i>Title</i>	<i>Page</i>
1 1	OIS and OIC Communication Levels	1 2
1 2	IIOIS201 Console Front and Rear Views	1-4
1 3	IIOIS20A/D Driver Cabinet Front View	1 5
1 4	IIOIC20 Models 19 Inch Table Top, 33 Inch Table Top, Panel Mounted, Environmental Cabinet and Console (CW)	1 8
1 5	IIOIC201 Table Top (19 Inch) Front and Rear Views	1 9
1 6	IIOIC2021 Console Front and Rear Views	1 10
1 7	IIOIC203 Environmental Cabinet Front and Rear Views	1 11
1 8	IIOIC204 Panel Mounted Model Front and Rear Views	1 12
1 9	IIOIC205 Tabletop (33 Inch) Front and Rear Views	1 13
2 1	IIOIS20 Block Diagram	2 2
2 2	IIOIC201/2/3/4/5 Block Diagram	2 3
3 1	IIOIS20 Cabinet Dimensions	3 4
3 2	IIOIS20 Anchoring Dimensions	3 5
3 3	OIS/OIC Keyboard Table	3 5
3 4	OIS/OIC 15 Degree Wedge Table Dimensions	3 6
3 5	OIS/OIC 45 Degree Wedge Table Dimensions	3 7
3 6	IIOIS20A/D Cabinet Dimensions	3 8
3 7	IIOIS20A/D Anchoring Dimensions	3 9
3 8	IIOIS20 Cable Connections	3 12
3-9	IIOIS20 and IIOIS20A/D Power Entry Panel (PEP) AC Input Terminal	3 15
3 10	IIOIC201 Case Dimensions	3 17
3 11	IIOIC2021/2/3 Cabinet Dimensions	3 18
3 12	IIOIC2021/2/3 Anchoring Dimensions	3 19
3 13	IIOIC201/2/3 Keyboard Table	3 19
3 14	IIOIC203 Cabinet Dimensions	3 20
3 15	IIOIC203 Anchoring Dimensions	3 21
3 16	IIOIC204 Mounting Dimensions	3 22
3 17	IIOIC202 Cable Connections	3 24
3 18	IIOIC202 Power Entry Panel PEP) AC Input Terminal	3 27
3 19	IIOIC203 Cable Connections	3 29
3 20	IIOIC203 Power Entry Panel PEP)	3 30
3 21	IIOIC201 Cable Connections	3 32
3 22	IIOIC204 Cable Connections	3 33

List of Figures (continued)

No.	Title	Page
3 23	IIOIC201/4 Chassis Connections	3-34
3 24	IIOIS20, IIOIS20A/D and IIOIC202 Power Entry Panel AC Wiring	3-35
4 1	IIOIS20 Multibus Card Cage (Front View)	4 4
4 2	IIOIC202 Multibus Card Cage (Front View)	4 4
4 3	IIOIC202 Multibus Card Cage with Slide In Power Supply	4 5
4-4.	Multibus Card Cage (Back View)	4 5
4-5	Removing Multibus Modules	4 7
4-6	Multibus Graphics Controller Module	4 8
4-7	Connections for Multibus Keyboard Module	4-9
4 8	Connections for Multibus Reset Module	4 11
4-9	Multibus Serial Interface Module	4 13
4 10	SASi Disk Bus Interface Adapter	4 14
4 11	Multibus Processor Module	4 15
4 12	Multibus Loop Module	4 16
4 13	Multibus Communication Processor Module	4 18
4 14	Multibus Communication Loop Module	4 21
4 15	Keyboard Interface Panel	4 22
4 16	Operator Keyboard	4-24
4 17	Color Monitor	4-26
4 18	Disk Drive Controller Module	4 27
4 19	Annunciator Display Panel	4-29
4 20	Annunciator Panel Circuit Board	4 30
4 21	TEAC Floppy Disk Drive	4 31
4 22	NEC Floppy Disk Drives	4 32
4 23	PRIAM V185A Hard Disk Drive	4 33
4 24	CONTROL DATA Hard Disk Drive	4-34
4 25	SEAGATE ST4096 Hard Disk Drive	4 35
4 26	MAXTOR XT1085 Hard Disk Drive	4 36
4 27	IIOIS20 and IIOIC202 Power Entry Panel	4 39
4 28	IIOIS20 and IIOIC202 Connections for Power Entry Panel	4-40
4-29	IIOIS20A/D Power Entry Panel	4 43
4 30	IIOIS20A/D Connections for Power Entry Panel	4-44
4 31	IIOIC202 Connector Panel for Slide In Power Supply	4-47
4-32	IIOIC202 Connections for Slide In Power Supply Connector Panel	4 48
4-33	IIOIS20 and IIOIS20A/D Main Power Supply	4 49
4 34	IIOIS20 and IIOIS20A/D Connections from Main Power Supply	4-50
4 35	IIOIS20 and IIOIS20A/D Power Connections to DC Distribution Board	4 51
4 36	IIOIS20 and IIOIS20A/D Power Connections to Backplane	4 52
4 37	IIOIC202 Main Power Supply	4 54
4 38	IIOIC202 Connections from Main Power Supply	4 55
4 39	IIOIC202 Power Connections to DC Distribution Board	4-56
4 40	IIOIC202 Power Connections to Backplane	4 57
4 41	IIOIC202 Slide In Power Supply	4 58
4-42	IIOIC202 Connections Inside the Slide In Power Supply	4 59
4 43	IIOIS20, IIOIS20A/D and IIOIC202/3 PEP AC Connections	4 61
5 1	Tabletop Annunciator Display Panel	5-2
5 2	Configuring the Second Multibus Graphics Controller Module	5 4
5 2a	Optional Color Monitor	5 6A
5 3	Engineering Keyboard Connector	5-7
5 4	Back View of the Color Video Processor	5-12
5 5	Gammadata Color Copier	5 17
5 6	Video Copier Menu Structure	5 18
5 7	Streaming Tape IIDST01 Cable Connections	5 20

List of Figures (continued)

<i>No</i>	<i>Title</i>	<i>Page</i>
5 8	Streaming Tape Drive Jumper Settings	5 20
5 9	Reel to Reel Tape Drive Unit	5 22
5 10	Reel to Reel Tape Transport Mechanism	5 23
5 11	Reel to Reel Tape LED and Switch Location	5 25
5 12	Loading Reel to-Reel Tape	5 26
5 13	IIDOP01 Optical Disk Unit Front View	5 29
5 14	IIDOP01 Optical Disk Unit Back View	5 30
5 15	Mounting Bracket Assembly	5 31
5 16	IIOIS20A/D Cabinet Mounting	5 32
5 17	IIDOP01 Optical Disk Unit Installed	5 33
5 18	IIDOP02 Optical Disk Unit Front View	5 41
5 19	IIDOP02 Optical Disk Unit Back View	5 42
5 20	Touch Screen Controller Card Connections	5 49
5 21	Touch Screen Controller Card Dipswitch Settings	5 50
5 22	Trackball/Mouse Connections	5 52
6 1	Main Circuit Breaker (CB1)	6 3
6 2	IIOIS20, IIOIS20A and IIOIC202 Main Power Supply	6 6
8 1	Multibus Module Removal	8 1
8 2	Color Monitor Removal for IIOIS20/IIOIC202	8 3
8 3	Color Monitor Removal for IIOIC203	8 5
8 4	Disk Drive Controller Card Removal for IIOIS20	8 6
8 5	Disk Drive Controller Card Removal for IIOIC20A	8 7
8 6	Hard Disk Drive Removal for IIOIS20	8 8
8 7	Hard Disk Drive Removal for IIOIS20A	8 9
8 8	Fan Assembly Removal for IIOIS20/IIOIC202	8 10
8 9	Fan Assembly Removal for IIOIS20A	8 12
8 10	Floppy Disk Drive Removal for IIOIS20	8 14
8 11	Floppy Disk Drive Removal for IIOIS20A	8 16
8 12	Multibus Card Cage Removal for IIOIS20/IIOIC202	8 17
8 13	Multibus Card Cage Removal for IIOIS20A	8 18
8 14	Power Entry Panel (PEP) Removal for IIOIS20/IIOIC202	8 19
8 15	Power Entry Panel (PEP) Removal for IIOIS20A	8 20
8 16	Power Entry Panel (PEP) Removal for IIOIC203	8 22
8 17	Main Power Supply Removal for IIOIS20/IIOIC202	8 24
8 18	Slide In Power Supply Removal for IIOIC202	8 25
8 19	Main Power Supply Removal for IIOIS20A	8 26
8 20	Main Power Supply Removal for IIOIC203	8 27
A 1	IIOIS20 Cable Connections	A 4
A 2	IIOIC202 Cable Connections	A 5
A 3	IIOIC203 Cable Connections	A 6

List of Tables

<i>No</i>	<i>Title</i>	<i>Page</i>
1 1	OIS Models	1 3
1 2	Multibus Card Cage Modules	1 6
1 3	OIC Models	1 7
1 4	Standard OIS/OIC Hardware	1 14

List of Tables (continued)

No.	Title	Page
1 5	Optional OIS/OIC Hardware	1 15
1 6	IIOIS20 and IIOIC20 Power Consumption	1 17
1 7	IIOIS20 and IIOIC20 Dimensions	1 17
3 1	OIS Wiring Color Codes	3-9
3 2	IIOIS20 Cable Connections	3 10
3 3	OIC Wiring Color Codes	3 22
3 4	IIOIC202 Cable Connections	3 23
3-5	IIOIC203 Cable Connections	3 28
3 6	IIOIC201/4 Cable Connections	3 30
3 7	Firmware Requirements for Software Release E 2	3 37
3 8	B.1 Full Load Configuration Files	3 38
3 9	B 1 Partial Load Configuration Files	3 39
3 10	New Load Command Files	3 40
3 11	Full Load Configuration Files	3 41
3 12	B 1 to E 2 Configuration Files	3 43
3 13	Saving E 2 Tag Database and System Configuration Files	3 44
3-14	Restoring E 2 Tag and System Command Files	3 45
3 15	SVCFG CN Files	3 57
4 1	Standard OIS/OIC Hardware	4 1
4 2	Multibus Modules	4 3
4 3	Multibus Wiring Connections	4-6
4 4	Multibus Serial Interface Port Assignments	4 12
4 5	Loop Module Configuration	4 17
4 6	Multibus Communication Processor Configuration	4 19
4-7	Connections to Keyboard Interface Panel	4 23
4 8.	Connections to Disk Drive Controller Module	4 27
4 9	Connections to Annunciator Display Board	4 28
4 10	IIOIS20 and IIOIC202 PEP Connector Assignments	4 37
4 11	IIOIS20A/D PEP Connector Assignments	4 41
4-12	IIOIC202 PEP Connector Assignments	4-45
4-13	IIOIS20 and IIOIS20A/D Power Supply Connections	4 53
4 14	IIOIC202 Power Supply Connections	4 57
4 15	IIOIC202 Power Supply Connections	4 59
5 1	Optional OIS/OIC Hardware	5 1
5 2	Connections to Annunciator Display Board	5 3
5 3	19 Inch Color Monitor Options	5 5
5 4	OIS20/OIC20 Printers	5 8
5 5	Video Copier Related Products	5-11
5 6	Video Copier Related Products	5 14A
5 6A	Hard Disk Drive Compatibility	5-19
5 7	Reel to Reel Tape (IIDMT01/02) Basic Parts List	5 21
5 8	Reel to-Reel Tape (IIDMT01) Parts List	5 21
5 9	Reel to Reel Tape (IIDMT02) Parts List	5 21
5 10	IIDOP01 Parts List	5 27
5 11	Optical Disk Storage IIDOP01 Carton Contents	5 28
5 12	IIDOP01 Installation Hardware	5 31
5 13	SCSI ID Selection Jumpers	5 32
5 14	Optical Disk Unit IIDOP01 Wiring Hardware	5 35
5-15	Optical Disk Storage IIDOP02 Parts List	5 39
5-16	Optical Disk Storage IIDOP02 Carton Contents	5 40
5-17	Optical Disk Unit IIDOP02 Wiring Hardware	5 44
5-18	Touch Screen Parts	5 48
6-1	Troubleshooting Guide	6 1

List of Tables (continued)

<i>No</i>	<i>Title</i>	<i>Page</i>
6 2	Multibus Graphics Controller Module Self Test Status	6 9
6 3	Disk Read Test Error Codes	6 11
6 4	Control Commands for Advanced Diagnostics	6 12
6 5	Command Syntax Description	6 14
6 6	File System Error Codes	6 17
6 7	Disk Controller Error Codes	6 18
6 8	UNIX I/O Error Codes	6 19
6 9	Tape File Error Codes	6 20
6 10	NIU Error Codes	6 20
6 11	IIMCP01 Failure LED Codes	6 22
6 12	IIMLM01 Failure LED Codes	6 22
6 13	Optical Disk Unit IIDOP02 Troubleshooting Table	6 23
7 1	OIS/OIC Preventive Maintenance	7 1
9 1	Recommended Spare Parts List	9 2
A 1	IIOIS20/IIOIC20 Wiring Color Codes	A 1
A 2	IIOIS20 Cable Connections	A 2

Safety Summary

SPECIFIC WARNINGS

Do not operate the OIC with doors or covers opened or removed. Touching connections that carry current and voltage may cause injury. (p 13, 111)

The CRT will slide out the rear of the OS20 and OIC20 cabinet by itself when the mounting bolts are removed. Removing the rear two bolts without supporting the CRT could cause personal injury. (p 5-5, 5-48, 84)

SPECIFIC CAUTIONS

Make sure that all labels on the power supply and the power entry panel are changed to show 240 VAC operation or equipment damage may result.

Make sure main power breaker is off before changing operating voltage setting or equipment damage may result. (p 313)

Do not plug modules or peripherals such as a tape drive or printer into the OIS with power applied. A current surge or voltage spike could damage sensitive components on the unit. (p 314, 326)

List of Tables (continued)

No	Title	Page
6 7	Disk Controller Error Codes	6-18
6 8	UNIX I/O Error Codes	6 19
6 9	Tape File Error Codes	6 20
6 10	NIU Error Codes	6 20
6 11	IIMCP01 Failure LED Codes	6 22
6 12	IIMLM01 Failure LED Codes	6 22
6 13	Optical Disk Unit IIDOP02 Troubleshooting Table	6 23
7 1	OIS/OIC Preventive Maintenance	7 1
9-1	Recommended Spare Parts List	9 2
A 1	IIOIS20/IIOIC20 Wiring Color Codes	A 1
A 2	IIOIS20 Cable Connections	A 2

Safety Summary

SPECIFIC WARNINGS

Do not operate the OIC with doors or covers opened or removed. Touching connections that carry current and voltage may cause injury. (p 1 3, 1-11)

The CRT will slide out the rear of the IIOIS20 and IIOIC20 cabinet by itself when the mounting bolts are removed. Removing the rear two bolts without supporting the CRT could cause personal injury (p 5-5 5-48 8-4)

SPECIFIC CAUTIONS

Make sure that all labels on the power supply and the power entry panel are changed to show 240 VAC operation or equipment damage may result.

Make sure main power breaker is off before changing operating voltage setting or equipment damage may result (p 3-13)

Do not plug modules or peripherals such as a tape drive or printer into the OIS with power applied. A current surge or voltage spike could damage sensitive components on the unit (p 3 14, 3 26)

Make sure main power breaker is off before changing operating voltage setting or equipment damage may result.

Make sure that all labels on the power supply and the power entry panel are changed to show 240 VAC operation or equipment damage may result (p 3-25)

Safety Summary

SPECIFIC CAUTIONS

(continued)

Failure to turn off the main power circuit breaker before removing or inserting modules into the card cage may result in equipment failure (p. 4-6, 4-7, 4-38, 4-44, 4-45, 8-1)

Failure to plug in the streaming tape drive ribbon cable before turning the tape drive power on may result in equipment failure. Read the notice on the front of the power entry panel before turning on the power to the tape drive. Set the streaming tape drive to the same voltage as the PEP outlet or equipment damage may result (p. 4-38, 4-42)

Verify that the O C202 is set up to receive 240 VAC if the supply circuit to the power entry panels is 240 VAC or equipment damage may result.

Incorrectly setting the input power select may damage the disk drive unit (p. 5-34, 5-43)

Sommaire de Sécurité

AVERTISSEMENT D'ORDRE SPECIFIQUE

Ne faites pas fonctionner l'OIC si les portes ou les couvercles sont ouverts ou retirés. Tout contact avec les connexions ou circulation du courant ou de haute tension risque de provoquer des blessures (p. 1-3, 1-11)

Lorsque les boucles d'ancrage sont retirées, l'écran cathodique risque de sortir à l'arrière de l'armoire I/O S20 et I/OIC20. Si les deux boucles d'ancrage arrière sont retirées, il faut retenir l'écran afin d'éviter toute blessure (p. 5-5, 5-48, 8-4)

Safety Summary (continued)

SPECIFIC CAUTIONS
(continued)

Make sure main power breaker is off before changing operating voltage setting or equipment damage may result

Make sure that all labels on the power supply and the power entry panels are changed to show 240 VAC operation or equipment damage may result. (p 3-25)

Failure to turn off the main power circuit breaker before removing or inserting modules into the card cage may result in equipment failure (p 4-6, 4-7, 4-38, 4-44, 4-45, 8-1)

Failure to plug in the streaming tape drive ribbon cable before turning the tape drive power on may result in equipment failure. Read the notice on the front of the power entry panel before turning on the power to the tape drive. Set the streaming tape drive to the same voltage as the PEP outlet or equipment damage may result (p 4-38, 4-42)

Verify that the I/OIC202 is set up to receive 240 VAC if the supply circuit to the power entry panel is 240 VAC or equipment damage may result

Incorrectly setting the input power select may damage the disk drive unit (p 5-34, 5-43)

Sommaire de Securite

AVERTISSEMENT D'ORDRE SPECIFIQUE

Ne faites pas fonctionner l'OIC si les portes ou les couvercles sont ouverts ou retirés. Tout contact avec les connexions ou circuits du courant ou de la tension risque de provoquer des blessures (p 1-3, 1-11)

Lorsque les boulons d'ancrage sont retirés, l'écran cathodique risque de sortir à l'arrière de l'armoire I/OIS20 et I/OIC20. Si les deux boulons d'ancrage arrière sont retirés, il faut retenir l'écran afin d'éviter toute blessure (p 5-5, 5-48, 8-4)

Sommaire de Securite (continued)

ATTENTION D'ORDRE SPECIFIQUE

Assurez-vous que toutes les étiquettes apposées sur le bloc d'alimentation et sur le panneau d'entrée de l'alimentation ont été modifiées pour correspondre au fonctionnement à 240 V c.a. si non le matériel pourra subir des dommages

Assurez-vous que le disjoncteur de l'alimentation principale est hors tension avant de modifier le réglage de la tension de service, sinon le matériel pourrait subir des dommages (p 3-13)

Ne pas insérer les cartes ni les périphériques tels que les rouleaux de bande et les imprimantes dans l'OIS lorsque ce dernier est sous tension. Les composants de l'unité risquent d'être endommagés par les pointes de courant ou de tension (p 3 14, 3-26)

Assurez-vous que le disjoncteur de l'alimentation principale est hors tension avant de modifier le réglage de la tension de service, sinon le matériel pourrait subir des dommages

Assurez-vous que toutes les étiquettes apposées sur le bloc d'alimentation et sur le panneau d'entrée de l'alimentation ont été modifiées pour correspondre au fonctionnement à 240 V c.a., si non le matériel pourra subir des dommages (p 3-25)

Ne pas insérer les cartes ni les périphériques tels que les rouleaux de bande et les imprimantes dans l'OIS lorsque ce dernier est sous tension. Les composants de l'unité risquent d'être endommagés par les pointes de courant ou de tension (p 3 37)

Si l'on omet d'éteindre l'interrupteur du circuit d'alimentation principal avant de retirer les cartes ou de les insérer dans le porte-cartes, l'équipement pourrait faire défaut (p 4-6, 4-7, 4-38 4-44, 4-45, 8 1)

Si l'on néglige de brancher le câble-ruban du dérouleur de bande en contact avant d'acheminer l'alimentation au rouleau de bande, le matériel pourra subir des dommages

Lisez l'avis figurant à l'avant du panneau d'entrée d'alimentation avant d'acheminer l'alimentation au rouleau de bande. Réglez le dérouleur en contact au même niveau de tension que la sortie du panneau d'entrée d'alimentation si non le matériel pourrait subir des dommages (p 4-38, 4 42)

Vérifiez si le IIOIC202 est réglé de façon à recevoir 240 V c.a. et si le circuit d'alimentation au panneau d'entrée est de 240 V c.a. si non le matériel pourra subir des dommages (p 4-46)

Un mauvais réglage de la sélection de l'alimentation d'entrée pourra endommager l'unité de disque (p 5-34, 5-43)

SECTION 1 - INTRODUCTION

OVERVIEW

This document contains directions and cautions for installing and servicing the Operator Interface Station (IIOIS20) and the Operator Interface Console (IIOIC20).

The OIS contains a set of console electronics supporting up to two CRTs. The OIC is a remote CRT and keyboard interface that connects to an IIOIS20. This section contains an overview of the IIOIS20 and IIOIC20.

Read all of this manual to get the greatest benefit of the information it contains. Read each procedure before doing the task. Call the local Bailey Controls sales office for answers to any questions.

INTENDED USER

This manual is a reference for experienced installers with installation and maintenance experience on process monitoring equipment. It is not a tutorial.

APPLICATIONS

The IIOIS20 Operator Interface Station (IIOIS20) is an integrated operator console providing a window into the process. The IIOIS20 provides the INFI 90 Strategic Process Management System and Network 90 Distributed Control System with an integrated operations interface that has data acquisition and reporting capabilities.

The Operator Interface Console (IIOIC20) is the remote operator interface for an IIOIS20. It uses the OIS to process trend information and control the process.

Features of the IIOIS20 (OIS) and IIOIC20 (OIC) include:

- Process monitoring and process control via flexible, dynamic, interactive color graphics for up to 5000 pieces of information (tags).
- Advanced alarm management capabilities to optimize operator response.
- A trending package that offers a historical perspective of process conditions for analysis of current operations.
- A logging function that provides a paper history of process operations and customized operations summaries.

INTRODUCTION

- An archiving function that provides a history of process operations for subsequent analysis and process improvement studies
- On line troubleshooting and diagnostics for the INFI 90/ Network 90 systems through system status displays.
- Configuration and tuning capabilities for the INFI 90/Net work 90 modules over the communication highway

Figure 1 1 shows the communication levels of the OIS and OIC.




Figure 1 1 OIS and OIC Communication Levels

IIOIS20 HARDWARE OVERVIEW

The IIOIS20 interfaces to INFI NET[®] and Plant Loop communication highways. The OIS can monitor and control a process through color graphics displays which show equipment status and process state.

© INFI NET is a registered trademark of the Bailey Controls Co.

Refer to Table 1-1 for the five models of the IIOIS20

Table 1 1. OIS Models

Nomenclature	Description
I OIS201	Console with cwer CRT
IIOIS202	Console with upper CRT
IIOIS203	Console with upper and ower CRT
.IIOIS20A	Driver cabinet
I OIS20D	Driver cabinet (dual electronics)

The console model may have a lower CRT, an upper CRT or both with the required power supply, card cage and interface hardware. The driver cabinet model contains one or two sets of the same hardware contained in the console model. The driver cabinet has no CRT or keyboard. It requires a remote OIC for operator interface.

WARNING	Do not operate the OIS with doors or covers opened or removed. Touching connections that carry current and voltage may cause injury.
ATTENTION	Ne faites pas fonctionner l'OIS si les portes ou les couvercles sont ouverts ou retirés. Tout contact avec les connexions ou circule du courant ou de la tension risque de provoquer des blessures.

OIS Console Hardware

The CRT, alarm display panel (ADP) and I/O panel for the keyboard are in the upper half of the console cabinet. The lower half of the console cabinet contains the power supply, power entry panel (PEP), cable connector panel, multibus card cage and hard disk drive.

The hardware components of an integrated IIOIS201 console cabinet are:

- 19 inch color CRT (640 x 480 pixel resolution)
- Operator keyboard with 16 user defined keys (32 keys if the shift key is used)
- INFI NET/Plant Loop
- 85 megabyte hard disk drive
- 1 2 megabyte floppy disk drive; 5¼ inch format
- Annunciator relays and audible tones

INTRODUCTION

- 32 bit 25 megahertz processor
- 8 megabytes of dynamic RAM (DRAM) memory
- Battery backed real time clock
- 32 key annunciator display panel (ADP)

OIS Console Component Locations

Figure 1 2 shows the rear view of the OIS console with the door removed This figure shows the physical relationship between the subassemblies in this unit. Refer to Section 2 and Section 4 for the layout of the multibus card cage, cable connector panel and the power entry panel

NOTE: Figures 1 2 to 1 4 are shown with power removed

OIS console hardware is located in the operator console cabinet The power entry panel, cable connector panel, and hard disk are in the lower half of the cabinet with the multi bus card cage The CRT, power supply, annunciator display panel and operator keyboard interface panel are located in the upper half of the cabinet

The keyboard interface panel is located beside the CRT on the front of the cabinet It is made up of the floppy disk drive and connections for the keyboard, mouse/trackball and an engineering keyboard




Figure 1 2 OIS201 Console Front and Rear Views

The power entry panel has terminals for input AC. The cable connector panel has alarm contact outputs located on a terminal block and cable connectors for peripheral devices. The alarm contact relay outputs are for alarm annunciation only.

OIS Driver Cabinet Hardware

The IIOIS20A has one set of OIS driver cabinet hardware located in the bottom of the driver cabinet. The IIOIS20D has two sets of OIS electronics, the second set of hardware is located in the top half of the driver cabinet.

In the IIOIS20A, the power entry panel, cable connector panel and hard disk are in the lower half of the cabinet with the multibus card cage and power supply. There is no annunciation display panel and operator keyboard interface panel in the driver cabinet (see Figure 1 3)




Figure 1 3. IIOIS20A/D Driver Cabinet Front View

INTRODUCTION

The power entry panel has terminals for input AC. The cable connector panel has alarm contact outputs and cable connectors for peripheral devices.

The hardware components of an integrated IIOIS20A driver cabinet are:

- INFI NET/Plant Loop interface
- 85 megabyte hard disk drive
- 1 2 megabyte floppy disk drive; 5¼ inch format
- Annunciator relays and audible tones
- 32 bit, 25 megahertz processor
- 8 megabytes of dynamic RAM (DRAM) memory
- Battery backed real time clock

OIS Driver Cabinet Components Location

Figure 1 3 shows the front view of the OIS driver cabinet with the door removed. This figure shows the location of the sub assemblies in this unit. Refer to Section 4 for the layout of the multibus card cage, cable connector panel and the power entry panel. Table 1 2 lists the modules in the multibus card cage of the OIS console and the OIS driver cabinet.

Table 1 2 Multibus Card Cage Modules

Slot	Card	Description
Slot 1/3	IMGC01	Slot 1 The Multibus Graphics Controller Module sends the video signals to the CRT. Slot 3 optional MGC01 for a second CRT.
Slot 6	IMKM01	Console The Multibus Keyboard Module connects the keyboard interface pane and touch screens to the MSM01 through an RS 232 serial link. The MPM01 reads and processes keyboard data from the MSM01.
Slot 6	IMRM01	Driver cabinet The Multibus Reset Module provides system reset.
Slot 9	MSM01	The Multibus Serial Interface Module allows the MPM01 to communicate to the communication loop interface, printers and keyboards.
Slot 10	IMPM01	The Multibus Processor Module contains the 25 MHz 32 bit microprocessor and 8 Mbytes of dynamic RAM memory.
Slot 12	IMCP0	The Multibus Communication Processor Module allows the IMM01 to communicate with the MPM01 through the IMSM01.
Slot 14	IMLM01	The Multibus Loop Module allows the IMCL01 and the MCP0 to communicate together.
Slot 16	MCL01	The Multibus Communication Loop Termination Module terminates the coax or twinax cable of the communication loop.

IIOIC20 OPERATOR INTERFACE CONSOLE

There are five models of the Operator Interface Console (IIOIC20) remote consoles Table 1 3 lists the IIOIC20 models. The Operator Interface Console (IIOIC20) models are shown in Figure 1 4

Table 1 3 OIC Models

Nomenclature	Description
IIOIC201	Tabletop Operator Interface Console (19 inch CRT)
IIOIC2021	Console Model Operator Interface Console, Lower CRT
I OIC2022	Console Mode Operator Interface Console, Dual CRT
OIC2023	Console Mode Operator Interface Console, Upper CRT
IIOIC203	Environmental Cabinet Operator Interface Console
IIOIC204	Panel Mounted Operator Interface Console
IIOIC205	Tabletop Operator Interface Console (37 inch CRT)

IIOIC20 HARDWARE OVERVIEW

The OIC provides a remote operator interface for display graphics, alarm summaries, INFI 90 status, logs, trends and control stations. The OIC allows more than one operator to use a single host OIS.

There are five models of OIC; console, environmental cabinet, 19 inch table top, panel mount and 33 inch table top models. The console model (IIOIC20) may have a lower CRT, an upper CRT or both with a power entry panel, cable connector panel ADP panel, operator keyboard and interface board.

The environmental cabinet model (IIOIC203) contains a CRT, power entry panel, cable connector panel, operator keyboard, ADP panel and interface similar to the console model, panel mount, 19 inch tabletop and 37 inch tabletop model.

The OIC hardware connects to the operator interface station with minimum wiring and configuring. The OIC connects to the OIS through an RS 232 cable from the IIMKM01 board on the OIC and an RGB cable to the CRT. Note that each OIC

INTRODUCTION




Figure 1 4 I/OIC20 Models. 19 Inch Table Top, 37 Inch Tabletop Panel Mounted, Environmental Cabinet and Console (CW)

requires two RGB cables. One cable (part number 6637597 24100) connects the IIMGC01 graphics card in the OIS to the connector panel on the back of the OIS. The other cable (part number NKMC01 xx) connects the connector panel on the back of the OIS to the OIC.

WARNING

Do not operate the OIC with doors or covers opened or removed. Touching connections that carry current and voltage may cause injury.

ATTENTION

Ne faites pas fonctionner l'OIC si les portes ou les couvercles sont ouverts ou retirés. Tout contact avec les connexions ou circuits de courant ou de la tension risque de provoquer des blessures.

OIC Tabletop (19 Inch) Hardware

OIC tabletop hardware is located in a case. The power supply and Multibus Keyboard Module (IIMKM01) are in the case with the power supply. The CRT is mounted on top of the case (see Figure 1-5).

NOTE: Figures 1-5 to 1-9 are shown with power removed.

The rear panel has terminals for input AC, alarm contact outputs, CRT cables and a power switch. The front panel has the connectors for peripheral devices and a tune/off/configuration keyswitch.




Figure 1-5 IIOIC201 Tabletop (19 Inch) Front and Rear Views

OIC Console Hardware

OIC console hardware is located in both the upper and lower sections of the operator console cabinet. The IIOIC202 may include a lower, upper or dual CRTs, depending on the configuration.

The PEP and cable connector panel are in the lower half of the cabinet with the multibus card cage. The CRT, power supply, annunciator display panel (ADP) and operator keyboard interface panel are located in the upper half of the cabinet. The keyboard interface panel is located beside the CRT on the front of the cabinet. It is made up of connectors for the keyboard, mouse/trackball and an engineering key board.

INTRODUCTION



The power entry panel has terminals for input AC. The cable connector panel has alarm contact outputs and cable connectors for peripheral devices. OIC console cabinet hardware consists of:

- 19 inch color CRT (640 x 480 pixel resolution)
- Operator keyboard with 16 user defined keys
- Annunciator relays (24 VDC) and audible tones
- The alarm contact relay outputs are for alarm annunciation only
- 32 key annunciator display panel (ADP)

OIC Console Component Locations

Figure 1 6 shows the front and rear view of the OIC console with the door removed. This figure shows the placement of the subassemblies in this unit. Refer to Section 4 for the layout of the multibus card cage, cable connector panel and the PEP.




Figure 1 6. OIC2021 Console Front and Rear Views

OIC environmental cabinet hardware is located in the bottom of the cabinet. The PEP, cable connector panel and Multibus Keyboard Module (IIMKM01) are in the lower half of the cabinet with the power supply. The annunciator display panel and CRT are on the front of the cabinet.

The power entry panel has terminals for input AC. The cable connector panel has alarm contact outputs (24 VDC) and cable connectors for peripheral devices. The alarm contact relay outputs are for alarm annunciation only.

OIC Environmental Cabinet Component Locations

Figure 1 7 shows the front view of the OIC environmental cabinet. This figure shows the physical relationship between the subassemblies in this unit. Refer to Section 4 for the layout of the cable connector panel and the power entry panel.




Figure 1 7 I/OIC203 Environmental Cabinet Front and Rear Views

OIC Panel Mounted Hardware

OIC panel mounted hardware is located behind the CRT and operator keyboard interface panel. The power supply, power entry panel and Multibus Keyboard Module (IIMKM01) are located with the CRT.

The back of the power entry panel has terminals for input AC, alarm contact outputs (24 VDC) and the CRT cables. The operator keyboard interface panel is mounted on a separate panel. It has the connectors for operator devices such as keyboard, trackball or mouse, and a tune/off/configuration keyswitch. The alarm contact relay outputs are for alarm annunciation only.

INTRODUCTION

OIC Panel Mounted Component Locations

Figure 1 8 shows the rear view of the OIC This figure shows the physical relationship between the subassemblies in this unit Refer to Section 4 for the layout of the cable connector panel and the power entry panel.




Figure 1 8 I/OIC204 Panel Mounted Model Front and Rear Views

OIC Tabletop (37 Inch) Hardware

The OIC 37 inch table top monitor is a standard package (see Figure 1 9). The power supply, Multibus Keyboard Module (IIMKM01) and keyboard are optional

The optional operator keyboard interface box (part number 6639030 2) has terminals for input AC, alarm contact outputs, a power switch and the CRT RGB cable (part number NKMC01 XX) from the OIS The front panel has the connectors for peripheral devices and a tune/off/configuration key switch The CRT part number is 1948014 7




Figure 1 9 IIOIC205 Tabletop (37 Inch) Front and Rear Views

INTRODUCTION

STANDARD AND OPTIONAL HARDWARE

Table 1 4 lists the hardware used in the Operator Interface Station, console (IIOIS20) and driver cabinet (IIOIS20A/D) This table also lists the hardware used for the Operator Interface Console, console (IIOIC202), environmental cabinet (IIOIC203) and tabletop (IIOIC201) The optional hardware is listed in Table 1 5

Table 1 4 Standard OIS/OIC Hardware

Part Nomenclature	Where Used							Description
	OIS		OIC					
	20	20A 20D	201	202	203	204	205	
1948002 1	X	X						Hard Disk Drive
1948013 1	X	X						Disk Drive Controller Module
1948014 7							X	Co-ordinator (37 inch)
1948018 1	X	X						Floppy Disk Drive
1948023_1	X	X						SAS Module
1948623 1	X		X	X	X	X		Co-ordinator (19 inch)
6637801 4				X				Screen Socket Multibus Card Cage (with a slide-in power supply)
6637801 2	X	X						Screen Socket Multibus Card Cage
6638235 1	X		X	X	X	X		Keyboard Interface Panel
6638353 1	X							Power Entry Panel
6638353 2				X				Power Entry Panel
6638514 1	X		X	X	X	X		Keyboard Assembly
6638564_				X				Power Supply
6638565 1	X	X						Power Supply
6638564 2			X		X	X	X	Power Supply
6638960 1		X						Power Entry Panel
ADP02	X			X				Annunciator/Display Panel
ADS03					X			Annunciator/Display Panel
MCL01	X	X						Multibus Communication Loop Module
MCP0	X	X						Multibus Communications Processor Module
MGC01 ¹	X	X						Multibus Graphics Controller Module
MKM01	X		X	X	X	X		Multibus Keyboard Module
MLM01	X	X						Multibus Loop Module
MPM01	X	X						Multibus Processor Module
MRM01		X						Multibus Reset Module
MSM01	X	X						Multibus Serial Interface Module

NOTE 1 Multibus graphics controller modules mount in the O20 but are not coded with the O201/2/3/4/5

Table 1-5. Optional OIS/OIC Hardware

Part Nomenclature	Where Used							Description
	OIS		OIC					
	20	20A 20D	201	202	203	204	205	
6638514 1							X	Keyboard Assembly
I ADP01	X		X	X			X	Annunciator/D splay Pane (tabletop)
AKB01	X		X	X	X	X	X	QWERTY Auxil ary Enq neer ng Keyboard
IIAMS01	X		X	X			X	Mouse
I ATB01	X		X	X			X	Trackbal
IATS01	X		X	X			X	Touch Screen
I DMT01		X						Magnet c Tape (rack mount)
IIDMT02	X							Magnetic Tape for Archival Storage (tabletop)
I DOP01		X						Optical Dr ve for Arch va Storage (rack mount)
DOP02	X							Tabletop Opt ca D sk
DST01	X	X						Stream ng Tape Arch va Storage
IIMGC01	X	X						Multibus Graphics Controller Card (add t onal card)
IIPRT02	X	X						B ack and Wh te Pr nter
I PRT03	X	X						Color Printer
IIPRT04	X	X						V deo Cop er (color)
PRT05	X	X						Black and Wh te Pr nter (h gh speed)
VTE01	X	X						Terminal for D agnost cs/ Start Up

INSTRUCTION CONTENT

Introduction Presents an overview of the IIOIS20, IIOIC20 and associated hardware. It also provides a complete list of system specifications.

Description and Operation Describes the physical attributes of the IIOIS20, IIOIC20 and related hardware.

Installation Gives instructions on installation and wiring AC power to the PEP. Be sure to read and follow all warnings and cautions.

INTRODUCTION

- Standard Hardware** Gives the configuration for an IIOIS20 and IIOIC20. Be sure to read and follow all warnings and cautions.
- Optional Hardware** Describes the available options and their configuration and installation procedures. Be sure the model of the option being connected is compatible with the IIOIS20 or IIOIC20 and can be installed using these instructions.
- Maintenance** Contains preventive maintenance information.
- Troubleshooting** Lists troubleshooting steps and information.
- Repair/Replacement Procedures** Describes how to replace standard and optional units and the printed circuit boards in the multibus card rack.
- Service and New Parts** Includes a recommended spare parts list and ordering instructions.

REFERENCE DOCUMENTS

References are made in this manual to the following Bailey Controls publications:

Number	Document Name
E93-905 9	Enhanced Computer Interface Unit Programmer's Reference Manual
-E96 100	IIOIS20 Operation and Configuration Manual
-E96 500	Network 90 S to Planning Preparation and Equipment Installation Instructions

RELATED EQUIPMENT

INFI 90 Multi Function Processor Modules

Plant Loop and INFI NET Communications Modules

INSTALLATION SUMMARY

This section contains a summary of installation data for the IIOIS20 and IIOIC20. Refer to the site planning, preparation and installation instruction manual for more information.

Table 1.6 lists the power consumption for the IIOIS20 and IIOIC20. Table 1.7 lists the cabinet dimensions for the IIOIS20 and IIOIC20.

Table 1 6. IIOIS20 and IIOIC20 Power Consumption

Nomenclature	Description	Typ. Amps	Max. Amps	Max. Dissipation BTU/Hr
O S2011	Console Low CRT, 120 VAC	3.96	9.64	2650
IIOIS2012	Console Low CRT, 240 VAC	2.16	4.82	2650
IO S2021	Console High CRT, 120 VAC	3.96	9.64	2650
IIOIS2022	Console - High CRT, 240 VAC	2.16	4.82	2650
IO S2031	Console - Dual CRT, 120 VAC	5.50	10.67	3026
IIOIS2032	Console Dual CRT, 240 VAC	3.02	5.34	3026
O S20A1	Driver Cabinet - 120 VAC	2.48	8.94	2274
IO S20A2	Driver Cabinet 240 VAC	1.41	4.47	2274
O S20D1	Dual Driver Cabinet 120 VAC	4.96	17.88	4548
IIOIS20D2	Dual Driver Cabinet - 240 VAC	2.82	8.94	4548
O C20101	19 inch CRT Tabletop, 120 VAC	1.72	4.26	992
IO C20102	19 inch CRT Tabletop 240 VAC	0.93	2.13	992
IIOIC20211	Console - Low CRT 120 VAC	1.72	4.26	992
IIOIC20221	Console High CRT, 120 VAC	0.93	2.13	992
IO C20212	Console - Low CRT 240 VAC	1.72	4.26	992
IIOIC20222	Console - High CRT, 240 VAC	0.93	2.13	992
IO C20231	Console - Dual CRT, 120 VAC	2.83	5.82	1368
IIO C20232	Console Dual CRT, 240 VAC	1.46	2.91	1368
IO C20301	Environmental, 120 VAC	2.50	10.34	3905
IIOIC20302	Environmental 240 VAC	1.57	5.17	3905
OIC20411	Panel Mount, 120 VAC	1.72	4.26	992
IO C20412	Panel Mount 240 VAC	0.93	2.13	992
IO C20501	37 inch CRT Tabletop, 120 VAC	1.52	2.70	786
IIOIC20502	37 inch CRT Tabletop, 240 VAC	0.78	1.35	786

Table 1 7. IIOIS20 and IIOIC20 Dimensions

Nomenclature	Description	Dimensions					
		Height		Width		Depth	
		cm	inch	cm	inch	cm	inch
O S201	Console - Low CRT	107.27	42.23	71.12	28.00	109.01	42.92
IOIS202	Console - High CRT	156.94	61.99	71.12	28.00	109.01	42.92
O S203	Console - Dual CRT	156.94	61.99	71.12	28.00	109.01	42.92
IIOIS20A	Driver Cabinet	221.28	87.12	60.96	24.00	76.20	30.00
O S20D	Driver Cabinet	221.28	87.12	60.96	24.00	76.20	30.00
IIOIC201	19 inch Tabletop - CRT	61.00	24.00	51.30	20.00	55.90	22.00
O C2021	Console - Low CRT	107.27	42.23	71.12	28.00	109.01	42.92
IIOIC2022	Console High CRT	156.94	61.99	71.12	28.00	109.01	42.92
O C2023	Console Dual CRT	156.94	61.99	71.12	28.00	109.01	42.92
O C203	Environmental - CRT	177.80	70.00	30.00	76.20	77.80	30.63
IIOIC204	Panel Mount CRT	48.26	19.00	50.8	20.00	50.80	20.00
IIOIC205	37 inch Tabletop - CRT	78.74	31.00	78.74	31.00	58.42	23.00

INTRODUCTION

GLOSSARY OF TERMS AND ABBREVIATIONS

Term	Definition
ADP	A arm annunciator/display panel
Baud	Rate at which data is transmitted over a serial bus in bits per second
Bus	A channel or path for transferring data, electrical signals and power
Configuration	The act of setting up equipment to accomplish specific functions or a list of parameters associated with such a setup
Dipshunt	Dual in-line package with shorting straps
Dipswitch	Dual in-line package that contains switches
DCE	Data Communication Equipment or Data Circuit-Terminating Equipment. Equipment that establishes and terminates a communication link between two devices. In RS 232 C communication systems, the DCE nomenclature indicates the signals that appear at specified cable connection contacts. A modem is an example of this type of device.
DMA	Direct Memory Access. A method by which data gets transferred directly to memory without processor intervention.
DRAM	Dynamic Random Access Memory. Contents are lost when power is removed.
DTE	Data Terminal Equipment. Equipment comprising the data source, data sink or both that provides the communication function. In RS 232 C communication systems, the DTE nomenclature indicates the signals that appear at specified cable connection contacts. Terminals and printers are examples of this type of device.
EPROM	Electrically programmable read-only memory. Contents remain when power is removed.
ESD	Electrostatic Sensitive Devices. Electronic components subject to damage or failure when exposed to an electrostatic charge. require special handling.
Handshaking	Procedures and protocols used by two devices to establish and maintain communication.
INFI-NET	Advanced data communication highway.
LED	Light Emitting Diode.
LSB	Least Significant Bit. The bit of a binary number that carries the least numerical weight.

GLOSSARY OF TERMS AND ABBREVIATIONS (continued)

Term	Definition
MFP	Multi-Funct on Processor Module. A multiple-loop controller with data acquisition and information processing capabilities.
MMU	Module Mounting Unit. A card cage that provides electrical and communication support for INFI 90/Network 90 modules
Module Address	A unique identifier of a specific device or a communication channel. Refers to Controlway or module bus address.
Module Bus	Peer to peer communication link used to transfer information between intelligent modules within a process control unit
MSB	Most Significant Bit. The bit of a binary number that carries the most numerical weight
NVRAM	Nonvolatile Random Access Memory. Retains stored information when power is removed
Node	A point of interconnection to a network
Node Address	A unique identifier of a specific device or a communication channel. Refers to Plant Loop, Superloop or INF NET address
OIS	Operator Interface Station. Integrated operator console with data acquisition and reporting capabilities. It provides a digital access into the process for flexible control and monitoring
Parity Bit	A bit added to a byte, character or word to ensure that there is a way, either an even number or odd number of ones, according to the logic of the system. It is used to verify the integrity of the data.
Parallel Data	Data transmitted simultaneously over multiple signal lines
PEP	Power Entry Pane
PCU	Process Control Unit. A node on the plant-wide communication network containing master and slave modules
PFI	Power Failure Interrupt. A signal generated by the power entry pane when there is a loss of AC or DC input power or an out-of-plant bus voltage
Plant Loop	Network 90 data communication highway
PROM	Programmable Read Only Memory. Contents remain when power is removed
RAM	Random Access Memory. Contents are lost when power is removed

INTRODUCTION

GLOSSARY OF TERMS AND ABBREVIATIONS (continued)

Term	Definition
ROM	Read Only Memory Contents remain when power is removed.
RS-232-C and RS-485	Two serial communication interface standards developed by the Electronics Industry Association (EIA) specifying what signals and voltages will be used to transmit data from a computer (DTE) to a modem (DCE)
SASI	Shugart Associates Standard Interface Defines the protocol and performance interconnection formats of a high speed parallel bus for use throughout the computer industry
SCSI	Small Computer System Interface An I/O bus standard by the American National Standard Institute (ANSI) that defines the protocol and performance interconnection formats of a high speed parallel bus for use throughout the computer industry
Serial Data	Data transmitted sequentially on one signal line

NOMENCLATURE

Nomenclature	Description
IDMT01	Rack mounted nine track magnetic tape drive for archival storage
IDMT02	Tabletop nine track magnetic tape drive for archival storage
DOP01	Rack mount optical disk drive for archival storage
DOP02	Tabletop optical disk drive for archival storage
IO C201	Tabletop operator console with a 19 inch CRT, tilt/swivel base and keyboard
IO C2021	Console style operator console with a lower mounted 19 inch CRT and keyboard
IO C2023	Console style operator console with two 19 inch CRTs (one cabinet mount and one tilt/swivel base mount) and a keyboard
IOIC2022	Console style operator console with an upper mounted 19 inch CRT with tilt/swivel base and keyboard
IO C203	Environmental operator console with a 19 inch CRT and keyboard
IO C204	Panel mount operator console with a 19 inch CRT and an optional keyboard
IO C205	Tabletop 37 inch CRT and keyboard

NOMENCLATURE (continued)

Nomenclature	Description
I OIS20A	Operator interface station driver cabinet unit with multibus card cage, cable connector panel and PEP. An integrated unit with the same function as the OIS except for peripheral devices such as CRT and keyboard.
II OIS20D	Operator interface station driver cabinet unit with two multibus card cages, cable panels and PEPs. An integrated unit with the same function as two I OIS20 cabinets except for peripherals such as CRT and keyboard.
I O S201	Operator interface station integrated unit with cabinet mount CRT and optional keyboard
II OIS202	Operator interface station integrated unit with CRT with tilt/swivel base and keyboard.
I OIS203	Operator interface station integrated unit with dual CRTs (one cabinet mount and one tilt/swivel base mount) and keyboard
II MCL01	Multibus communication loop module
II MCP0_	Multibus communications processor module
II MGC01	Multibus graphics controller module
II MKM01	Multibus keyboard module
I MLM01	Multibus loop module
I MPM01	Multibus processor module
II RRM01	Multibus reset module
I MSM01	Multibus serial interface module
II AKB01	QWERTY style auxiliary (engineering) keyboard.
II ATB01	Trackball cursor controller
I AMS01	Mouse cursor controller
I DST01	Streaming tape for archival data storage
II PRT02	Black and white printer
I PRT03	Color printer (up to 64 colors).
I PRT04	Color video copier.
II PRT05	High speed black and white printer.
NKMR01	RS232 cable from the OIC to the OIS, 25 pin to 25 pin male to male This cable was used on the OIC 202 and 204 before 4/90
NKMR02	RS232 cable from the OIC to the OIS, 9 pin to 25 pin male to male

INTRODUCTION

SPECIFICATIONS FOR OPERATOR INTERFACE CONSOLE (IIOIS20)

Power

Line Voltage	240 V Nominal (204 VAC to 264 VAC RMS)
Line Voltage	120 V Nominal (102 VAC to 132 VAC RMS)
Line Frequency	47 to 63 Hz
Power Consumption	

Model	Description	Watts
IIOIS2011	Console - Low CRT, 120 VAC	775
IIO S2012	Console - Low CRT, 240 VAC	775
IIOIS2021	Console - High CRT, 120 VAC	775
IIOIS2022	Console - High CRT, 240 VAC	775
IIOIS2031	Console - Dual CRT, 120 VAC	885
IIO S2032	Console - Dual CRT, 240 VAC	885
IIO S20A1	Driver Cabinet - 120 VAC	665
IIO S20A2	Driver Cabinet - 240 VAC	665
IIO S20D1	Driver Cabinet - 120 VAC	1330
IIO S20D2	Driver Cabinet - 240 VAC	1330

Hardware

CPU	1 (25 MHz, 32 bit processor)
Memory	8 Mbytes
Floppy Disk	1 2 Mbytes
Hard Disk	85 Mbytes (unformatted)
CRT Resolution	640 x 480 pixels
CRTs Supported per OS	IIO S201 - 1 (plus up to 1 slave) IIO S202 - 1 (plus up to 1 slave) IIO S203 - 2 IIO S20A - 0 (plus up to 2 slaves) IIO S20D - 0 (plus up to 4 slaves)
Keyboards	2 (6 output relays and 5 alarm tones per keyboard) The IIO S20D can support up to four keyboards, all other IIO models can support two keyboards

Alarm Relays	Typical	Maximum
Contact Voltage	24 VDC	100 VDC
Contact Current	0.25 A	0.5 A
Contact Power	6 W	10 W

Configuration	Nonvolatile ROM and hard disk memory
CRT Resolution	640 x 480 pixels

SPECIFICATIONS FOR OPERATOR INTERFACE CONSOLE (IIOIS20) (continued)

Attributes																			
Display Screens	1,000; 200 dynamic items per screen																		
Control/Display Selects	200 selects from touch screen or keyboard 200 selects from keyboard																		
Tags	5,000																		
Trends	1,000																		
Real Time Trends	20																		
Operator Configurable Display	25																		
Logs (total, trend, trip snapshot)	100 in any combination of trend, trip and periodic logs; sequence of events logs are additional																		
SOE Logs/Reports	16/80																		
Event Log (no. of events)	1000																		
Environment																			
Temperature																			
Operating	10° to 40°C (50° to 104°F)																		
Storage	5° to 50°C (41° to 122°F)																		
Relative Humidity																			
Operating	20% to 80% noncondensing																		
Storage	10% to 95% noncondensing																		
Altitude	-1,000 feet to +10,000 feet																		
Cooling Requirements																			
	<table border="1"> <thead> <tr> <th>Model</th> <th>Description</th> <th>Dissipation BTU/Hr (Max.)</th> </tr> </thead> <tbody> <tr> <td>IIOIS201</td> <td>Console - Low CRT</td> <td>2650</td> </tr> <tr> <td>IIOIS202</td> <td>Console - High CRT</td> <td>2650</td> </tr> <tr> <td>IIOIS203</td> <td>Console - Dual CRT</td> <td>3026</td> </tr> <tr> <td>IIOIS20A</td> <td>Driver Cabinet</td> <td>2274</td> </tr> <tr> <td>IIOIS20D</td> <td>Dual OIS Driver Cabinet</td> <td>4548</td> </tr> </tbody> </table>	Model	Description	Dissipation BTU/Hr (Max.)	IIOIS201	Console - Low CRT	2650	IIOIS202	Console - High CRT	2650	IIOIS203	Console - Dual CRT	3026	IIOIS20A	Driver Cabinet	2274	IIOIS20D	Dual OIS Driver Cabinet	4548
Model	Description	Dissipation BTU/Hr (Max.)																	
IIOIS201	Console - Low CRT	2650																	
IIOIS202	Console - High CRT	2650																	
IIOIS203	Console - Dual CRT	3026																	
IIOIS20A	Driver Cabinet	2274																	
IIOIS20D	Dual OIS Driver Cabinet	4548																	
Weight	IIOIS201 - 174 kg (384 lbs) IIOIS202 - 191 kg (421 lbs) IIOIS203 - 230 kg (506 lbs) IIOIS20A - 207 kg (456 lbs) IIOIS20D - 230 kg (506 lbs)																		
Certification	CSA certified for use in an ordinary (nonhazardous) location																		

SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

INTRODUCTION

SPECIFICATIONS FOR OPERATOR INTERFACE CONSOLE (I/OIC20)

Power

Line Voltage	240 V Nom na (204 VAC to 264 VAC RMS) 120 V Nom na (102 VAC to 132 VAC RMS)
Line Frequency	47 to 63 Hz
Circuit Breaker Size	20 A circuit breaker for I/O C203 10 A circuit breaker for I/OIC201, I/O C202 and I/OIC204 The I/O C205 has a manufacturers on/off switch

Power Consumption

Nomenclature	Description	Watts
O C20101	19 nch Tab etop CRT, 120 VAC	290
O C20102	19 nch Tab etop - CRT, 240 VAC	290
O C20211	Console Low CRT 120 VAC	290
O C20221	Console High CRT 120 VAC	290
O C20212	Console Low CRT 240 VAC	290
O C20222	Console - High CRT, 240 VAC	290
O C20231	Console Dual CRT, 120 VAC	400
I/O C20232	Console Dual CRT, 240 VAC	400
I/OIC20301	Environmental CRT 120 VAC	893
I/OIC20302	Environmental CRT, 240 VAC	893
O C20411	Panel Mount - CRT, 120 VAC	290
O C20412	Panel Mount CRT, 240 VAC	290
I/OIC20501	37 nch Tab etop CRT 120 VAC	230
I/OIC20502	37 nch Tab etop CRT, 240 VAC	230

Power Supply

O C201/02/03/04/05	+5 VDC at 20 A +12 VDC at 5 A -12 VDC at 1 A +12 VDC at 1 A (fan)
--------------------	--

Hardware

Model	CRTs	Keyboards
O C201	1	1
O C202	1 or 2	1
I/O C203	1	1
I/O C204	1	1 (optional)
O C205	1	

SPECIFICATIONS FOR OPERATOR INTERFACE CONSOLE (IIOIC20) (continued)

Hardware (continued)																									
Keyboards	1 (6 output relays and 5 a arm tones per keyboard)																								
	<table border="1"> <thead> <tr> <th>Alarm Relays</th> <th>Typical</th> <th>Maximum</th> </tr> </thead> <tbody> <tr> <td>Contact Voltage</td> <td>24 VDC</td> <td>100 VDC</td> </tr> <tr> <td>Contact Current</td> <td>0.25 A</td> <td>0.5 A</td> </tr> <tr> <td>Contact Power</td> <td>6 W</td> <td>10 W</td> </tr> </tbody> </table>	Alarm Relays	Typical	Maximum	Contact Voltage	24 VDC	100 VDC	Contact Current	0.25 A	0.5 A	Contact Power	6 W	10 W												
Alarm Relays	Typical	Maximum																							
Contact Voltage	24 VDC	100 VDC																							
Contact Current	0.25 A	0.5 A																							
Contact Power	6 W	10 W																							
Attributes																									
	OIC attributes are determined by the host OIS																								
Environment																									
Temperature																									
Operating	10° to 50°C (40° to 104°F)																								
Storage	5° to 50°C (41° to 122°F)																								
Relative Humidity																									
Operating	5% to 40% noncondensing																								
Storage	5% to 95% noncondensing																								
Altitude	Sea level to 18 miles (3km)																								
Cooling Requirements																									
	<table border="1"> <thead> <tr> <th>Model</th> <th>Description</th> <th>Dissipation BTU/Hr (Max.)</th> </tr> </thead> <tbody> <tr> <td>IIOIC201</td> <td>19 inch Tabletop</td> <td>992</td> </tr> <tr> <td>IOIC2021</td> <td>Console</td> <td>992</td> </tr> <tr> <td>IIOIC2022</td> <td>Console</td> <td>992</td> </tr> <tr> <td>IO C2023</td> <td>Console</td> <td>1368</td> </tr> <tr> <td>IIO C203</td> <td>Environmental Cabinet</td> <td>3053</td> </tr> <tr> <td>IO C204</td> <td>Panel Mount</td> <td>992</td> </tr> <tr> <td>IO C205</td> <td>37 inch Tabletop</td> <td>786</td> </tr> </tbody> </table>	Model	Description	Dissipation BTU/Hr (Max.)	IIOIC201	19 inch Tabletop	992	IOIC2021	Console	992	IIOIC2022	Console	992	IO C2023	Console	1368	IIO C203	Environmental Cabinet	3053	IO C204	Panel Mount	992	IO C205	37 inch Tabletop	786
Model	Description	Dissipation BTU/Hr (Max.)																							
IIOIC201	19 inch Tabletop	992																							
IOIC2021	Console	992																							
IIOIC2022	Console	992																							
IO C2023	Console	1368																							
IIO C203	Environmental Cabinet	3053																							
IO C204	Panel Mount	992																							
IO C205	37 inch Tabletop	786																							
Weight																									
	IO C201 - 61 kg (135 lbs) IIOIC2021 - 152 kg (334 lbs) IIOIC2022 - 168 kg (371 lbs) IIOIC2023 - 211 kg (456 lbs) IIOIC203 - 222 kg (490 lbs) IIOIC204 - 61 kg (134 lbs) IIOIC205 - 91 kg (200 lbs)																								
Certification																									
	CSA certified for use in an ordinary (nonhazardous) location																								

SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

23.02.87 04.10.07

Bailey

SECTION 2 - DESCRIPTION AND OPERATION

INTRODUCTION

This section explains the electronic circuitry for the Operator Interface Station (IIOIS20) and the Operator Interface Console (IIOIC20). An operator uses the OIS to monitor and control the process. The OIS shows equipment status and process states with interactive color graphics displays.

The display is 640 x 480 pixels with any of the available colors. Each display can use dynamic variables and symbols allowing data to be condensed in each display. Any graphic element can be mixed with any symbol on any display such as schematics, faceplates, trends and alarm summaries.

OIS FUNCTIONAL OPERATION

Figure 2-1 shows a block diagram of the IIOIS20. This block diagram shows the signal flow for the IIOIS201/2/3 and IIOIS20A/D. Figure 2-1 shows the logic and signal flow described in the text.

Process data from the Plant Loop or INFI-NET enters the OIS through the network interface unit (NIU). Three cards in the multibus card cage make up the NIU. They are the Multibus Communication Loop Termination Module (IIMCLO1), Multibus Loop Module (IIMLM01) and Multibus Communication Processor Module (IIMCPO1). The MCL module in slot 16 of the multibus card cage connects to the loop. Front edge connectors on the MCL terminate a redundant coaxial or twinaxial cable of the loop. A ribbon cable connects the MCL to the MLM module in slot 14. The MLM converts analog loop signals to digital format for the MCP module. A ribbon cable connects the MLM to the MCP module. A cable connects the MCP to the MSM serial module through the NIU connector on the cable connector panel on the PEP.

The Multibus Processor Module (IIMPM01) in slot 12 contains the 20 megahertz 68020 microprocessor and 8 megabytes of Dynamic RAM memory. The MPM performs the controlling function for the system. Backplane connections connect the MPM to the MSM serial module and the MGC graphics card.

Modules in slots 1 to 11 communicate with each other over the backplane of the multibus card cage. The Multibus Communication Processor Module (IIMCPO1) in slot 14 interfaces the NIU to the MSM serial interface card.

DESCRIPTION AND OPERATION




Figure 2 1 IIOIS20 Block Diagram

The Multibus Serial Interface Module (IIMSM01) in slot 11 allows the MPM processor module to communicate with the communication loop interface, printers and keyboards

The Multibus Keyboard Module (IIMKM01) in slot six connects the keyboard interface panel and touch screens to the MSM through an RS 232 serial link. The MPM reads and processes keyboard data from the MSM. A cable connects the MKM to the keyboard connector panel. The controller board for the touchscreen mounts to this module (two maximum).

The Multibus Graphics Controller Module (IIMGC01) in slot one or slot three sends video signals to the CRT. The optional MKM in slot three is for a second CRT on the OIS or a CRT

with remote mounting. A cable connects the MGC to the RGB connectors on the back of the CRT

Refer to Section 4 for more information on standard OIS modules and units. Refer to Section 5 for more information on optional OIS modules and units.

OIC FUNCTIONAL OPERATION

Figure 2-2 shows a block diagram of the IIOIC20. This block diagram shows the signal flow for the IIOIC201/2/3/4/5. See this figure when you read the description.

The OIC controls and monitors the process through the OIS. The OIC is a remote operator station with a CRT and keyboard. Process data on the Plant Loop and INFI NET connect to the NIU modules in the OIS. The processor and serial controller card in the OIS controls the OIC.

Two cables connect the OIC to the OIS. Commands from the OIC go to the OIS through a serial interface cable. The serial cable connects from the MKM module serial interface port of the OIC to the cable connector panel of the OIS. RGB signals from the OIS go to the OIC through a triple cable with three




Figure 2-2 IIOIC201/2/3/4/5 Block Diagram

DESCRIPTION AND OPERATION

BNC connectors The RGB cable connects from the optional second CRT connector panel in the back of the OIS to the RGB connectors on the MGC card

The Multibus Keyboard Module (IIMKM01) connects the operator keyboard interface panel and touch screens to the MSM in the OIS through an RS 232 serial link Each MKM will support a Bailey Controls keyboard and an engineering keyboard connected through the operator keyboard interface panel. The MPM reads and processes keyboard data from the MSM A cable connects the MKM to the keyboard I connector on the cable connector panel Each OIS with a keyboard or OIC with a keyboard requires an MKM Note that the keyboard is optional for the IIOIC205

The controller board for the touchscreen mounts to the MKM module (two maximum) Note that no touch screen is available for the IIOIC205 (37 inch monitor) or IIOIC203 (environmental cabinet)

The Multibus Graphics Controller Module (IIMGC01) in slot one (or optional card in slot three) of the OIS sends video signals to the CRT A cable connects the MGC to the RGB connectors on the back of the CRT

Refer to Section 4 for more information on standard OIC modules and units Refer to Section 5 for more information on optional OIC modules and units

LOGIC POWER

An internal power supply converts the AC input to the DC voltages needed to power the OIS or OIC electronics (+5, +12 VDC)

MULTIBUS

The INFI 90 multibus is a high speed synchronous parallel bus It provides a path between cards in the multibus card cage The bus provides control signals for connecting multiple masters in either parallel or serial priority Both the P1 and P2 card edge connector of the cards connect to the bus.

The multibus has twelve parallel signal and control lines located on the multibus card cage backplane The bus allows memory and I/O data transfers, direct memory access and interrupt generating The bus is built on the master slave concept where the master device in the system takes control of the bus The slave device acts on the command from the master The handshake between the master and slave allows devices of different speeds to be interfaced through the bus Data rates up to five million transfers per second (bytes of words) to take place across the bus

SECTION 3 - INSTALLATION

INTRODUCTION

This section explains how to install and prepare the IIOIS20 (OIS) and IIOIC20 (OIC) for operation. Read and understand these steps before installing the OIS. Call the local Bailey Controls sales office before starting with questions about installing or setting up the OIS/OIC.

SPECIAL HANDLING

The IIOIS20 and IIOIC202 weigh approximately 138 to 230 kilograms (304-506 pounds). Be sure to move the cabinet with equipment rated for this weight.

The IIOIS20A/D and IIOIC203 weigh approximately 207 to 230 kilograms (456-506 pounds). Be sure to move the cabinet with equipment rated for this weight.

HARDWARE SETUP ELECTROSTATIC DISCHARGE (ESD) CONTROL

The OIS contains circuit boards using CMOS components. Before removing a module from the multibus card cage or do maintenance on equipment having static sensitive devices read this section.

Static susceptible devices (SSD) are likely to be damaged from contact with potential static charges more than 6 225 volts. This potential, when placed across the leads of a SSD can damage the oxide layers within the package. Latent or immediate damage may result. Latent damage may not be detectable under normal circuit check out, but may result in a reduced life of equipment or reduced system functions.

Methods for preventing damage involve equalizing the potentials across all SSD terminals and across the SSD working area, tooling and operator. The most common method is to connect tools, assembly equipment and the operator electrically to earth ground. This procedure should be followed at all stages of handling.

Special handling procedures help avoid damage to the printed circuit boards.

1. Personnel working with or handling printed circuit boards need to be grounded by wearing conductive wrist ground straps.

INSTALLATION

NOTE. Always use the Bailey Controls field static kit (P/N 1948385A2 consisting of a wrist strap, ground cord assembly, and alligator clip) when working with the O/S or O/C. The kit is designed to connect the technician and the static dissipating work surface to the same ground point to prevent damage to the modules by electrostatic discharge.

- 2 Personnel wearing silk, wool or synthetic clothing shall wear a conductive material smock. Personnel shall keep all plastic and textiles which are not antistatic away from SSD and work stations.
- 3 Use antistatic containers and bags. Store ESD sensitive equipment in these containers/bags when they are not in the system.
- 4 Ground containers and bags before opening.
- 5 Ground test and assembly equipment.
- 6 Work stations need to be constructed or covered with conductive materials.
- 7 Keep the work area free of plastic, styrofoam, cellophane and vinyl materials (e.g., coffee cups, cup holders, cigarette packages, combs, books, folders).
- 8 Be sure the tools that come into contact with SSD are made of conductive materials and provide a means for connection to ground.
- 9 Use soldering irons with a grounded tip that are approved for use on SSD.

UNPACKING AND INSPECTION

Compare the shipment to the invoice upon receiving the OIS/OIC. Examine the shipping crate for damage. Report any damage immediately to the carrier. If immediate repair or replacement is necessary, notify the nearest Bailey Controls sales/service office.

If the OIS is not put into service immediately, store it in its original shipping package. If the OIS is to be stored, maintain the storage environment defined in the environmental specifications in Section 1 of this manual.

PLANNING AN INSTALLATION

Refer to the site planning, preparation and equipment installation manual for site selection, preparation and hardware installation of the INFI 90 control system. This document includes requirements and recommendations of load bearing for floors, space around equipment, temperature, humidity,

shock and vibration, AC power wiring, power and DC signal common grounding, line conditioning, uninterrupted power supplies, radio frequency and electromagnetic interference, electrostatic discharge, lighting, equipment protection, equipment handling and storage.

SAFETY CONSIDERATIONS

Do not remove or install circuit boards with power applied to the OIS or OIC. The circuit board may be damaged. Remove power to all AC wiring when removing or connecting AC wires to prevent personal injury and equipment damage. Remove DC power to all DC wiring when removing or connecting DC wires or circuit boards to prevent damage to equipment.

IIOIS202 PHYSICAL DESCRIPTION

The operator interface station (OIS) has front and rear swing out doors with individual locks. The front door has slotted openings for the air intake to cool the inside of the cabinet. The cabinet has a stabilizer which must be fastened to the front of the cabinet when the OIS is not secured to the floor. The 6.4 centimeters (2.5 inches) diameter cable entry is located at the bottom right rear of the unit. There is also a bottom cable entry in the cabinet. The cabinet dimensions are shown on Figure 3-1.

IIOIS202 SETUP AND PHYSICAL INSTALLATION

Before the OIS is set into place in a control room, insure that the floor is level in the area where the cabinets will be set. Adjust the leveling screws on all cabinets and connecting tables until the CRT bezel of each cabinet lines up. The leveling screws adjust 2.56 centimeters (1.05 inches). The dimensions for the leveling screws are shown on Figure 3-2.

After the cabinets are fastened down, put the tables on the cabinets and lock them into place by pushing the red handle above the front access door to the right until it stops at the bottom of the slot.

The tabletops are adjustable. The brackets supporting the tabletops are bolted through oversize holes. Loosen the bolts and move the top up to 0.25 inches up, down, forward or back toward the cabinet to line up the tabletop.

There are two chrome table alignment pins shipped inside the brass bushings located on each side of each tabletop. When two tabletops are lined up, push the pins outward into

INSTALLATION




Figure 3 1 IIOIS20 Cabinet Dimensions

the bushing of the table to the right of the cabinet. Tighten the three bolts on each tabletop support bracket.

Protect the wires and cabling going to the OIS cabinet. Run cabling through conduit to the back of the cabinet or under the floor through the bottom of the cabinet. Follow local wiring codes when wiring and installing cableways or conduit. Refer to the site planning, preparation and equipment installation manual for more information.

Figure 3 1 and Figure 3 2 show the IIOIS20 cabinet dimensions. Figure 3 3 shows the IIOIS20 keyboard table. Figure 3 4 shows the 15 degree wedge table dimensions. Figure 3 5 shows the 45 degree wedge table dimensions.




Figure 3 2. IIOS20 Anchoring Dimensions




Figure 3 3. OIS/OIC Keyboard Table




Figure 3 4 OIS/OIC 15 Degree Wedge Table Dimensions

IIOIS20A/D PHYSICAL DESCRIPTION

The Operator Interface Station Driver Cabinet (IIOIS20A/D) has a front and rear swing out door with individual locks. The front and back doors seal in the air that is cooled by the internal cooling system of the unit. Two cable entries are located at the bottom of the unit. The cabinet dimensions are shown on Figure 3 6.

IIOIS20A/D SETUP AND PHYSICAL INSTALLATION

Before the IIOIS20A/D is set into place in a control room, insure that the floor is level in the area where the cabinet will be set. The unit must be secured to the floor before it is wired or operated. The dimensions for locating the mounting screws are shown in Figure 3 7.

Protect the wires and cabling going to the OIS cabinet. Run cabling through conduit to the back of the cabinet or under the floor through the bottom of the cabinet. Follow local




Figure 3 5. OIS/OIC 45 Degree Wedge Table Dimensions

wiring codes when wiring and installing cableways or conduit. For more information, refer to the site planning, preparation and equipment installation manual.

IIOIS20 WIRING CONNECTIONS AND CABLING

Table 3 1 contains the color codes for wiring the IIOIS20 or IIOIS20A/D. Table 3 2 contains a list of cables and their connections. IIOIS20 cable connections are shown in Figure 3 8

The OIS is internally wired when it is shipped. Connect the communication loop cables, AC power and any peripheral devices. AC power is connected to TB1 on the power entry panel (PEP). Communication loop cables connect to the

INSTALLATION




Figure 3 6 IIOIS20A/D Cabinet Dimensions

IIMCLO1 module in the multibus card cage Peripheral devices connect to the front of the PEP or to the keyboard interface panel Refer to Section 4 and Section 5 for specific instructions on installing and configuring peripheral devices and replacement components




Figure 3-7 I/OIS20A/D Anchoring Dimensions

Table 3-1 OIS Wiring Color Codes

Color	Function
Brown	AC Hot
Blue	AC Neutral
Green/Yellow	AC Common
Brown	+5 VDC
White/Green	DC Common
Violet	12 VDC
White/Violet	+12 VDC
Green	Remote Voltage Sense
White	+ Remote Voltage Sense

INSTALLATION



Table 3 2 IIOIS20 Cable Connections

Cable No	Cable Name	Connect From	Connect To
6637599 1	AC Power	J1 on PEP	AC High on Main Power Supply AC Low on Main Power Supply Ground on Main Power Supply
1947950 1	AC Power	J2 on PEP	CRT1 AC Power Connector
1947950 5	AC Power	J3 on PEP	CRT2 AC Power Connector
6638712 1	PF Sense	J1 on Power Supply	TB1 on Backplane P3 on I MKM01
6638718_1	Power	Connector +12/ 12 on Backplane	Terminal Strip on DC Distributor on Board
6638708 1	Power	TB2 on Backplane	Terminal Strip on DC Distributor on Board
6638711 1	Power	CH1+, CH1 on Power Supply	TB3, TB4 TB5 TB6 on Backplane
6638719 1	Reset Cable	Reset Switch on PEP	P4 on I MKM01
6637776 2	Worst Ground	User	Worst Connector on PEP
6637460 50N42	Disk Drive	J8 on Disk Controller	Streaming Tape Port on PEP
6637460 50N42	Disk Drive	J43 on MPM01	SCS Port on PEP
6638716 1	RS 232 Cable	J6 on MPM01 (top half) (bottom half)	P10 on PEP P9 on PEP
6638715 1	RS 232 Cable	P1 P4 on PEP	Lower Connector on MSM01
6638715 1	RS 232 Cable	P5 P8 on PEP	Upper Connector on MSM01
6638720 1	Lower CRT Bright	9 Pin Connector on Rear of Lower CRT	CRT Bezel Brightness CRT Bezel Contrast Degaussing Switch on PEP
6638720 2	Upper CRT Bright	9 Pin Connector on Rear of Upper CRT	CRT Bezel Brightness CRT Bezel Contrast Degaussing Switch on PEP
6638771 1	Power	P8 DC Distributor on Board on Main Power Supply	Fan
6637597 31200	Upper RGB Video	RGB on IMGC01	RGB on Upper CRT
6637597 24100	Lower RGB Video	RGB on MGC01	RGB on Lower CRT
6634512 26N72	I/O Distributor	P5 on MKM01	P1 on Keyboard Interface Board
6634512 26N72	I/O Distributor	P6 on MKM01	Terminal Block on Rear of PEP

Table 3 2. IIOIS20 Cable Connections (continued)

Cable No	Cable Name	Connect From	Connect To
6638713 1	Per phera Power	J2 on Keyboard-Interface Board	P3 on DC D str but on Board on Ma n Power Supp y
6638713_2	Per phera Power	P1 on ADP Board	P4 on DC Distribut on Board on Ma n Power Supp y
6638713 3	Per pheral Power	Connector on Floppy Drive Power	P2 on DC Distribution Board on Main Power Supp y
6634328 34N48	Floppy S gna	J7 on D sk Contro er	J1 on F oppy Dr ve
6638849_1	ADP Signal	P7 on IIMKM01	P8 on Keyboard - interface Board P2 on ADP Pane
6632686 50-1	D sk Data	J1 on D sk Contro er	J1 on SAS Modu e
6634329_20N8	Hard Dr ve Data	J4 on Disk Contro er	J2 on Hard Disk Dr ve
6634329 34N12	Hard Drive Data	J2 on D sk Controller	J1 on Hard D sk Drive
6638713 4	Per pheral Power	Power Connector on Hard D sk	P1 on DC D str but ion Board on Main Power Supp y
6638713_5	Per pheral Power	J10 on Disk Controller	P6 on DC Distribution Board on Ma n Power Supp y
6638717 1	PFI Sense	J2 on Main Power Supply	P7 on DC Distribution Board on Ma n Power Supp y
6634512_26N2	Internal I/O	P4 on IIMCP0_	P4 on IIMLM01
6634512_26N2	nterna I/O	P3 on IIMCL01	P3 on I MLM01
NKMR02 3	9-25 RS-232	P5 on I MCP0_	F4 on PEP
NKMR02 3	9 25 RS-232	P9 on IIMKM01	P1 on PEP
1948644_5	Touch Screen Extension	Touch Screen on Upper CRT	5 P n Connector on Touch Screen Module

Communication Loop Connections

Redundant communication loops can connect to the IIMCL01 module in the multibus card cage. Run coaxial cables with BNC connectors or twinaxial cables to the front connections on the IIMCL01 module. Cables can enter the cabinet from the floor level opening on the rear of the cabinet or through the hole in the bottom of the cabinet under the power entry panel.

Peripheral Device Connections

There are peripheral device ports on the cable connector panel located above the power entry panel (PEP) and on the keyboard interface panel located beside the CRT. The SCSI port on the cable connector panel is not used at this time. The streaming tape port on the cable connector panel connects to an optional streaming tape reader. The keyboard port on the keyboard interface panel connects to the keyboard shipped with the OIS. The AUX 1 port on the keyboard interface panel connects to an optional tabletop annunciator display panel (ADP). The mouse/trackball port supports either a mouse or trackball cursor controller. The AUX KBD port connection is for an optional engineering keyboard. Refer to Section 5 for more information on peripheral devices.

AC Power

IIOIS20 AC power input connects to a terminal block on the bottom front of the power entry panel. The IIOIS20 can operate from 120/240 VAC 50/60 hertz. The PEP provides line filtering, transient suppression and a 20 amp circuit breaker.

SETUP FOR 240 VAC

Setting up the IIOIS20 for 240 VAC requires changing the switch setting on the DC power supply. The location of this switch is shown in Figure 4-31. The Intecolor and Aydin brand color monitors are autosensing and need no changes for 240 VAC operation, although monitors by other vendors may require changes.

CAUTION

Make sure that all labels on the power supply and the power entry panel are changed to show 240 VAC operation or equipment damage may result. Make sure main power breaker is off before changing operating voltage setting or equipment damage may result.

ATTENTION

Assurez-vous que toutes les étiquettes apposées sur le bloc d'alimentation et sur le panneau d'entrée de l'alimentation ont été modifiées pour correspondre au fonctionnement à 240 V c.a., sinon le matériel pourrait subir des dommages. Assurez-vous que le disjoncteur de l'alimentation principale est hors tension avant de modifier le réglage de la tension de service, sinon le matériel pourrait subir des dommages.

INSTALLATION

AC OUTLETS

There are four AC outlets on the IIOIS20 power entry panel. Three are located on the rear for color monitors and the power supply.

There are three AC outlets on the IIOIS20A power entry panel. Two are located on the rear for the power supply and an auxiliary device. Each AC outlet is rated for a maximum of 10 amps. The circuit breaker for the OIS is rated for a maximum of 20 amps.

NOTE: Do not connect motors, lights or test equipment to the AC outlets. Electrical noise may cause data to be lost or changed.

AC WIRING

The following steps outline the required procedure to install and power up the OIS. Observe and follow all related safety procedures when doing these steps (see Figure 3-9).

CAUTION

Do not plug modules or peripherals such as a tape drive or printer into the OIS with power applied. A current surge or voltage spike could damage sensitive components on the unit.

ATTENTION

Ne pas insérer les cartes ni les périphériques tels que les dérouleurs de bande et les imprimantes dans l'OIS lorsque ce dernier est sous tension. Les composantes de l'unité risquent d'être endommagées par les pointes de courant ou de tension.

NOTE: Before removing a module from the multi-bus card cage or doing maintenance on equipment containing static sensitive devices, read **HARDWARE SETUP ELECTROSTATIC DISCHARGE (ESD) CONTROL** in this section.

- 1 Turn off the breakers for the AC supply power and verify that no power is present to the OIS when making wiring connections.
- 2 Open the front door of the OIS cabinet. This provides access to the terminals needed for wiring to the INFI 90 communication highway and AC power.
- 3 Wire AC power to the terminals at the bottom front of the power entry panel.

NOTE: Verify that the incoming voltage is the same as the rating on the label of TB1 on the PEP.

The recommended minimum size for power wiring is 14 AWG copper wire with a 600 volt, 75 degree Celsius rating and thermoplastic insulation. Wire with a 300 volt or 150 volt rating may be used if it is accepted by local wiring codes.




Figure 3 9 IIOIS20 and IIOIS20A/D Power Entry Panel (PEP) AC Input Terminal

Wiring must be protected by cable trays or conduit and suited for the service voltage.

The power wiring to the OIS must include a third wire grounding conductor. This grounding conductor must not be a smaller gauge than the power wiring and must be either bare, green colored or green/yellow colored if insulated. The grounding conductor must be terminated at the system safety ground connection on the front of the power entry panel

Over-current protection provided for the AC distribution must be sized to allow for the inrush current required by the OIS hardware. Refer to Section 1 for the peak inrush current and duration for the OIS

For more information on power wiring and grounding, such as line conditioning, and EMI (electromagnetic interference), refer to the site planning, preparation and equipment installation manual

The power entry panel (PEP) and cable connector panel is located in the front of the cabinet in the bottom right corner. Connect 120/240 VAC at 50/60 hertz into the terminal block below the circuit breaker on the PEP. Refer to Section 4 of

INSTALLATION

this manual for information on wiring connections for the PEP. If other power is present, a compensating transformer is required.

NOTE If remote CRTs are being installed, be sure they are powered using the same polarized power and ground as the OIS to prevent ground loops. Failure to do so may cause display distortion on CRTs. If ground loops are suspected, use optically isolated modems to eliminate the problem.

4. Vibration during shipping and handling may unseat modules and connections, causing problems. Before applying power, do the AC and DC power up tests in Section 6 of this manual. Adjust the supplies as shown if necessary.

5. After AC wiring is complete, check the placement of modules in the multibus card cage. Compare module placement to Figure 4-1 and check the switch settings on the boards shown in Section 4.

6. Connect the Plant Loop or INFI NET communication link. Refer to **Multibus Communication Loop Module (IIMCLO1)** in Section 4 of this manual for further information.

7. After completing the wiring and checking the AC voltage sources, apply power. If problems occur, refer to the troubleshooting chart in Section 6 of this manual.

OIS peripherals (keyboards, printers, etc.) are connected to the cable connector panel. Refer to Section 4 of this manual for wiring connections for the PEP. If the installation calls for connecting a CRT touch screen, refer to **TOUCH SCREEN** in Section 5 of this manual.

IIOC201 PHYSICAL DESCRIPTION

The operator interface console (OIC 19 inch tabletop) has slotted openings that accommodate the air intake for the internal cooling system of the unit. Figure 3-10 shows the IIOC201 case dimensions.

IIOC201 SETUP AND PHYSICAL INSTALLATION

Before the OIC is set into place in a control room application, insure that the table is strong enough to support the CRT and OIC. Follow local wiring codes when wiring and installing cableways or conduit. For more information, refer to the site planning, preparation and equipment installation manual.




Figure 3 10. IIOIC201 Case Dimensions

IIOIC201 WIRING CONNECTIONS AND CABLING

A list of cables and their connections are in this section. IIOIC201 cable connections and the chassis connections are shown later in this section.

IIOIC202 PHYSICAL DESCRIPTION

The operator interface console has front and rear swing-out doors with individual locks. The lower front access door has slotted openings to accommodate the air intake for the internal cooling system of the unit. The unit has a stabilizer which must be fastened to the front of the cabinet when the IIOIC202 is not secured to the floor. The 6.4 centimeters (2.5 inches) diameter cable entry is located at the bottom right rear of the unit. The cabinet dimensions for the low, high or dual mounted CRTs are shown in Figure 3 11.

IIOIC202 SETUP AND PHYSICAL INSTALLATION

Before the OIC is set into place in a control room, insure that the floor is level in the area where the cabinets will be set. Adjust the leveling screws on all cabinets and connecting tables until the CRT bezel of each cabinet lines up. The leveling screws adjust 2.56 cm (1.05 inches). The locating dimensions for the leveling screws are shown on Figure 3 12.

INSTALLATION




Figure 3 11 IIOIC2021/2/3 Cabinet Dimensions

After the cabinets are fastened down, put the tables on the cabinets and lock them into place by pushing the red handle above the front access door to the right until it stops at the bottom of the slot

The tabletops are adjustable The brackets supporting the tabletops are bolted through oversize holes Loosen the three bolts on each table support bracket and move the top 0 25 inches up, down, forward or back toward the cabinet

There are two chrome table alignment pins shipped inside the brass bushings located on each side of each tabletop When two tabletops are lined up, push the pins outward into the bushing of the table to the right of the cabinet Tighten the six bolts on the support brackets Figure 3 13 shows the IIOIC202 keyboard table

Protect the wires and cabling going to the IIOIC202 cabinet Run cabling through conduit to the back of the cabinet or under the floor through the bottom of the cabinet Follow local wiring codes when wiring and installing cableways or conduit




Figure 3 12 IIIC201/2/3 Anchoring Dimensions




Figure 3 13. IIIC201/2/3 Keyboard Table

INSTALLATION

IIOIC203 PHYSICAL DESCRIPTION

The operator interface console environmental cabinet has a front and rear swing out door with individual locks. The front and back door seal in the air that is cooled by the unit's internal cooling system. The sealed cable entry is located at the back bottom unit. The cabinet dimensions are shown on Figure 3 14.




Figure 3 14 IIOIC203 Cabinet Dimensions

IIOIC203 SETUP AND PHYSICAL INSTALLATION

Before the OIC is set into place, insure that the floor is level in the area where the cabinet will be set. The unit must be secured to the floor before it is wired or operated. The dimensions for the mounting screws are shown in Figure 3 15.




Figure 3 15 I/OIC203 Anchoring Dimensions

Protect the wires and cabling going to the OIC environmental cabinet. Run cabling through conduit to the back of the cabinet or under the floor through the bottom of the cabinet. Follow local wiring codes when wiring and installing cableways or conduit. Refer to the site planning, preparation and equipment installation manual for more information.

I/OIC204 PHYSICAL DESCRIPTION

The operator interface console (CIC panel mounted) consists of a CRT, power entry panel, operator keyboard interface and operator keyboard.

I/OIC204 SETUP AND PHYSICAL INSTALLATION

Before the OIC is set into place in a control room, insure that the supporting panel is strong enough to support the CRT. Follow local wiring codes when wiring and installing cableways or conduit. For more information, refer to the site equipment installation manual. Figure 3 16 shows the CRT and keyboard interface panel cut out dimensions.

INSTALLATION




Figure 3 16 IIOIC204 Mounting Dimensions

IIOIC201 WIRING CONNECTIONS AND CABLING

For IIOIC201 wiring connections, refer to **IIOIC204 WIRING CONNECTIONS AND CABLING** in this section

IIOIC202 WIRING CONNECTIONS AND CABLING

The IIOIC202 is internally wired when it is shipped. Connect the AC power and any peripheral devices. Refer to Section 4 and Section 5 for specific instructions on installing and configuring peripheral devices and replacement components.

Table 3 3 contains the color codes for the wiring. Table 3 4 contains a list of cables and their connections. Figure 3 17 shows the cable connections.

Table 3 3 OIC Wiring Color Codes

Color	Function
Brown Blue Green/Yellow	AC Hot AC Neutral AC Common
Brown White/Green Violet	+5 VDC DC Common 12 VDC
White/Violet Green White	+12 VDC - Sense + Sense

Table 3 4. IIOIC202 Cable Connections

Cable No	Cable Name	Connect From	Connect To
6637599_1	AC Power	J1 on PEP	AC High on Main Power Supply AC Low on Main Power Supply Ground on Main Power Supply
1947950_1	AC Power	J2 on PEP	CRT1 AC Power Connector
1947950_5	AC Power	J3 on PEP	CRT2 AC Power Connector
6638709_1	PFI Sense	J1 on Power Supply	P3 of IIMKM01
6638719_1	Reset Cable	Reset Switch on PEP	P4 on IIMKM01
6638720_1	Lower CRT Bright	9 Pin Connector on Rear of CRT	CRT1 Bezel Brightness CRT1 Bezel Contrast Degaussing Switch on PEP
6638720_2	Upper CRT Bright	9 Pin Connector on Rear of CRT	CRT2 Bezel Brightness CRT2 Bezel Contrast Degaussing Switch on PEP
6637597_31200	Upper RGB Video	IIMGC01	RGB on CRT
NKMC01_xx	HGB Cable	Connector Panel HGB Cable on Host IIOIS20	HGB on CH1 of Slave IIOIC202
6638771	Power	P8 on DC Distribution Board	Cooling Fan
6634512_26N72	I/O Distribution	P5 on IIMKM01	P1 on Keyboard Interface Board
6634512_26N72	I/O Distribution	P6 on IIMKM01	Terminal Block on Rear of PEP
6638713_1	Peripheral Power	J2 on Keyboard Interface Board	P3 on DC Distribution Board on Main Power Supply
6638713_2	Peripheral Power	P1 on ADP Board	P4 on DC Distribution Board on Main Power Supply
6638849_1	ADP Signal	P7 on IIMKM01	P8 on Keyboard Interface Board P2 on ADP Panel
6638717_1	Power	J2 on Main Power Supply	P7 on DC Distribution Board on Main Power Supply
1948644_5	Touch Screen Extension	Touch Screen on Upper CRT	5 Pin Connector on Touch Screen Module
NKMR01_xx	Keyboard Data	P1 on Connector Panel on IIOIC202	P1 or P2 on PEP of host IIOIS20




Figure 3 17 IIOIC202 Cable Connections

AC POWER

IIOIC20 AC power input connects to a terminal block on the bottom front of the power entry panel. The IIOIC20 can operate from 120/240 VAC 50/60 hertz. The PEP provides line filtering, transient suppression and a 10 amp circuit breaker.

Setup for 240 VAC

Setting up the IIOIC202 for 240 VAC requires changing the switch setting on the DC power supply. The location of this switch is shown in Figure 4-31. The Intecolor and Aydin brand color monitors are autosensing and need no changes for 240 VAC operation, although monitors by other vendors may require changes.

CAUTION	<p>Make sure main power breaker is off before changing operating voltage setting or equipment damage may result.</p> <p>Make sure that all labels on the power supply and the power entry panel are changed to show 240 VAC operation or equipment damage may result.</p>
ATTENTION	<p>Assurez-vous que le disjoncteur de l'alimentation principale est hors tension avant de modifier le réglage de la tension de service, sinon le matériel pourrait subir des dommages.</p> <p>Assurez-vous que toutes les étiquettes apposées sur le bloc d'alimentation et sur le panneau d'entrée de l'alimentation ont été modifiées pour correspondre au fonctionnement à 240 V c.a., sinon le matériel pourrait subir des dommages.</p>

AC Outlets

There are three AC outlets on the OIC power entry panel. Two are located on the rear for color monitors and the power supply.

NOTE: Do not connect motors, lights, or test equipment to the AC outlets. Electrical noise may cause data to be lost or changed.

INSTALLATION

AC Wiring

The following steps outline the required procedure to install and power up the OIS. Observe and follow all related safety procedures when doing these steps (see Figure 3-18).

CAUTION

Do not plug modules or peripherals such as a tape drive or printer into the OIS with power applied. A current surge or voltage spike could damage sensitive components on the unit.

ATTENTION

Ne pas insérer les cartes ni les périphériques tels que les dérouleurs de bande et les imprimantes dans l'OIS lorsque ce dernier est sous tension. Les composantes de l'unité risquent d'être endommagées par les pointes de courant ou de tension.

NOTE: Before removing a module from the multi-bus card cage or performing maintenance on equipment containing static sensitive devices, read **HARDWARE SETUP ELECTROSTATIC DISCHARGE (ESD) CONTROL** in this section.

- 1 Turn off the breakers for the AC supply power and verify that no power is present to the OIC when making wiring connections.
- 2 Open the front door of the OIC cabinet. This provides access to the terminals needed for wiring to the INFI 90 communication highway and AC power.
- 3 Wire AC power to the terminals at the bottom front of the power entry panel.

NOTE: Verify that the incoming voltage is the same as the rating on the label of TB1 on the PEP.

The recommended minimum size for power wiring is 14 AWG copper wire with a 600 volts, 75 degree celsius rating and thermoplastic insulation. Wire with a 300 volt or 150 volt rating may be used if it is accepted by local wiring codes. Wiring must be protected by cable trays or conduit and suited for the service voltage.

The power wiring to the OIC must include a third wire grounding conductor. This grounding conductor must not be a smaller gauge than the power wiring and must be either bare, green colored or green/yellow colored if insulated. The grounding conductor must be terminated at the system safety ground connection.

Over current protection provided for the AC distribution must be sized to allow for the inrush current required by the OIC hardware. Refer to Section 1 for the peak inrush current and duration for the OIC.




Figure 3-18 I/OIC202 Power Entry Panel (PEP) AC Input Terminal

For more information on power wiring and grounding, such as line conditioning, and EMI (electromagnetic interference), refer to the site planning, preparation and equipment installation manual.

The power entry panel (PEP) and cable connector panel is located in the front of the cabinet in the bottom right corner. Connect 120/240 VAC at 50/60 hertz into the terminal block below the circuit breaker on the PEP. Refer to **I/OIS20 and I/OIC202 Power Entry Panel** in Section 4 of this manual for further information. If other power is present, a compensating transformer is required.

NOTE: If remote CRTs are being installed, be sure they are powered using the same polarized power and ground as the O/C to prevent ground loops. Failure to do so may cause display distortion. If ground loops are suspected, use optically isolated modems to eliminate the problem.

4. Vibration during shipping and handling may unseat modules and connections, causing problems. Before applying power, do the AC and DC power up tests in Section 6 of this manual. Adjust the supplies as shown if necessary.
5. After AC wiring is complete, check the placement of modules in the multibus card cage. Compare module placement to Figure 4-2 and check the switch settings on the boards with Section 4.

INSTALLATION

6 After completing the wiring, and checking the AC voltage sources, apply power. If problems occur, refer to the trouble shooting chart in Section 6 of this manual

OIC peripherals (keyboards, printers, etc) are connected to the cable connector panel Refer to **IIOIS20 and IIOIC202 Power Entry Panel** in Section 4 of this manual for wiring connections If the installation calls for a CRT touch screen, refer to **TOUCH SCREEN** in Section 5 of this manual

IIOIC203 WIRING CONNECTIONS AND CABLING

The IIOIC203 is internally wired when it is shipped Connect the AC power and any peripheral devices IIOIC203 AC power input connects to the power connector on the back of the case The PEP provides line filtering, transient suppression and a 20 amp circuit breaker

Table 3 3 contains the color codes for the wiring Table 3 5 contains a list of cables and their connections IIOIC203 cable connections are shown in Figure 3 19. Figure 3 20 shows the power entry panel connections

Table 3 5 IIOIC203 Cable Connections

Cable No.	Cable Name	Connect From	Connect To
6638709 1	PF Sense	J2 on Power Supply	P3 on IIMKM01
6638719 1	Reset Cable	Reset Switch on PEP	P4 on IIMKM01
NKMC01 xx	RGB	RGB on Connector Panel on Host IIOIS20	RGB on CRT Save IIO C202
Vendor	Power	AC Connector on PEP	AC Distribution Board
6634512 26^15	I/O Distribution	P5 on IIMKM01	P1 on Keyboard Interface Board
6638713_1	Peripheral Power	P2 on Keyboard Interface Board	P3 on DC Distribution Board
6638707 1	Power Cable	Terminal Block on Main Power Supply	Terminal Block on DC Distribution Board
NKMR01 xx	Keyboard Data	P1 on IIO C202 Connector Panel	P1 or P2 on PEP of Host IIO S20
6638713 1	Power	P16 on IIMKM01	P1 on DC Distribution Board
6638849_1	ADS Signal	P7 on IIMKM01	P8 on Keyboard Interface Board P2 on ADS Panel
6638713 4	ADP Power	P4 on DC Distribution Board	P1 on ADS Panel

Table 3 5. IIOIC203 Cable Connections (continued)

Cable No	Cable Name	Connect From	Connect To
6634512_26N38	Alarm Contacts	Terminal Block on PEP	P6 on IIMKM01
6639117_1	Keyboard Data	P1 on PEP (inside PEP)	P9 on IIMKM01
1947950_5	CRT Power	AC Input on CRT	AC Out on PEP




Figure 3-19. IIOIC203 Cable Connectors

INSTALLATION




Figure 3 20 IIOIC203 Power Entry Panel (PEP)

The IIOIC201/4 is internally wired when it is shipped. Connect the AC power and any peripheral devices. IIOIC201/4 AC power input connects to the power connector on the back of the case. The PEP provides line filtering, transient suppression and a 10 amp circuit breaker.

Table 3 3 contains the color codes for the wiring. Table 3 6 contains a list of cables and their connections. IIOIC201 cable connections are shown in Figure 3 21. IIOIC204 cable connections are shown in Figure 3 22. The chassis connections for the IIOIC201/4 are shown in Figure 3 23.

Table 3 6 IIOIC201/4 Cable Connections

Cable No	Cable Name	Connect From	Connect To
6638719_1	Reset Cable	Reset Switch on PEP	P4 on IMKM01
NKMC01	RGB	RGB Connector Panel on Host OS20	RGB on Slave CRT I OIC202
6639211 1	Power	TB Power Supply	Cooling Fan
6634512 26N72 O C204 on y	I/O Distribution	I/O DB Connector on Chassis	P1 on Keyboard I/O Interface Board
6639352 1	Peripheral Power	P2 on Keyboard Interface Board	P3 on IMKM01 Board
6639213 1 IIOIC201 only	Power	J2 on Main Power Supply	P7 on DC Distribution Board on Main Power Supply

Table 3 6. IIOIC201/4 Cable Connections (continued)

Cable No	Cable Name	Connect From	Connect To
NKMR01_xx	Keyboard Data	J1 on Rear of Base Unit	P1 or P2 on PEP of Host O S
6634512_26N72 OIC204 only	I/O Distribution	I/O DB Connector on Chassis	P8 on Keyboard Interface Board
6638705_1 O C204 only	I/O Distribution	P5 on IMKM01	I/O DB Connector on Chassis
6638705_1 OIC204 on y	ADS Signal	P7 on IMKM01	ADS DB Connector on Chassis
6639525_1 OIC204 only	Power	TBI on Power Supply	Keyboard Power Connector on Chassis P16 on MKM01
6639352_1 OIC204 only	Power	P2 on Remote Keyboard Interface Board	Keyboard Power Connector on Chassis
1947950_5 OIC204 on y	CRT Power	AC In on CRT	J2 on Chassis
6639117_1	Keyboard Data	J1 on Chassis	P9 on IIMKM01
6639211_1 OIC201 only	Power	TB on Power Supply	Fan P2 on Keyboard Interface Board P16 on IMKM01
6639212_1 O C201 on y	AC Power	AC High AC Low AC Ground	Power n on Chassis AC In on CRT
6639213_2	Power	J2 on Power Supply	P3 on IMKM01
6634512_26N15	Alarm Contacts	Terminal Block on Chassis	P6 on IIMKM01
6634512_26N15 OIC201 only	Alarm Contacts	P1 on Keyboard Interface Board	P5 on IMKM01
6634512_26N15 O C201 on y	I/O Distribution	Terminal Block on Chassis	P7 on IMKM01

INSTALLATION




Figure 3 21 IIOIC201 Cable Connections




Figure 3 22 I/OIC204 Cable Connections

INSTALLATION




Figure 3 23. IIOIC201/4 Chassis Connections

AC POWER

After completing all other OIS and OIC connections connect the AC to the power entry panel. Follow all national and local codes. See the figures in this section for the location of the AC connections for the unit being installed. Figure 3 24 shows the AC wiring inside the power entry panel for the IIOIS20, IIOIS20A/D and IIOIC202. The IIOIC203 is similar except that it has a transformer and switch for 120 VAC/240 VAC for the air conditioner. IIOIC201/4 have different internal AC wiring.

NOTE 120 volt outlet assignments may be different for different OIS and OIC models.

PREOPERATING ADJUSTMENTS

Each OIS/OIC is powered up and tested before shipment. All necessary power supply adjustments, CRT and touch screen alignments, and jumper connections have been made. Install the OIS/OIC by following the instructions in this section.

- Set it into place according to the site preparation manual
- Connect the incoming AC, equipment ground
- Connect the loop connections (OIS only)
- Connect the OIC to the OIS (OIC only)
- Check connections
- Check that doors are in place and locked to assure proper cooling

Refer to the troubleshooting steps in Section 5 to correct any problems.




Figure 3 24. IIOIS20, IIOIS20A/D and IIOIC202 Power Entry Panel AC Wiring

INSTALLATION

SOFTWARE UPGRADE

This section contains information required to install software release E.2 onto an IIOIS20 console. These procedures are grouped into two categories:

- Upgrading a software release B.1 console to a software release E.2 OIS console
- General software release E.2 maintenance procedures

These procedures assume that the installer is familiar with the operation and basic troubleshooting of the console.

Console upgrade procedures use command files and file conversion utilities designed to upgrade software to a later release. Using upgrade procedures for any other purpose may cause the system to operate erratically. Use the procedures in this section only if a console is being upgraded from software release B.1 to software release E.2.

Procedures for loading and restoring software as a part of routine maintenance can be found in **SOFTWARE RELEASE E.2 MAINTENANCE**. This section contains procedures to load the software onto a new installation, save the tag database and system configuration and load software. It also contains procedures to reload an existing configuration and software.

General Notes Save an existing configuration before loading new software.

If hard errors are encountered by the disk system (9100, 9300, 9400, etc.) during the load process, the hard disk will have to be reformatted. Bad track mapping must be done. A new load can be used to upgrade the machine to software release E.2. If errors persist, check the disk system hardware including the cables. The hard disk may need reprogramming.

E.2 Notes Use the set time and date function to establish GMT (Greenwich mean time), the first time the console started. See the operation and configuration manual for an explanation.

DEVSTAT tags must be defined for all printers.

Before upgrading the OIS console, verify the module firmware with Table 3.7. After the firmware is verified, follow the procedures in this section.

SOFTWARE RELEASE E.2

Follow the procedures in this section when upgrading software release B.1 to software release E.2.

Software release E.2 may be installed as an upgrade to an existing console running B.1 software. There are two load procedures for upgrading a console running B.1 software.

Table 3-7. Firmware Requirements for Software Release E.2

Board Type	ID Number	Part Number	Revision
IIMGC01	238	A2	15
	239	A41	15
	240	A1	15
	A41	A40	15
MKM01	U4	1900212C10	C 0
IIMLM01	U2	1900165E11	E 1
IIMPM01	U49	1900214B12	B 2
	U19	1900214B22	B 2
IIMSM01	IC31 Vendor ID No 240028 DRV	N/A	V1 010 V1 010 V1 010
IPST01 (P ant Loop)	U23	1900208B10	B 0
	U24	1900208B10	B 0
I ST01 (INFI-NET)	U23	1900207E11	E 1
	U24	1900207E11	E 1
Touch screen	E2/1-15U	N/A	N/A

NOTE: N/A = not applicable

The full load procedure initializes the hard disk. It is recommended to unfragment the disk before installing software. This procedure saves B.1 tag database and system configuration, initializes the hard disk and loads E.2 software onto the console.

The partial load procedure upgrades from B.1 software. It saves the current B.1 tag database and system configuration. It also upgrades the tag database and system configuration, and loads E.2 system software.

Full Load OIS B.1 to OIS E.2

This procedure saves software release E.2 tag database and system configuration, initializes the hard disk, and loads software release E.2. To install the software with a full load procedure:

- 1 Start the utility program from the SYS6 floppy disk. Refer to **Starting Off-Line Utility**.
- 2 If necessary, log in. Refer to **Logging into Off-Line Utility**.
- 3 At the DDT terminal, type

```
0 00> FD01
```

INSTALLATION

- 4 Save site specific configurations from the console where software release E.2 will be installed Refer to **SAVING SITE SPECIFIC CONFIGURATIONS**.
- 5 Insert SYS5 system floppy disk into the floppy drive
- 6 Enter the appropriate full load command from Table 3 8

Table 3 8. B.1 Full Load Configuration Files

Tag Range	Command File	Formatted Disks Required	Number of Disks
0000-2500	FULL25B1 CN	B1C1 UCF2, UCF6	3
2501 5000	FULL50B1 CN	B1C1, UCF2, UCF3 UCF6	4

For example, to full load a console for 0 to 2,500 tags, type

```
1 00> INT . FULL25B1.CN
```

- 7 Change disks when prompted
- 8 When the load procedure completes, reset the console The console is functional and ready for configuration
9. Restore the B.1 configuration Refer to **Restore OIS B.1 Files**
10. Install the site specific configuration Refer to **RESTORING SITE SPECIFIC CONFIGURATIONS**

Partial Load OIS B.1 to OIS E.2

This procedure saves the tag database and system configuration, then loads software release E.2 system software To install the software with a partial load procedure:

- 1 Start the utility program from the SYS6 floppy disk Refer to **Starting Off Line Utility**
- 2 If necessary log in Refer to **Logging into Off-Line Utility**
- 3 At the DDT terminal, type:

```
0 00> FD01
```

- 4 Save site specific configurations from the console where software will be installed Refer to **SAVING SITE SPECIFIC CONFIGURATIONS**
- 5 Insert SYS5 system floppy disk into the floppy drive

6 Enter the appropriate partial load command from Table 3 9

This automatically runs the general conversion program and **TRCONE2.CN** If needed, run conversions for user created configurations

Table 3 9. B.1 Partial Load Configuration Files

Tag Range	Command File	Formatted Disks Required	Number of Disks
0000-2500	PART25B1 CN	B1C1, UCF2, UCF6	3
2501-5000	PART50B1 CN	B1C1, UCF2, UCF3, UCF6	4

For example, to partial load a console for 0 to 2,500 tags, type

```
1.00> INT . PART25B1.CN
```

7. Change disks when prompted

8. When the load procedure completes, reset the console. The console is functional

SOFTWARE RELEASE E.2 MAINTENANCE

This section contains three procedures for loading software release E 2 onto a console They are, new load, full load and reload. The reload procedure assumes that the console is currently running software release E 2.

The **New Load Procedure** is used for systems that are new This procedure initializes the hard disk, loads a default (blank) configuration and loads the software.

The **Full Load Procedure** starts by saving the tag database and system configuration Any specific configurations must be saved before running this procedure This procedure initializes the hard disk, loads a default (blank) configuration, then loads software release E 2

The **Reload Procedure** is a development utility rather than a maintenance utility It is used to reload an existing system with updated software The reload procedure should **not** be used to update from one major release revision to another such as from software release B 1 to software release E.2

INSTALLATION

New Load Procedure

This procedure initializes the hard disk, loads software release E 2 system software, then loads a default (blank) configuration To install the software with a new load procedure

- 1 Start the utility program from the SYS6 floppy disk Refer to **Starting Off-Line Utility**
- 2 If necessary log in Refer to **Logging into Off-Line Utility**
- 3 At the DDT terminal, type

0 00> FD01
- 4 Insert SYS5 system floppy disk into the floppy drive
- 5 Enter the appropriate new load command from Table 3 10

Table 3 10. New Load Command Files

Tag Range	Command File
0000 2500	NEW25 CN
2501 5000	NEW50 CN

For example, to new load a console for 0 to 2,500 tags, type

1 00> INT . NEW25.CN

- 6 Change disks when prompted.
- 7 When the load procedure completes, reset the console. The console is functional and ready for configuration

Full Load Procedure

This procedure will save software release E.2 tag database and system configuration, initialize the hard disk and load software release E 2 onto the console To install the software with a full load procedure

- 1 Start the utility program from the SYS6 floppy disk Refer to **Starting Off-Line Utility**
- 2 If necessary log in Refer to **Logging into Off-Line Utility**
- 3 At the DDT terminal, type

✓ 0 00> FD01

- 4 Save site specific configurations from the console where software release E.2 will be installed Refer to **SAVING SITE SPECIFIC CONFIGURATIONS**
- 5 Insert SYS5 system floppy disk into the floppy drive.
- 6 Enter the appropriate full load command from Table 3-11

Table 3-11. Full Load Configuration Files

Tag Range	Command File	Formatted Disks Required	Number of Disks
0000 2500	FULL25E2.CN	E2C1, UCF2 UCF6	3
2501-5000	FULL50E2.CN	E2C1, UCF2 UCF3, UCF6	4

For example, to full load a console for 0 to 2,500 tags, type.

```
✓ 1 00> INT . FULL25E2.CN
```

- 7 Change disks when prompted

NOTE When prompted, record the arm descriptor file size that is needed to restore the configuration

8. When the load procedure completes, reset the console. The console is functional and ready for loading configurations
9. Restore the E.2 tag database and system configuration, refer to **Restoring a Tag Database**.
- 10 Install the site specific configurations Refer to **RESTORING SITE SPECIFIC CONFIGURATIONS**

Reload Procedure

The reload procedure expects the system to be loaded with software release E.2 configuration. It only loads system software and relevant system configuration updates to the machine.

1. Start the utility program from the SYS6 floppy disk Refer to **Starting Off-Line Utility**
2. Remove SYS6 disk and insert SYS5 disk
3. If necessary log in Refer to **Logging into Off-Line Utility**.
4. At the DDT terminal, type

```
0 00> FD01
```

INSTALLATION

- 5 At the DDT terminal, type

```
1.00> INT . RELOAD.CN
```
- 6 Change disks when prompted
- 7 When the load procedure completes, reset the console
 The console is operational

RESTORING B.1 CONFIGURATIONS AND FILES

There are two procedures in this section. The procedures restore the tag database and site specific files from a console with software release B 1 Refer to **Restore OIS B.1 Configurations**

Restore OIS B.1 Configurations

This procedure explains how to use the off line utility to restore a B 1 configuration onto a console upgraded with the E 2 software To restore the B.1 configuration to a console with software release E 2

- 1 Refer to **USING THE UTILITY** for information on loading the utility
- 2 Start the utility program from the hard disk drive Refer to **Starting Off-Line Utility**
- 3 Log in to the console Refer to **Logging into Off-Line Utility**
- 4 Use the **Restore OIS B.1 Files** procedure to restore the tag database
- 5 Use the **RESTORING SITE SPECIFIC CONFIGURATIONS** procedure to restore the site specific configurations (displays, trend data, log reports, etc)
- 6 Use the **MANDATORY CONVERSIONS** procedure to convert the configurations from software release B 1 to E 2 files The B 1 to E.2 conversion command automatically runs the general conversion program If needed, run conversions for site specific created configurations

Restore OIS B.1 Files

This procedure explains how to use the off line utility to restore the tag database and system configuration To restore system and tag database from software release B 1

- 1 Start the utility program from the hard drive Refer to **Starting Off-Line Utility**

- 2 If necessary, log in Refer to **Logging into Off-Line Utility**
- 3 At the DDT terminal, type

```
0 00> FD00 FF
```
- 4 Enter the appropriate command from Table 3 12

This automatically runs the general conversion program If needed, run conversions for site specific created configurations Refer to **MANDATORY CONVERSIONS**

Table 3 12. B.1 to E 2 Configuration Files

Tag Range	Command File	Formatted Disks Required	Number of Disks
0000-2500	B1E2-25 CN	B1C1, UCF2, UCF6	3
2501-5000	B1E2 50 CN	B1C1, UCF2, UCF3, UCF6	4

For example, to restore a console with 0 to 2,500 tags, type

```
0.FF> INT . B1E2-25.CN
```

- 5 Change disks when prompted
6. When the configuration is restored and mandatory conversions are run, reset the console The console is functional and ready for loading site specific configurations

SAVING AND RESTORING AN E.2 TAG DATABASE

This section contains two procedures The first one saves the tag database and system configuration. The second procedure restores the tag database and system configuration.

Saving a tag database describes how to save the current software configuration The configuration can be saved at any time Save the configuration after a load, restore or when conversions are done. Before saving, verify that all conversions have been completed and the console is running properly. To restore additional saved files refer to **RESTORING SITE SPECIFIC CONFIGURATIONS**

Saving the configuration requires formatted floppy disks. They are E2C1 and UCF2 through UCF6. The number of

INSTALLATION

disks needed depends on the tag range of the system E2C1 and UCF6 are common to all systems

NOTE: It may be necessary to install a new version of the **SVCFG.CN** and **LDCFG.CN** files on the hard drive if the number of tags on this console has been changed since the last software installation. This is only a concern if the new tag count falls into a different 2,500 tag range than when loading the previous software revision. Refer to **SVCFG.CN AND LDCFG.CN** for an explanation.

Restoring a Tag Database restores the software release E 2 tag database and system configuration saved on E2C1 and UCF2 through UCF6 disks. To restore additional saved files refer to **RESTORING SITE SPECIFIC CONFIGURATIONS**

Saving a Tag Database

This section describes how to use the off line utility to save the tag database. To save a tag database:

- 1 Start the utility program from the hard disk. Refer to **Starting Off-Line Utility**
- 2 If necessary log in. Refer to **Logging into Off Line Utility**
- 3 At the DDT terminal, type.

```
0 00> FD00 FF
```

- 4 Enter the appropriate save command from Table 3-13.

Table 3 13. Saving E.2 Tag Database and System Configuration Files

Tag Range	Command File	Formatted Disks Required	Number of Disks
0000-5000	CP01CFE2.CN	E2C1, UCF2, UCF4, UCF5, UCF6	5

For example, to save the tag database for a console with 0 to 2,500 tags, type

```
1 00> INT . CP01CFE2.CN
```

- 5 Change disks when prompted.

NOTE: When prompted, be sure to record **ALMDESC.CF** file size. Refer to **ALMDESC.CF FILE**

Restoring a Tag Database

This section describes how to use the off line utility to restore the tag database To restore a tag database

1. Start the utility program from the hard disk Refer to **Starting Off-Line Utility**
2. If necessary log in. Refer to **Logging into Off-Line Utility**
3. At the DDT terminal, type

```
0 00> FD00 FF
```

4. Enter the appropriate restore command from Table 3 14

Table 3 14. Restoring E.2 Tag and System Command Files

Tag Range	Command File	Formatted Disks Required	Number of Disks
0000 5000	CP10CFE2 CN	E2C1, UCF2, UCF4 UCF5, UCF6	5

For example, to restore the tag database for a console with 0 to 2,500 tags, type

```
0.FF> INT . CP10CFE2.CN
```

5. Change disks when prompted.
6. Restore the alarm descriptor file Refer to **ALMDESC.CF FILE**

SAVING SITE SPECIFIC CONFIGURATIONS

This section describes how to save site specific displays, trend data files, sequence of events logs, etc The configuration can be saved at any time Save the configuration periodically to maintain a current backup

NOTE: Be sure to have plenty of blank, formatted and initialized disks ready The number of disks required varies between installations Be sure to label the disks in the order they are saved It is important that they be restored in the same order

Saving Software Release E.2 User Displays

User display files consist of **DT**, **DL**, **DU** and **CF** (**CF** files are in directory USN 0.53) files and each should be saved

NOTE: If user created **DT** files must reside on the hard disk, they should be stored in directory USN 0.55 Any user created **DT** files not in directory USN 0.55 will not be saved

INSTALLATION**Saving DT Files** To save **DT** files

1. Put a floppy disk into the floppy drive
2. At the DDT terminal, type
`0.00> COPY 0.55:*.DT 1.55:`
3. Put in a new floppy disk when a disk full message is displayed and enter **R** for retry to continue

Saving DL Files To save **DL** files

1. Put a floppy disk into the floppy drive
2. At the DDT terminal, type
`0.00> COPY 0.44-4E:*.DL 1.*:`
3. Put in a new floppy disk when a disk full message is displayed and enter **R** for retry to continue

Saving DU Files To save **DU** files

1. Put a floppy disk into the floppy drive
2. At the DDT terminal, type
`0.00> COPY 0.04-0E:*.DU 1.*:`
3. Put in a new floppy disk when a disk full message is displayed and enter **R** for retry to continue

Saving CF Files To save **CF** files

1. Put a floppy disk into the floppy drive
2. At the DDT terminal, type
`0 00> COPY 0.53:*.CF 1:`
3. Put in a new floppy disk when a disk full message is displayed and enter **R** for retry to continue

Saving Trend Data Files

Trend data files will automatically be created at start up if they are not present. Save the trend files only to keep the data. Note that the format of trend data files changed at software release E.2. Be sure that **TRCONV.CN** was used to

convert any trend data files from previous releases prior to starting this console

NOTE: Starting this console with trend data files from a previous release can cause unpredictable results. Software release E 2 trend data files may not be used on a console running a previous release

The trend data files reside in directories numbered from USN 0 14 to USN 0.2B (hexadecimal) inclusive. Trend data file names are formatted this way:

T000xxxx TR

Where *xxxx* is defined as a trend index number (range 0001-1000)

Note the difference between the names of trend data files in software release E 2 and previous releases. Previously, trend files were named *Txxxx TR* where *xxxx* is defined as a trend index number (range 0001-1000)

To back up the trend data files.

- 1 Put a floppy disk into the floppy drive
- 2 At the DDT terminal, type

0 00> COPY 0.14-2B:*.TR 1.*:

- 3 Put in a new floppy disk when a disk full message is displayed and enter **R** for retry to continue

Be sure to label the disks and number them in the order that they were saved. It is important that they be restored in the same sequence

NOTE Due to a change in DDT, the trend files will be stored in directories USN 1 14-2B by using the above command. **Do not assume** the disk is blank with no files just because it does not contain any files in directory USN 1 00

Saving Log Report Definition and Retention Files

This section contains procedures to save log report definition, log retention files and the log data files. Several floppy disks may be required to complete the save. Be sure to have enough formatted, initialized, blank disks on hand

INSTALLATION

Log Report Definition The log report definition files reside in directories numbered from USN 0 2C to USN 0.34 (hexadecimal) inclusive. Log definition file names are formatted in this way:

LOG0xxx.LF

Where xxx is defined as a log index number from 001 to 100 (note the leading zero)

To back up the log definition files

- 1 Put a floppy disk into the floppy drive
- 2 At the DDT terminal, type:

0 00> COPY 0.2C-34:*.LF 1.*:

- 3 Put in a new floppy disk when a disk full message is displayed and enter **R** for retry to continue

Be sure to have enough formatted, initialized, blank disks on hand. Label each disk for software release E.2

Be sure to label the disks and number them in the order that they were saved. It is important that they be restored in the same sequence.

NOTE Due to a change in the DDT terminal, the log files will be stored in directories USN 1 2C to USN 0 34 by using the above command. **Do not assume** the disk s b ank with no f es just be cause i does not contain any files in d rectory USN 1 00

Log Retention Files Log retentions are in directories USN 0 35 to USN 0.3D (hexadecimal). The file and log data file names are the same but the extension becomes **.L0, .L1, .L2, ..., .L8** for up to nine retentions.

To back up the log retention files

- 1 Put a floppy disk into the floppy drive
- 2 At the DDT terminal, type:

0.00> COPY 0.35-3D:*.L? 1.*:

- 3 Put in a new floppy disk when a disk full message is displayed and enter **R** for retry to continue.

Be sure to have enough formatted, initialized, blank disks on hand. Label the disks and number them in the order that

they were saved. It is important that they be restored in the same sequence

NOTE Due to a change in the DDT terminal the log files were stored in directories USN 135 to USN 03D by using the above command. **Do not assume** the disk subsystem with no files just because it does not contain any files in directory USN 100

Log Data Files In software release E.2, the log data files (in USN 041) should be backed up. Save these files for the logging task to be able to continue data collection where it ended

To back up the log data files

1. Put a floppy disk into the floppy drive
2. At the DDT terminal, type.

```
0.00> COPY 0.41:*TM 1.*:
```

3. Put in a new floppy disk when a disk full message is displayed and enter **R** for retry to continue

Be sure to label the disks and number them in the order that they were saved. It is important that they be restored in the same sequence.

Any logs which were completed but not yet processed for output, retention, or archival (.Bn files in USN 041) will be lost when system is upgraded to software release E 2

Saving Sequence of Events Log Configuration Files

Sequence of events log configuration files are stored in directory USN 0.02.

To back up the sequence of events log files:

1. Put a floppy disk into the floppy drive
2. At the DDT terminal, type

```
0.00> COPY 0.2:SERDEF* 1*
```

3. Put in a new floppy disk when a disk full message is displayed and enter **R** for retry to continue.

Be sure to label the disks and number them in the order that they were saved. It is important that they be restored in the same sequence.

INSTALLATION

Saving Trend Pen Files

Trend pen files are stored in directory USN 0 02

To back up the trend pen files

1 Put a floppy disk into the floppy drive

2 At the DDT terminal, type

```
0 00> COPY 0.2:TPC* 1:
```

```
0.00> COPY 0.2:PIO* 1:
```

3 Put in a new floppy disk when a disk full message is displayed and enter **R** for retry to continue

Be sure to label the disks and number them in the order that they were saved. It is important that they be restored in the same sequence.

RESTORING SITE SPECIFIC CONFIGURATIONS

This section describes how to restore the additional saved files. The saved files are display files, trend data files, log definition files, log data files, sequence of events log files and trend pen files.

NOTE: Be sure to have plenty of blank, formatted and initialized disks ready. The number of disks required varies between installations. Be sure to label the disks in the order they are saved. It is important that they be restored in the same order.

Restoring User Display Files

User display files consist of **DT**, **DL**, **DU** and **CF** (**CF** files are in directory USN 0 53) files. This procedure is only valid for display files saved from a console which is at revision B 1 or greater.

Restoring DT Files To restore **DT** files

1 Put each **DT** floppy disk into the floppy drive

2 At the DDT terminal, type.

```
0 00> COPY 1.55:*.DT 0.55:
```

Restoring DL Files To restore **DL** files:

1 Put each **DL** floppy disk into the floppy drive

2 At the DDT terminal, type

```
0 00> COPY 1.44-4E*.DL 0.*:
```

Restoring DU Files To restore *DU* files.

1 Put each *DU* floppy disk into the floppy drive

2 At the DDT terminal, type

```
0 00> COPY 1.4-E:*DU 0.*:
```

Restoring CF Files To restore *CF* files:

1. Put each *CF* floppy disk into the floppy drive

2 At the DDT terminal, type

```
0 00> COPY 1:*CF 0.53:
```

Restoring Trend Data Files

When the load process completes, these files can be restored to recreate the same environment. This is the only time these files should be restored. To restore the trend data files, enter this command from the DDT terminal.

```
0 00> COPY 1.14-2B:*TR 0.*:
```

Restoring Logging Files

To restore the log definition files, enter this command for each log definition disk:

```
0 00> COPY 1.2C-34:*LF 0.*:
```

To restore the log retention files, enter this command for each log retention disk:

```
0 00> COPY 1.35-3D:*L? 0.*:
```

Restoring Sequence of Events Log Files

To restore the sequence of events log files, enter this command for each disk:

```
0 00> COPY 1:SERDEF* 0.02:
```

Restoring Trend Pen Files

To restore the trend pen files, enter these commands for each trend pen disk:

```
0 00> COPY 1:TPC* 0.02:
```

```
0 00> COPY 1:PIO* 0.02:
```

INSTALLATION

USING THE UTILITY

Use the off line utility provided and the DDT terminal to down load the configuration and load and save command files

Monitor 68K Terminal

A monitor 68K terminal is used to define configurations and load files. Several of the instructions in this section will discuss input to and output from the monitor 68K terminal. In further discussion, this will be named the 68K terminal.

The primary purpose of the 68K terminal, when installing software, is to load and start the off line utility program. The 68K terminal also outputs information and diagnostic messages at system startup and during operation.

DDT Terminal

The DDT terminal is the interface to the off line utility and on line utility programs. The DDT terminal is connected to serial I/O port eight. To install software, the DDT terminal is used in its off line mode to:

- Run console command files which load the system
- Provide prompts indicating that a particular floppy disk must be loaded in the floppy disk drive
- Prompt the user prior to initializing the floppy or hard drive
- Load and save tag database and site specific files

Procedures for other operations on the DDT terminal using the off line and on-line utility programs are described in the operation and configuration manual.

Starting Off-Line Utility

To load and start the off line utility program, (utility for short)

1. Connect the DDT terminal to the MON 68 port
2. Reset the console
3. Wait for the system restart message on the 68K terminal. It should read:

*SYSTEM RESTARTED
 ENTER MONITOR BY PRESSING <RETURN>
 OTHERWISE MTOS AUTOLOAD WILL OCCUR IN 7 SECONDS*

*BCCo 68020 MONITOR REV B 1 JUL, 1991
 Processor ID: 1*

INSTALLATION

Press **Return** at the 68K terminal to prevent autoloading from continuing. The prompt `I:>` will be displayed

4 At this point, the utility program can be started from either a floppy disk or from the hard disk. To start the utility program from the hard disk (device 0), at the 68K terminal type

`I:> LF 1000 UTILITY.OB 0`

`I:> MT`

A start-up message will be displayed on the DDT terminal

The DDT terminal displays this message

BCCo. OIS Diagnostic/Debug Terminal.

NOTE: UTILITY OB is normally stored on the SYS6 disk

To start the utility program from the floppy disk (device 1), type

`I:> LF 1000 UTILITY.OB 1`

`I:> MT`

5 Enter the month, day, year and hour, minute, second at the prompt

id date [DD MMM-YYYY

us message.

ug Terminal

sed as both 68K terminal and DDT
cab e between ports Remember to
d ng the cab e

repeat the nstruct on to start up the
) be oaded aga n once t s started

ie password security function,
d procedures that are run from
re protected To perform these
rninal with a security mainte
rence that requires a log in will
ection.

MEMORANDUM



Referred To _____

Location _____

- Per Your Request
- Per Your Conversation
- For Your Information
- For Your Approval
- For Handling
- For Your File
- For Distribution
- For Discussion
- For Your Comments
- For Follow Up
- For Your Signature
- Please Return

Remarks

560
221-6337

10610379596AD0001000C0089

Date _____ From _____

TP MEMO

INSTALLATION

MAINT is the security maintenance password configured in the default security configuration. If password security has been reconfigured, the new maintenance password should be used. The password is hidden as it is typed in. The message *Hello User* is displayed when the log in is successful.

NOTE. It is important that the password security configuration always contain at least one user ID and password which is configured as the default MAINT.

The default MAINT has:

Region access	System
Access rights	Monitor
	Security maintenance
	Diagnostic debugging terminal

This combination of region access and access rights are necessary to permit security configuration and loading the next software revision.

This example shows how to log in at the utility terminal. Type

```
0 00> LOGIN
          Enter Password: (type MAINT)
          Hello
0 00>
```

MANDATORY CONVERSIONS

This section describes file conversions required whenever a previous configuration or any off line generated configuration is loaded to a software release E.2 system.

Explanation of Conversions

There are three procedures which must be performed when the console configuration is loaded onto a software release E.2 console. This section describes those procedures and demonstrates how they should be run.

CONVB1.CN **CONVB1.CN** is the command file which performs the general software release E.2 conversion. It should be run any time any new log configuration is loaded onto the console.

CONVB1.CN will skip converting a configuration which has already been converted. It can be run multiple times with the same configuration. Therefore, if there is a doubt that this conversion has been performed or should be performed, do it.

CONVB1.CN is primarily intended to convert the tag database to the format and content required for the current revision. It

will also convert site specific configuration files depending on the requirements of the software release

To convert files from B.1

1 Start the utility program from the hard disk Refer to **Starting Off-Line Utility**

2 At the DDT terminal, if necessary log in Refer to **Logging into Off-Line Utility**

3. Type:

```
0.00> FD00 FF
```

4 Type.

```
0 FF> INT . CONVB1.CN
```

NOTE: To run the **CONVE2.SP** converts on program when the **RUN** command is used, the program parameters now have to be passed

```
Format 0 00> RUN CONVE2.SP B1 E2
```

This command file prompts for the keyboard type of each keyboard which is configured. This could be useful if the system is configured for the wrong type of keyboards. Misconfigured keyboards will not communicate with the console

TRCONV.CN **TRCONV.CN** must be run to convert files used by the trend subsystem to a new format and content Like **CONVB1.CN**, **TRCONV.CN** should be run anytime a new trend configuration is loaded onto the console This includes configuration from previous releases and from SLDG programs. It can be run repeatedly with the same configuration in case there is a doubt that it was run.

Note that **TRCONV.CN** expects that **CONVB1.CN** has already been run successfully For example, to convert files from B.1

1 Start the utility program from the hard disk Refer to **Starting Off-Line Utility**.

2 At the DDT terminal, if necessary log in. Refer to **Logging into Off-Line Utility**

3 Type.

```
0.00> FD00 FF
```

4. Type:

```
0 FF> INT . TRCONV.CN
```

INSTALLATION

Log Configuration Files

NOTE Logs loaded onto the console may be active or inactive. Inactive logs are automatically converted when they are activated. Active logs are not automatically converted. The conversion utility converts both inactive and active logs. It is recommended to run the conversion utility whenever a SLDG generated log configuration files loaded.

- 1 Start the utility program from the hard disk. Refer to **Starting Off-Line Utility**.
2. At the DDT terminal, if necessary log in. Refer to **Logging into Off-Line Utility**.
- 3 Type


```
0.00> FD00 FF
```
- 4 To start the log conversion utility type


```
0.FF> INT . CONV1.CN
```

Configurable Text File Conversion

This procedure may be required after a load process. All software load procedures overwrite the previous version of the configurable text files on the hard disk with the default configurable text files.

This procedure is required if text substitutions were made at anytime in the past, before the system was running software release E.2. It requires the B.1 disks made during the upgrade and the software release E.2 CFG2 disk.

- 1 Start the utility program from the hard disk. Refer to **Starting Off-Line Utility**.
- 2 At the DDT terminal, if necessary log in. Refer to **Logging into Off-Line Utility**.
- 3 Type


```
0 00> FD00 FF
```
- 4 To start the configurable text file conversion utility, type:


```
0 FF> INT . CTCONV.CN
```
- 5 Insert and change disks when prompted.
- 6 The program will prompt


```
Enter Source Release Number (K1/L1 ...)
```


Enter **B1**

7. The program will prompt:

Enter Target Release Number (L1/M1...)

8. Type **E2**

SVCFG.CN AND LDCFG.CN

Some of the load procedures expect to find copies of file **SVCFG.CN** and **LDCFG.CN** residing in the USN 0.FF directory at the time of the software installation. **SVCFG.CN** is placed in USN 0.FF when installing system software. **SVCFG.CN** is a copy of **SVCFG25.CN** or **SVCFG50.CN**. It saves the user database. Similarly, **LDCFG.CN** is in USN 0.FF to restore a database.

Create a new copy of **SVCFG.CN** to use a load procedure for a different tag range than the procedure used previously. The new copy can be made from the SYS5 disk of the new software. Table 3-15 contains information used in the examples.

Table 3 15. *SVCFG.CN Files*

Tag Range	SVCFG.CN on Hard Drive is a Copy of	LDCFG.CN on Hard Drive is a Copy of
2500	SVCFG25.CN	LDCFG25.CN
5000	SVCFG50.CN	LDCFG50.CN

The **LDCFG.CN** and **SVCFG.CN** are database related utilities used as subroutines of other command files. They are created during the initial system load process to accommodate the database size specified at that time. If the size of the database is changed after the initial system load, the **LDCFG.CN** and **SVCFG.CN** files must be modified to show the change. These two examples explain how to modify those files for any database size change that may be made. Proceed with the software upgrade after doing this.

Example 1 The console had a 2,500 tag database that was increased to a 5,000 tag database. Enter these commands from the DDT terminal.

0.00> COPY 0.FF:LDCFG50.CN 0.FF:LDCFG.CN

0.00> COPY 0.FF:SVCFG50.CN 0.FF:SVCFG.CN

INSTALLATION

Example 2 The console had a 5,000 tag database that was reduced to a 2,500 tag database. Enter these commands from the DDT terminal:

```
0 00> COPY 0.FF:LDCFG25.CN 0.FF:LDCFG.CN
```

```
0 00> COPY 0.FF:SVCFG25.CN 0.FF:SVCFG.CN
```

ALMDESC.CF FILE

The size of the alarm descriptor file (**ALMDESC.CF** file) needs to be recorded for it to be reloaded. Follow the procedures in this section to reload the alarm descriptor file.

The file size of **ALMDESC.CF** is no longer a strict relation to the number of tags in the console database. The **ALMDESC1.CF** file will be saved to UCF4 and **ALMDESC2.CF** will be saved to UCF5. **ALMDESC1.CF** and **ALMDESC2.CF** will copy the largest **ALMDESC.CF** file possible.

When saving software system configuration, record the file size of **ALMDESC.CF** for later use when prompted.

```
0 02> DIR ALMDESC.CF
```

Directory of FD00 02 02 ALMDESC CF									
Usn	File	Ex	Typ	Size	File size	Wrt	RDP	Updated	
02	ALMDESC	CF	Con	0100	00000A10	00	00	1 Apr 1993	

NOTE Be sure to record the *filesize*.

RESTORING THE ALMDESC.CF FILE

To restore the **ALMDESC.CF** file either modify the **LDALMTRD.CN** file in the USN 0 FF directory, or restore the file manually using the elementary line editor (ELE) on the DDT terminal. Copy this file, then edit that copy to restore **ALMDESC.CF**. Refer to the operation and configuration manual for more information.

INSTALLATION

For example, to restore a **ALMDESC.CF** file size of A10 using **LDALMTRD.CN**, the file should be modified to contain these entries

```

NOTE FILE LDALMTRD CN
NOTE
NOTE
NOTE Beginning with rev R1, ALMDESC CF is a variable sized file
NOTE SVALMTRD CN is used to save TRENDDEF CF to UCF4, and
NOTE ALMDESC CF to UCF4 and UCF5
NOTE
NOTE This file, LDALMTRD.CN, copies ONLY TRENDDEF CF to FD00 IT
NOTE contains an example of the DDT commands to restore a
NOTE full sized ALMDESC CF file The user should make a copy of this
NOTE file, then edit that copy to perform the restore of ALMDESC CF
NOTE The user can also perform the restore manually using DDT
NOTE
DSM
ACTION INSERT DISK UCF4 INTO FLOPPY DRIVE (PROTECTED)
NOTE
VMNT 1 UCF4
COPY 1 00 TRENDDEF CF 0 02
NOTE
FD00 02
DEL ALMDESC CF -P
ACF ALMDESC CF A10 0 0
FD00 FF
APF 1 00 ALMDESC1 CF 0 02 ALMDESC CF 0 0 9C4
DSM
NOTE
NOTE THE FOLLOWING SECTION ONLY NEEDS TO BE DONE IF FILE SIZE
NOTE IS GREATER THAN 9C4 REMCIVE THE "NOTE " FROM "ACTION",
NOTE "VMNT" AND "APF" LINES THAT FOLLOW
NOTE
NOTE
NOTE ACTION INSERT DISK UCF5 INTO FLOPPY DRIVE (PROTECTED)
NOTE
NOTE VMNT 1 UCF5
NOTE
NOTE WHEN FILE ERROR 1 OCCURS (END FILE) LOAD IS COMPLETE
NOTE
NOTE APF 1 00 ALMDESC2 CF 0 02 ALMDESC CF 0 9C5
DSM
NOTE
NOTE CONFIGURATION FILES COPY FROM FD01 TO FD00 COMPLETE
NOTE
0 FF
    
```

ASCII DATABASE

SLDG program release 5 4 for the engineering work station provides tools which create and accept input from floppy disks which contain ASCII and compressed ASCII database and configuration files Refer to the operation and configuration manual for more information. Refer to SLDG revision 5 3 documentation for information regarding its ASCII database tools

SECTION 4 - STANDARD HARDWARE

INTRODUCTION

This section contains the standard hardware used by the IIOIS20 and IIOIC20 operator interfaces. Each entry contains jumper and switch configurations for the IIOIS20 and IIOIC20 operator interface where it is used.

NOTE. The components in the O S and O C are configured at the factory. Settings shown in Section 4 and Section 5 are not required to operate your operator interface. Information in these sections is given in case settings are changed or hardware needs to be replaced.

The location of components and the wire and cable connections are also given. This section is a reference for standard equipment. Information for OIS and OIC options is in Section 5 of this manual.

STANDARD HARDWARE

Table 4 1 lists the hardware used in the operator interface station console (IIOIS20) and driver cabinet (IIOIS20A/D). This table also lists the hardware used for the operator interface consoles; 19 inch table top (IIOIC201), console (IIOIC202), environmental cabinet (IIOIC203), panel mounted (IIOIC204) and 37 inch tabletop (IIOIC205). Refer to Section 5 for optional hardware.

Table 4 1 Standard OIS/OIC Hardware

Part Nomenclature	Where Used							Description
	OIS		OIC					
	20	20A 20D	201	202	203	204	205	
1948002_1	X	X						Hard Disk Drive
1948013_1	X	X						Disk Drive Controller Module
1948014_7							X	Color Monitor (37 inch)
1948018_1	X	X						Floppy Disk Drive
1948023_1	X	X						SAS Module
1948623_1	X		X	X	X	X		Color Monitor (19 inch)
6637801_4				X				Sixteen Slot Multibus Card Cage (with a slide in power supply)
6637801_2	X	X						Sixteen Slot Multibus Card Cage
6638235_1	X		X	X	X	X		Keyboard Interface Panel
6638353_1	X							Power Entry Panel
6638353_2				X				Power Entry Panel

STANDARD HARDWARE

Table 4 1 Standard OIS/OIC Hardware (continued)

Part Nomenclature	Where Used							Description
	OIS		OIC					
	20	20A 20D	201	202	203	204	205	
6638514 1	X		X	X	X	X		Keyboard Assembly
6638564 1				X				Power Supply
6638565 1	X	X						Power Supply
6638564 2			X		X	X	X	Power Supply
6638960_1		X						Power Entry Panel
I ADP02	X			X				Annunciator/Display Pane
NADS01					X			Annunciator/Display Pane
IIMCL01	X	X						Multibus Communication Loop Module
I MCP0_	X	X						Multibus Communications Processor Module
I MGC01 ¹	X	X						Multibus Graphics Controller Module
MKM01	X		X	X	X	X		Multibus Keyboard Module
IIMLM01	X	X						Multibus Loop Module
MPM01	X	X						Multibus Processor Module
MRM01		X						Multibus Reset Module
IIMSM01	X	X						Multibus Serial Interface Module

NOTE 1 Multibus graphics controller modules mount on the O S20 but are included with the O C201/2/3/4/5

MULTIBUS HARDWARE

The multibus hardware consists of the multibus card cage and the modules. The modules are discussed following the multibus card cage in this section.

Multibus Card Cage

Bayley Part Number - 6637801_2 (IOIS20 IOIS20A and IO S20D)
 Bayley Part Number - 6637801_4 (IO C202 /2/3 with slide in power supply)

The multibus card cage provides the communication paths and defines the priority level for the IOIS20 and IOIC202 multibus modules listed in Table 4 2. The modules in the card cage are slot dependent. Connect the modules into the slots shown in this section.

Table 4 2 Multibus Modules

Multibus Module	Nomenclature
Multibus Graphics Controller Module	IMGC01
Multibus Keyboard Module	MKM01
Multibus Serial Interface Module	IMSM01
Multibus Processor Module	IMPM01
Multibus Communications Processor Module	MCP0
Multibus Loop Module	MLM01
Multibus Communication Loop Termination Module	MCL01

Figure 4 1 shows the maximum number of modules that will fit into the IOIS20 multibus card cage. This may be more than is in your system. The touch screen controller modules and the additional graphics module and keyboard module are options.

Figure 4 2 shows the modules in the IOIC202 multibus card cage. The touch screen controller modules and the additional graphics module and keyboard module are options.

Figure 4 3 shows the modules in the IOIC202 multibus card cage with the slide in power supply. The touch screen controller module is an option.

Figure 4-4 shows the multibus card cage (back view).

The multibus processor module and multibus graphics controller modules require priority jumpers on the back of the card cage to be set. All slots are jumpered for priority interrupts when the system is shipped. This allows the multibus cards to be moved to a different slot in the card cage if needed.

Table 4-3 lists the multibus card cage power connections shown later in this section.




Figure 4 1 IIOIS20 Multibus Card Cage (Front View)




Figure 4 2 IIOIC202 Multibus Card Cage (Front View)




Figure 4 3 IIOIC202 Multibus Card Cage with Slide In Power Supply




Figure 4 4. Multibus Card Cage (Back View)

Table 4 3 Multibus Wiring Connections

TB1	TB2	TB3	TB4	TB5	TB6
Use w re assembly 6638712 1	Use w re assembly 6638708 1	Use w re assembly 6638711 1	Use w re assembly 6638711 1	Use w re assembly 6638711_1	Use w re assembly 6638711 1
Connect Green w re to terminal one	Connect Term one no connect on	Connect Two brown w res from each tab posit on to CH1 POS on power supply	Connect One brown w re from each tab posit on to CH1 POS on power supply	Connect Two green/ white w re from each tab posit on to CH1 NEG on power supply	Connect One green/ wh te w re from each tab posit on to CH1 NEG on power supply
Wh te w re to terminal two	V o et w re to terminal two				
Make no connect on to terminal three	Wh te/v o et w re to terminal three				

Multibus Module Installation

CAUTION	Failure to turn off the main power circuit breaker before removing or inserting modules into the card cage may result in equipment failure
ATTENTION	Si l'on omet d'eteindre l'interrupteur du circuit d'alimentation principal avant de retirer les cartes ou de les inserer dans le porte-cartes, l'equipment pourrait faire default.

- 1 Insert the multibus modules into the card cage along the upper and lower guide rails Slide the module into the desired position, being careful to align it beneath the slot number
- 2 Press on the module removal tabs on the top and bottom of the card front to fully insert the module into the multibus backplane

Multibus Module Removal

CAUTION	Failure to turn off the main power circuit breaker before removing or inserting modules into the card cage may result in equipment failure.
ATTENTION	Si l'on omet d'eteindre l'interrupteur du circuit d'alimentation principal avant de retirer les cartes ou de les inserer dans le porte-cartes, l'equiptment pourrait faire default.

Remove the modules by pulling the module removal tabs on the top and bottom of the card front toward you and gently sliding the module out of the rack. Figure 4-5 shows how to remove the multibus modules.

NOTE: Be sure not to loosen cables from the modules next to the one being removed.




Figure 4 5 Removing Multibus Modules

STANDARD HARDWARE

Multibus Graphics Controller Module

Bay Nomenclature - I MGC01

Each multibus graphics controller module can drive one OIS or OIC monitor. Set the module address by wire wrapping jumpers to the appropriate pins. Figure 4-6 shows the location of the pins.

NOTE: Refer to **SECTION 5 - IIOIS20 OPTIONS** for the jumper settings of any additional multibus graphics modules. Verify the jumper placement to reduce the chance for an interrupt on the O/S operation.




Figure 4-6 Multibus Graphics Controller Module

Multibus Keyboard Module

Bailey Nomenclature - IMKM01

The multibus keyboard interface module interfaces the keyboard and other operator input devices to the OIS or OIC. There are four jumpers on the MKM board to set for proper operation. J1 and J2 control serial port one (P8) and two (P9). Connecting the eight pins horizontally as shown for P8 in Figure 4.7 configures the serial port as data communication equipment (DCE). For DCE, data is transmitted from the MKM on pin three of the connector and received from the connected device on pin two of the connector. Connecting the eight pins vertically as shown for P9 in Figure 4.7 configures the serial port as data terminal equipment (DTE). For DTE, data is transmitted from the MKM on pin two of the connector and received from the connected device on pin three of the connector.

J3 allows the option of resetting the entire OIS when the MKM watchdog timer circuit times out. Set the jumper to J3 pins one and two for OIS reset on timeout. Set the jumper to J3 pins two and three for no OIS reset on timeout. Factory default is no reset on timeout.




Figure 4.7. Connections for Multibus Keyboard Module

STANDARD HARDWARE

J3 allows the option of disabling the power supply out of tolerance (OOT) signal to reset the MKM. Set the jumper to J4 pins one and two to disable the OOT signal. Set the jumper to J4 pins two and three to enable the OOT signal. Factory default is to disable OOT on all OIC20s. Factory default is to enable OOT on all OIS20s.

See Figure 4-7 for MKM connector locations.

NOTE: Figure 4-7 shows cable connections for the IO S20. Cable numbers may be different for other OIS and OIC models. Refer to the wiring diagram for the specific model of OS or OIC installed for complete wiring connections.

Multibus Reset Module

Bay e y Nomenclature - I MRM01

The multibus reset module provides power fault interrupt and a reset signal to the multibus back plane through the J1 connector for an IIOIS20A or IIOIS20D. See Figure 4 8 for wiring connections.




Figure 4 8. Connections for Multibus Reset Module

Multibus Serial Interface Module

Bailey Nomenclature - IIMSM01

The OIS interfaces with various peripherals through the multibus serial interface module. The peripherals may include keyboards, printers and terminals.

NOTE Use only the peripherals recommended by Bailey Controls. If you have questions, contact your Bailey Controls sales or service office.

Configure the multibus serial interface module by setting jumpers and dipswitches. Refer to Table 4.4 for port assignments and Figure 4.9 for module configuration.

NOTE. Jumpers located below IC32 must be set according to the size of the RAM used for IC32, 16K or 64K. The number 16 or 64 (located within the chip number) is printed on IC32. Set the jumper according to this number.

Table 4.4 Multibus Serial Interface Port Assignments

Port	Assignment
1	Keyboard 1
2	Keyboard 2
3	Unused
4	Aux/N U
5	Printer 1
6	Unused
7	Printer 2
8	Diagnostic Terminal (DDT)




Figure 4 9. Multibus Serial Interface Module

SASI Disk Bus Interface Adapter

Bailey Part Number 1948023_1

The disk bus interface adapter provides the Shugart Associates System Interface (SASI™) between the disk drives and the multibus processor module. Shown in Figure 4 10, it attaches to the multibus processor module and occupies the physical space of the next module in the multibus card cage.




Figure 4 10 SASI Disk Bus Interface Adapter

TM SASI is a trademark of Shugart Associates

STANDARD HARDWARE

Multibus Processor Module

Bay Nomenclature - MPM01

The multibus processor module has 8 megabytes of RAM on board. It also contains 64 kilobytes of read only memory (ROM), communication ports for a diagnostic terminal and SASI disk adapter and a small computer serial interface (SCSI) port for magnetic tape/optical disk storage. See Figure 4-11 when setting the jumpers on the multibus processor module.




Figure 4 11 Multibus Processor Module

STANDARD HARDWARE

Multibus Loop Module

Ba ey Nomenclature MLM01

The multibus loop module, shown in Figure 4 12 allows communication between the multibus communication processor module (IIMCPO_) and the INFI NET or Plant Loop communication highway through the termination module (IIMCLO1). The switch settings shown in the figure are default settings, refer to Table 4-5 for jumper and dipswitch settings Use two ribbon cables numbered 6634512 26N2 to connect the loop module to the communication processor and to the termination module

NOTE: Dipswitch SW1 and SW2 selects the loop address and ring number of this O/S and depends on your nd v dua system





Figure 4 12 Multibus Loop Module

Table 4 5 Loop Module Configuration



NOTE Switch Open = 1 Switch Closed = 0
 * indicates settings for normal operation

Multibus Communication Processor Module

Bailey Nomenclature - 1 MCP0

The multibus communication processor module (Figure 4 13) contains a library of commands which send and retrieve data from other process control units and operator consoles. The OIS sends commands to the multibus communication processor module requesting it to send or retrieve required data. Configure the multibus communication processor module by setting dipswitches. Refer to Table 4 6 for the standard module dipswitch settings.




Figure 4 13 Multibus Communication Processor Module

Table 4 6. Multibus Communication Processor Configuration

Switch 0		
Poles	Function	Description
1	ROM Checksumming	* 0 = ROM Checksum Enabled 1 = ROM Checksum Disabled
2 3	Port A Data Characteristics	00 = 8 1 N *10 = 8 1 O 01 = 8 1 E 11 = 8 1 N
4	Port B Operation Mode	0 = N U Command mode * 1 = N U Utility Mode
5 6	Port B Data Characteristics (only if switch 4 = 0)	* 00 = 8 1 N 10 = 8 1 O 01 = 8 1 E 11 = 8 1 N
7	Command Checksumming	0 = Command Checksum Disabled * 1 = Command Checksum Enabled
8	Unused	

NOTES

- Closed - 0 = On = Up
- Open - 1 = Off = Down
- normal setting

Switch 1		
Poles	Function	Description
1-4	Port A Baud Rate	0000 = N/U 0001 = 1800 1000 = 75 1001 = 2000 0100 = 110 0101 = 2400 1100 = 134.5 1101 = N/U 0010 = 150 0011 = 4800 1010 = 300 1011 = N/U 0*10 = 600 011* = 9600 1110 = 1200 * 1111 = 19.2k
5-8	Port B Baud Rate	0000 = N/U 0001 = 1800 1000 = 75 1001 = 2000 0100 = 110 0101 = 2400 1100 = 134.5 1101 = N/U 0010 = 150 0011 = 4800 1010 = 300 1011 = N/U 0110 = 600 * 0111 = 9600 1110 = 1200 1111 = 19.2k

NOTES

- Closed - 0 = On = Up
- Open - 1 = Off = Down
- * = normal setting

Table 4 6 Multibus Communication Processor Configuration (continued)

Switch 2		
Poles	Function	Description
1	Firmware Test Mode	* 0 = Disabled 1 = Enabled
2	MLM Diagnostic Mode	* 0 = Disabled 1 = Enabled
3	Loop Diagnostics	* 0 = Disabled 1 = Enabled
4 6	Unused	
7	NVRAM Installed	0 = NVRAM Not Installed * 1 = NVRAM Installed
8	RAM Component Size	0 = 32k x 8 (512k) * 1 = 128k x 8 (2m)

NOTES
 Closed = 0 - On - Up
 Open = 1 - Off - Down
 * = normal setting

Multibus Communication Loop Module

Bay Nomenclature 1 MCL01

The multibus communication loop module is the termination unit that interfaces the OIS to the communication highway. See Figure 4-14 for wiring instruction.

Set jumpers J1-J6 for the type of cable used in the Network 90 or INFI 90 to either coaxial or twinaxial cable.




Figure 4-14 Multibus Communication Loop Module

STANDARD HARDWARE

SYSTEM HARDWARE

Keyboard Interface Panel

Bailey Part Number - 6638238

The keyboard interface panel (Figure 4 15) is located on the IIOIS20 and IIOIC202 cabinet front panel next to the CRT behind a smoked polycarbonate door. The panel is located on the IIOIS20A/D on the front of the power entry panel. On the IIOIC201 and IIOIC204, the panel is on the front of the case below the CRT. On the IIOIC203, the panel is on the front of the power entry panel behind the front door.

The keyboard socket is for the operator keyboard supplied with the OIS and OIC. The AUX 1 port is for a tabletop annunciator display panel (future). The AUX KBD connector




Figure 4 15 Keyboard Interface Panel

is for an engineering (IBM AT[®]) keyboard. The keyboard interface panel connectors are listed in Table 4.7. The keyboard interface panel connectors and the floppy drive connect to the I/O distribution board. P9 and P10 are not used.

NOTE: The tune/config switch is in a different location in each O/S/O/C.

Table 4.7 Connections to Keyboard Interface Panel

Connector P1	Connector P2	Connector P8
Connect cable No. 6634512_26N72 to P5 on the I MKM01 module	Connect cable No. 6638713_1 to P3 on the DC distributor board	Connect cable No. 66388491_1 to P7 on the I MKM01 Module and to P2 on the ADP pane

STANDARD HARDWARE

Operator Keyboard

Bailey Part Number 6638514 1

The keyboard port on the keyboard interface panel is for the OIS and OIC lap top style keyboard. The three foot long coiled cord can be stretched to eight feet. See Figure 4 16




Figure 4 16. Operator Keyboard

Color Monitor

Bay Part Number - 1948623_6 (19-inch monitor)

The color monitor used in the OIS and OIC is an RGB monitor with a 640 x 480 pixel resolution CRT. See Figure 4 17 for more information

OIS20 and OIC202 NOTES:

- 1 Cable number 6637597 24100 connects the lower monitor of the O S20 and OIC202 to the multi bus graphics controller board. Cable number 6637597 34200 connects the upper monitor to the multi bus graphics controller board. Labels R, G and B represent red, green and blue, respectively.
- 2 Maximum length of RS-170 RCB cables is 250 feet. For distances over 250 feet, optical modems (NREMO1) using up to 1000 feet of fiber optic cable (NKFM01-xx) are required.
- 3 If remote CRTs are being installed, ensure they are powered using the same polarized power and ground as the O S and OIC to prevent ground loops. Failure to do so may cause display distortion if ground loops are suspected, use optically isolated modems to eliminate the problem.
- 4 A 9-pin D-sub connector connects an external brightness, contrast and degauss control. Use cable number 6638720_1 for the lower monitor and cable number 6638720_2 for the upper monitor. Brightness and contrast controls are mounted on the bezel. The degauss switch is mounted on the PEP.
- 5 CRT wiring connector location may be slightly different for each model of OIS and OIC.
- 6 Brightness and contrast controls are located on the front panel of the power entry panel of the OIC203.
- 7 Inteco and Aydin monitors are autosensing and do not need to be switched if the power to the cabinet is 120 volts or 220 volts. However, other monitors may need to be switched to prevent damage from over voltage or undervoltage.
- 8 For OIC205, make connections directly to the monitor.

STANDARD HARDWARE




Figure 4 17 Color Monitor

Disk Drive Controller Board

Bayley Part Number - 1948013 1

The disk drive controller board interfaces the floppy disk drive and the hard disk drive to the IIOIS20 and IIOIS20A/D. Configure this module with jumper settings. See Figure 4 18 for board configuration, and refer to Table 4 8 for wiring connections.




Figure 4 18. Disk Drive Controller Module

Table 4 8 Connections to Disk Drive Controller Module

From J1	From J2	From J4	From J7	From J10
To J1 connector on SASI module use wire assembly no 6632686 50-1	To J1 connector on hard disk drive use wire assembly no 6634329_34N12	To J2 connector on hard disk drive, use wire assembly no 6634329_20N8	To J1 connector on floppy disk drive use wire assembly no 6634329_34N48	To J6 on DC distribut on board on top of main power supply, use wire assembly no 6638713_5

NOTE J3 s reserved for future use and has no connections

Annunciator Display Panel (ADP)

Bailey Nomenclature - I ADP01 Tab etop
ADP02 Console Mounted

The annunciator display panel (ADP) provides a panel of 32 lamps and pushbuttons. Each lamp and pushbutton is assigned to an OIS or OIC display. When a tag on a display goes into an alarm condition, the assigned ADP lamp turns on. Press the assigned pushbutton to cause the assigned display to be printed to the screen.

The IIOIS20 or IIOIC202 can drive four annunciator display panels. One ADP panel is console mounted, the other three ADP panels are tabletop models connected with cables.

NOTE The OIC203 has a 64 key ADS panel. Only 32 of the keys can be accessed by software.

Refer to the tabletop annunciator display entry in Section 5 for the switch settings and cable connections.

Refer to Table 4-9 for wiring connections to the ADP Board. Refer to Figure 4-19 for the location of the first ADP. Refer to Figure 4-20 for the dipswitch configuration of the first annunciator display panel (IADP02).

Table 4-9 Connections to Annunciator Display Board

From P1	From P2
To P4 socket on top of main power supply, use cable assembly number 6638713-2	To P7 connector on IMKM01 module, use cable number 66388491-1




Figure 4 19 Annunciator Display Panel




Figure 4 20 Annunciator Panel Circuit Board

Floppy Disk Drive - TEAC

Bay Part Number - 1948018_1

The OIS uses a high density 1 2 megabyte floppy disk drive. Two drive styles are used, and each requires configuration by setting jumpers. Figure 4 21 shows the TEAC FD 55GFR 141 U and jumper configuration.




Figure 4 21. TEAC Floppy Disk Drive

Floppy Disk Drive - NEC

Bailey Part Number 1948018 1

Figure 4 22 shows the NEC FD 1157C high density 1 2 megabyte floppy disk drive and jumper configuration




Figure 4 22 NEC Floppy Disk Drives

Hard Disk Drive - PRIAM V185A 85 Megabyte

Bailey Part Number - 1948002_2 (obsolete)

Figure 4-23 shows the required jumper configuration for the PRIAM V185A 85 megabyte hard disk drive




Figure 4 23. PRIAM V185A Hard Disk Drive

Hard Disk Drive - CONTROL DATA 85 Megabyte

Bailey Part Number 1948002 2 (obsolete)

Figure 4 24 shows the required jumper configuration for the Control Data 85 megabyte hard disk drive




Figure 4 24 CONTROL DATA Hard Disk Drive

Hard Disk Drive - SEAGATE 85 Megabyte

Bailey Part Number 1948002_4

Figure 4-25 shows the required jumper configuration for the Seagate ST4096 85 megabyte hard disk drive.




Figure 4-25. SEAGATE ST4096 Hard Disk Drive

Hard Disk Drive - MAXTOR 85 Megabyte

Bay Part Number 1948002 4

Figure 4 26 shows the required jumper configuration for the MAXTOR XT1085 85 megabyte hard disk drive




Figure 4 26. MAXTOR XT1085 Hard Disk Drive

IIOIS20 and IIOIC202 Power Entry Panel

Bailey Part Number - 6638353_1

The power entry panel (PEP) contains the incoming AC power terminals and system circuit breakers along with ports for connecting peripheral devices, terminals for alarm contact outputs and ports for archival data storage devices. The power entry panel also contains the system reset switch and the degaussing switches for the CRTs.

Connectors P1 through P16 connect the PEP to the multibus processor module and peripheral devices on the OIS. Only P1 is used on the OIC. The connectors are assigned as shown in Table 4.10.

Table 4.10 IIOIS20 and IIOIC202 PEP
Connector Assignments

Connector		Connector	
Number	Use	Number	Use
P1	Keyboard 1 (O S20/OIC20)	P9	Processor Module Port 1
P2 ¹	Keyboard 2	P10	Monitor 68k
P3	Unused	P11	Unused
P4	N U Connect on	P12	Unused
P5	Printer 1	P13	Unused
P6	Unused	P14	Unused
P7	Printer 2	P15	Unused
P8	Dynamic Debugger Terminal	P16	Unused

NOTE: ¹ P2 through P16 are not used on the OIC202 only P1 is used.

The SCSI peripheral port (small computer system interface port) connects a magnetic tape or optical disk data storage device for the OIS.

The streaming tape port connection is for a streaming tape drive used for rapid reloading of system and user configuration files for the OIS.

NOTE: Read the notice on the panel before you plug in the tape drive. Plugging in the tape reader power cord first connects the tape reader ground to the IIOIS20 or IO C202.

Use the U degauss switch to correct picture distortion due to magnetic fields on the screen of the upper (swivel mount) CRT. Use the L degauss switch to correct picture distortion due to magnetic fields on the screen of the lower cabinet mount CRT.

The reset pushbutton resets the OIS or OIC to an initial power up condition when pressed.

A terminal block with six alarm contact outputs connects annunciators to user defined alarms. The terminal designation is printed on the panel beside the terminal. The digital in (DI) and digital out (DO) terminals are configured from OIS software

The power indicator is lit when the AC power is connected to the PEP and the main power circuit breaker is on

Connect your static ground wrist strap into the wrist strap connector before removing modules from the card cage.

CAUTION	Failure to turn off the main power circuit breaker before removing or inserting modules into the card cage may result in equipment failure.
ATTENTION	Si l'on omet d'eteindre l'interrupteur du circuit d'alimentation principal avant de retirer les cartes ou de les inserer dans le porte-cartes, l'equipe-ment pourrait faire default.

The streaming tape power AC outlet on the OIS PEP is a convenience outlet for either 120/240 VAC devices Check the label on the front of the PEP before connecting anything into this outlet

CAUTION	Failure to plug in the streaming tape drive ribbon cable before turning the tape drive power on may result in equipment failure. Read the notice on the front of the power entry panel before turning on the power to the tape drive. Set the streaming tape drive to the same voltage as the PEP outlet or equipment damage may result.
ATTENTION	Si l'on omet d'eteindre l'interrupteur du circuit d'alimentation principal avant de retirer les cartes ou de les inserer dans le porte-cartes, l'equipe-ment pourrait faire default. Lisez l'avis figurant a l'avant du panneau d'entree d'alimentation avant d'acheminer l'alimentation au derouleur de bande. Reglez le derouleur en continu au meme niveau de tension que la sortie du panneau d'entree d'alimentation sinon le materiel pourrait subir des dommages.

Use either 120 VAC or 240 VAC power to supply power to the IIOIS20 or IIOIC202 through the terminal block at the bottom of the panel

NOTES:

- 1 Be sure the IIOIS20 or IIOIC202 is set up to receive 240 VAC if you are connecting 240 VAC to the IIOIS20 or IIOIC202 power entry panel




Figure 4-27 I/OIS20 and I/OIC202 Power Entry Panel

2 Wiring connections shown in Figure 4-27 and Figure 4-28 are for the I/OIS20 or I/OIC202 with the exception of P2 to P16 on the PEP. These connections are only used for the I/OIS20.

3 Some of the connections are on the back side of the power entry panel and are accessed through the door on the back of the OIS or OIC.




Figure 4 28 IIOIS20 and IIOIC202 Connectors for Power Entry Panel

IIOIS20A/D Power Entry Panel

Ballay Part Number - 6638960_1

The power entry panel (PEP) contains the incoming AC power terminals and system circuit breakers along with ports for connecting peripheral devices, terminals for alarm contact outputs and ports for archival data storage devices. The power entry panel also contains the system reset switch and the degaussing switches for the CRTs

Connectors P1 through P16 connect the PEP to the multibus processor module and peripheral devices on the OIS. The connectors are assigned as shown in Table 4-11.

Table 4-11 IIOIS20A/D PEP Connector Assignments

Connector		Connector	
Number	Use	Number	Use
P1	Keyboard 1	P9	Processor Module
P2	Keyboard 2	P10	Port 1
P3	Unused	P11	Monitor 68k
P4	NU Connection	P12	Unused
P5	Printer	P13	Unused
P6	Unused	P14	Unused
P7	Printer 2	P15	Unused
P8	Dynamic Debugger Terminal	P16	Unused

The SCSI peripheral port (small computer system interface port) connects a magnetic tape or optical disk data storage device for the OIS.

The streaming tape port connection is for a streaming tape drive used for rapid reloading of system and user configuration files for the OIS.

NOTE: Read the notice on the panel before you plug in the tape drive. Plugging in the tape reader power cord first connects the tape reader ground to the OIS20A/D.

The reset pushbutton resets the OIS to an initial power up condition when pressed.

A terminal block with six alarm contact outputs connects annunciators to user defined alarms. The terminal designation is printed on the panel beside the terminal. The digital in (DI) and digital out (DO) terminals are configured from OIS software.

The power indicator is lit when the AC power is connected to the PEP and the main power circuit breaker is on.

Connect your static ground wrist strap into the wrist strap connector before removing modules from the card cage.

CAUTION

Failure to turn off the main power circuit breaker before removing or inserting modules into the card cage may result in equipment failure.

ATTENTION

Si l'on omet d'eteindre l'interrupteur du circuit d'alimentation principal avant de retirer les cartes ou de les inserer dans le porte-cartes, l'equipeent pourrait faire default.

The streaming tape power AC outlet on the OIS PEP is a convenience outlet for either 120/240 VAC devices. Check the label on the front of the PEP before connecting anything into this outlet.

CAUTION

Failure to plug in the streaming tape drive ribbon cable before turning the tape drive power on may result in equipment failure. Read the notice on the front of the power entry panel before turning on the power to the tape drive. Set the streaming tape drive to the same voltage as the PEP outlet or equipment damage may result.

ATTENTION

Si l'on omet d'eteindre l'interrupteur du circuit d'alimentation principal avant de retirer les cartes ou de les inserer dans le porte-cartes, l'equipeent pourrait faire default. Lisez l'avis figurant a l'avant du panneau d'entree d'alimentation avant d'acheminer l'alimentation au derouleur de bande. Reglez le derouleur en continu au meme niveau de tension que la sortie du panneau d'entree d'alimentation sinon le materiel pourrait subir des dommages.

Read the notice on the front of the power entry panel before turning on the power to the tape drive. Set the streaming tape drive to the same voltage as the PEP outlet or equipment damage may result.

Use either 120 VAC or 240 VAC to power the IIOIS20A/D through the terminal block at the bottom of the panel.

NOTE: Be sure the OIS20A/D is set up to receive 240 VAC if you are connecting 240 VAC to the power entry panel.

Wiring connections are shown in Figure 4-29 and Figure 4-30. Note that some of the connections are on the back side of the power entry panel and are accessed through the door on the back of the OIS.




Figure 4 29. IIOIS20A/D Power Entry Panel




Figure 4 30 IIOIS20A/D Connections for Power Entry Panel

IIOC202 Connector Panel for the Slide-In Power Supply

Barcy Part Number - 6639225 1

The connector panel contains the incoming AC power terminals, system circuit breakers, terminals for alarm contact outputs, system reset switch and the degaussing switches for the CRTs. Table 4-12 contains the power entry panel cable connection.

NOTE: The power entry panel is part of the slide-in power supply.

On the connector panel, use the U degauss switch to correct picture distortion due to magnetic fields on the screen of the upper (swivel mount) CRT. Use the L degauss switch to correct picture distortion due to magnetic fields on the screen of the lower cabinet mount CRT.

Table 4-12 IIOC202 PEP Connector Assignments

Connector Number	Use
P1 on the connector panel	Keyboard 1

The reset pushbutton resets the OIC to an initial power up condition when pressed.

A terminal block with six alarm contact outputs connects annunciators to user defined alarms. The terminal designation is printed on the panel beside the terminal. The digital in (DI) and digital out (DO) terminals are configured from OIC software.

On the power supply, the power indicator is lit when the AC power is connected to the PEP and the main power circuit breaker is on.

Connect your static ground wrist strap into the wrist strap connector on the power supply before removing modules from the card cage.

CAUTION	Failure to turn off the main power circuit breaker before removing or inserting modules into the card cage may result in equipment failure.
ATTENTION	Si l'on omet d'éteindre l'interrupteur du circuit d'alimentation principal avant de retirer les cartes ou de les insérer dans le porte-cartes, l'équipement pourrait faire défaut.

STANDARD HARDWARE

Use either 120 VAC or 240 VAC to supply the IIOIC202 through the terminal block at the bottom of the panel

CAUTION

Verify that the IIOIC202 is set up to receive 240 VAC if the supply circuit to the power entry panel is 240 VAC or equipment damage may result.

ATTENTION

Verifiez si le IIOIC202 est regle de facon a recevoir 240 V c.a. et si le circuit d'alimentation au panneau d'entree est de 240 V c.a., sinon le materiel pourrait subir des dommages.

Wiring connections are shown in Figure 4 31 and Figure 4 32 Note that there are connections on the back side of the power entry panel Access them through the door on the back of the OIC

The 24 volt alarm contact relay outputs are for alarm annunciation only Refer to **SPECIFICATIONS** in Section 1 for limits




Figure 4 31. IIOIC202 Connector Panel for Slide In Power Supply

STANDARD HARDWARE




Figure 4 32 I/OIC202 Connections for Slide In Power Supply Connector Panel

IIOIS20 and IIOIS20A/D Main Power Supply

Ba ley Part Number 1948565 1

The IIOIS20 and IIOIS20A/D main power supply is a 500 watt power supply which provides power to all OIS multibus modules, disk drives and OIC multibus modules (see Figure 4-33).

Figure 4 34 shows the connections from the main power supply. Figure 4 35 shows the connections from the main power supply to the DC distribution board Figure 4 36 shows the connections from the main power supply to the backplane of the card cage Table 4-13 lists the power supply connections to the DC distribution board and the backplane of the multibus card cage.




Figure 4 33. IIOIS20 and IIOIS20A/D Main Power Supply




Figure 4-34 IIOIS20 and IIOIS20A/D Connections from Main Power Supply




Figure 4 35. IIOIS20 and IIOIS20A/D Power Connections to DC Distribution Board

The DC distribution board is located at the top rear of the supply. Each socket on the DC distribution board is wired identically. Any peripheral device using power cable (6638713 1) may be plugged into any socket on this board.

NOTE: This power supply is used in both the 120 volts and 240 volts IIOIS20 and IO S20A/D. Check the switch on the side when replacing the power supply to make sure it is set for the voltage rating of the cabinet.




Figure 4 36 IIOIS20 and IIOIS20A/D Power Connections to Backplane

Table 4 13 IIOIS20 and IIOIS20A/D Power Supply Connections

500 W Main Power Supply DC Cable/Wire Connections					
Source			Destination		
Wire/Cable Number	From	Terminal	Wire Description	Terminal	To
6638708 1	DC D str but on	TB 1	White/V oilet	TB2-3	Mult bus Backp ane
	DC D str but on	TB-3	Violet	TB2-2	
6638710 2	Ma n P/S	GND STUD	Green/Ye ow	E1	PEP
6638710_3	Ma n P/S	CH2 -	Wh te/Green	CH3 +	Ma n P/S
6638710 4	Ma n P/S	CH2-	White/Green	GND STUD	Ma n P/S
6638711 1	Ma n P/S	GND STUD	Wh te/Green White/Green White/Green Wh te/Green White/Green White/Green	TB5-2 TB5 2 TB5 1 TB5-1 TB6 1 TB6-2	Mu t bus Backp ane
		+5 V STLD	Brown Brown Brown Brown Brown	TB3 2 TB3 2 TB3 1 TB3 1 TB4 1 TB4-2	
6638712 1	Ma n P/S	J1	Wh te Green	TB1-2 TB1 1	Mu tibus Backp ane
			Red Black	P3 P3	IMKM01
6638717_1	Ma n P/S	J2	Cable	P7	DC D str bution
6638718 1	Ma n P/S	+5 V Stud	Brown	TB 5	DC Distribution
		GND STUD	White/Green White/Green	TB-2 TB-7	
		CH3 - CH2 +	Vio et Wh te/V o et	TB 3 TB 1	

IIOIC202 Main Power Supply

Bailey Part Number 1948564_1

The IIOIC202 main power supply (Figure 4 37) is a 130 watt power supply which provides power to all multibus modules and CRTs Figure 4 38 shows the connections from the main power supply Figure 4 39 shows the connections from the main power supply to the DC distribution board Figure 4 40 shows the connections from the main power supply to the backplane of the card cage Table 4 14 lists the power supply connections to the DC distribution board and the backplane of the multibus card cage




Figure 4 37. IIOIC202 Main Power Supply




Figure 4 38 I/OIC202 Connections from Main Power Supply

The DC distribution board is located at the top-rear of the supply. Each socket on the DC distribution board is wired identically. Any peripheral device using power cable (6638713 1) may be plugged into any socket on this board

NOTE. This power supply is used in both the 120V and 240V I/O C20. Check the switch on the side when replacing the power supply to make sure it is set for the voltage rating of the cabinet.




Figure 4 39 I/OIC202 Power Connections to DC Distribution Board




Figure 4 40 IIOIC202 Power Connections to Backplane

Table 4 14. IIOIC202 Power Supply Connections

135 W Main Power Supply DC Cable/Wire Connections					
Wire/Cable Number	Source		Wire Description	Destination	
	From	Terminal		Terminal	To
6638706_1	Main P/S	TB 9 TB 6 TB 5	Brown White/Green White/Green	TB3 2 TB5 2 TB6 2	Multibus Backplane
6638707 1	Main P/S	TB 8 TB-7 TB-3 TB-2	Brown White/Green White/Green Violet	TB 8 TB 6 TB-1 TB 3	Multibus Backplane
6638708_1	DC Distribution	TB-1 TB 3	White/Green Violet	TB2 3 TB2-2	Multibus Backplane
6638709 1	Main P/S	TB 1	Red	P3	MKM01
6638710 1	Multibus Backplane	TB5 1	Green/Yellow	E1	PEP
6638710_9	DC Distribution	TB-2	Green/Yellow	TB 8	DC Distribution

IIOIC202 Slide In Power Supply

Bailey Part Number 6639225 1

The IIOIC202 slide in power supply is a 135 watt power supply which provides power to all multibus modules and CRTs. Figure 4 41 shows the connections from the slide in power supply. Figure 4 42 shows the connections from the power supply to the DC distribution board. Table 4 15 lists the power supply connections to the DC distribution board and the backplane of the multibus card cage.

The DC distribution board is located at the rear of the power supply. Each socket on the DC distribution board is wired identically. Any peripheral device using power cable (6638713 0) may be plugged into any socket on this board.

NOTE This power supply is used in both the 120 volt and 240 volt IIO C202. The supply is autosensing.





Figure 4 41 IIOIC202 Slide In Power Supply




Figure 4 42. IIOIC202 Connections Inside the Slide In Power Supply

Table 4 15. IIOIC202 Power Supply Connections

135 W Main Power Supply DC Cable/Wire Connections					
Source			Destination		
Wire/Cable Number	From	Terminal	Wire Description	Terminal	To
6638708 1	DC D str but on	TB-1 TB 3	Wh te/Violet Vio et	TB2-3 TB2 2	Mu t bus Backp ane
6638710 2	Main P/S	GND STUD	Green/Yellow	E1	PEP
6638710_3	Ma n P/S	CH2 -	Wh te/Green	CH3 +	Ma n P/S
6638710 4	Main P/S	CH2 -	White/Green	GND STUD	Ma n P/S

STANDARD HARDWARE



Table 4 15 IIOIC202 Power Supply Connections (continued)

135 W Main Power Supply DC Cable/Wire Connections					
Source			Destination		
6638711_1	Main P/S	GND STUD	White/Green White/Green White/Green White/Green White/Green White/Green	TB5 2 TB5 2 TB5 1 TB5 1 TB6 1 TB6 2	Multi bus Backplane
		+5 V STUD	Brown Brown Brown Brown Brown Brown	TB3 2 TB3 2 TB3 1 TB3 1 TB4 1 TB4 2	
6638712_1	Main P/S	J1	White Green	TB1 2 TB1 1	Multi bus Backplane
			Red Black	P3 P3	
6638717_1	Main P/S	J2	Red Black	P7	DC Distribution
6638718_1	Main P/S	+5 V STUD GND STUD	Brown White/Green White/Green	TB 5 TB 2 TB-7	DC Distribution
		CH3 CH2 +	Violet White/Violet	TB-3 TB 1	

AC POWER

Refer to Section 3 for the location of the AC connections for the unit being installed. Figure 4-43 shows the AC wiring inside the power entry panel for IIOIS20, IIOIS20A/D and IIOIC202. The IIOIC203 is similar except that it has a transformer and switch for 120 VAC/240 VAC for the air conditioner. IIOIC201/4/5 have similar internal AC wiring. The number of AC outlets is different.

NOTE: Connect the device only to the outlet labeled for that device to prevent possible overloading of the outlet.




Figure 4 43 IIOIS20, IIOIS20A/D and IIOIC202/3 PEP AC Connections

SECTION 5 - OPTIONAL HARDWARE

INTRODUCTION

This section contains the optional hardware for the OIS/OIC and the installation procedures. Table 5 1 lists the optional hardware used in the Operator Interface Station, console (IIOIS20) and driver cabinet (IIOIS20A/D). This table also lists the hardware used for the Operator Interface Consoles, 19 inch table top (IIOIC201), console (IIOIC202), environmental cabinet (IIOIC203), panel mounted (IIOIC204), and 37 inch tabletop (IIOIC205). Refer to Section 4 for standard hardware.

Table 5 1 Optional OIS/OIC Hardware

Part Nomenclature	Where Used							Description
	OIS		OIC					
	20	20A 20D	201	202	203	204	205	
6638514_1							X	Keyboard Assembly
ADP01	X		X	X		X	X	Annunciator/Display Panel (tabletop)
AKB01	X		X	X	X	X	X	QWERTY Auxiliary Engineering Keyboard
AMS01	X		X	X		X	X	Mouse
ATB01	X		X	X		X	X	Trackball
ATS01	X		X	X		X	X	Touch Screen
DMT01		X						Magnetic Tape (rackmount)
IDMT02	X							Magnetic Tape Drive for Archival Storage (tabletop)
IIDOP01		X						Optical Drive for Archival Storage (rackmount)
DOP02	X							Tabletop Optical Disk
DST01	X	X						Streaming Tape Drive for Archival Storage
MGC01	X	X						Multiprocessor Graphics Control Card (add-on card)
PRT02	X	X						Black and White Printer
IPRT03	X	X						Color Printer
PRT04	X	X						Video Copier (color)
PRT05	X	X						Black and White Printer (high speed)
VTE01	X	X						Terminal for Diagnostics/Start Up

OPTIONAL HARDWARE

Adding new hardware requires making the correct cable connections and making any required jumper and/or dipswitch settings. Specific installation procedures for individual components are given in the section with the option name.

Refer to Section 4 for details about standard OIS hardware.

Tabletop Annunciator Display Panel (ADP)

Bailey Nomenclature ADP01

The tabletop annunciator display panel (ADP) provides an additional 32 lamps and pushbuttons. Each lamp and pushbutton is assigned to an OIS display. When a tag on a display goes into an alarm condition, the assigned ADP lamp turns on. Press the assigned pushbutton to cause the assigned display to be printed to the screen.

The IICIS20 and IICIC202/3/4 can drive up to four annunciator display panels, one standard ADP and three tabletop ADPs. See Figure 5.1 for the dipswitch configuration. Refer to Table 5.2 for wiring connections to the ADP board.




Figure 5.1 Tabletop Annunciator Display Panel

Table 5 2. Connections to Annunciator Display Board

From P1	From P2
To P1 on optional ADP Panel, use cable assembly number 1948978 1	To AUX port on keyboard interface panel use cable number 1948978 1

OPTIONAL HARDWARE



Second Color Graphics Module

Bailey Nomenclature - MGC01

The second multibus graphics controller module is in slot three of the multibus card cage. The multibus in the OIS can have up to two IMGC01 modules. Up to two monitors can be connected to an IIOIS20, IIOIS20A/D or IIMGC01. A color graphics module is included for each CRT ordered. Each module must be configured by setting jumpers. See Figure 5.2 for module locations and jumper settings. Refer to the color monitor entry in this section for monitor wiring connections.




Figure 5.2. Configuring the Second Multibus Graphics Controller Module

Color Monitor

Bailey Part Number - 1948014 7 (33-inch monitor)
 Bailey Part Number - 1948623 6 (19-inch monitor)

Adding additional color monitors is model dependent. Refer to Table 5 3 for a list of available color monitor options. Refer to the color monitor entry in the part replacement procedures of Section 8 for steps to remove the monitor. See Figure 4-17 for the location of the 19 inch color monitor connections. See Figure 5 2a for the location of the 33 inch color monitor connections.

WARNING	The CRT will slide out the rear of the IIOIS20 and IIOIC202 cabinet by itself when the mounting bolts are removed. Removing the rear two bolts without supporting the CRT could cause personal injury.
AVERTISSEMENT	Lorsque les boulons d'ancrage sont retirés, l'écran cathodique risque de sortir à l'arrière de l'armoire IIOIS20 et IIOIC20. Si les deux boulons d'ancrage arrière sont retirés, il faut retenir l'écran afin d'éviter toute blessure.

Table 5 3 19 Inch Color Monitor Options

Nomenclature	Description
IO S202	One CRT mounted in cabinet and one mounted on the upper CRT mount
IO C2022	One CRT mounted in cabinet and one mounted on the upper CRT mount

A second color monitor includes another IIMGC01 module. See Figure 5-2 for module location and configuration information.

1. Slide the IIMGC01 module into slot three of the host OIS multibus card cage and secure the two front latches.
2. Plug the RGB inputs into the socket on the front of the IIMGC01 module.
3. Connect the cable from the IIMGC01 to the RGB connector panel in back of the host OIS below the main power supply.
4. Connect the red, green and blue cable plugs to the correct connectors on the back of the monitor.

OPTIONAL HARDWARE

5. Plug the monitor power line into the proper socket on the back of the power entry panel

IIOS20 and IIOC202 NOTES:

1 Cable number 6637597_24100 connects the lower monitor of the O S20 and O IC202 to the multibus graphics controller board. Cable number 6637597_34200 connects the upper monitor to the multibus graphics controller board. Labels R, G and B represent red, green and blue, respectively.

2 Maximum length of RS-170 RGB Cables is 250 feet. For distances over 250 feet, optical modems (NREM01) using up to 1000 feet of fiber optic cable (NKFM01 xx) are required.


3 If remote CRTs are being installed, ensure they are powered using the same polarized power and ground as the O S and O C to prevent ground loops. Failure to do so may cause display distortion if ground loops are still suspected, use of optically isolated modems will eliminate the problem.

4 A three-pin D subconnector connects an external brightness, contrast and degauss control. Use cable number 6638720_1 for the lower monitor and cable number 6638720_2 for the upper monitor. Brightness and contrast controls are mounted on the bezel. The degauss switch is mounted on the PEP.

5 CRT wiring connector location may be slightly different for each model of OIS and O C.

6 Brightness and contrast controls are located on the front panel of the power entry panel of the O C203.

OPTIONAL HARDWARE



TP36371A

Figure 5 2a. Optional Color Monitor

OPTIONAL HARDWARE

Engineering Keyboard

Barley Nomenclature | AKB01

Each IIOIS20 and IIOIC202 console supports an additional engineering QWERTY keyboard. The IIOIS20 and IIOIC202 keyboard plugs into a five pin DIN connector on the keyboard interface panel located to the right of the CRT and below the ADP panel. Each OIC has a five pin DIN connector located on the keyboard interface panel. Figure 5 3 shows the IIOIS202. The connector is similar on the OIS and OIC models.

Power does not have to be removed from the OIS or OIC before plugging in or unplugging the engineering keyboard. Initializing the system is not needed after plugging in or unplugging the engineering keyboard.

NOTE: Some keyboards may have underside switches. Set these switches to the fixed AT mode.




Figure 5 3. Engineering Keyboard Connector

OPTIONAL HARDWARE

Printer

Bailey Nomenclature PRT02/I PRT03/ IPRT04/ IPRT05

A maximum of two printers may be connected to the IIOIS20 or IIOIS20A/D. Refer to Section 4 for socket placement on the power entry panel. Plug the printer into the assigned AC receptacle on the back of the power entry panel. Table 5.4 lists the printers used by the serial interface.

Table 5.4 OIS20/OIC20 Printers

Nomenclature	Description
I PRT02	Black and White Printer
I PRT03	Color Printer
PRT04	Video Copier (color)
IIPRT05	Black and White Printer (high speed)

NOTES

- For distances over 200 feet, optical modems (using up to 1000 feet of fiber optic cable) are required.
- The power cord must have a safety ground referenced to the same point as the OIS section safety ground. Without connection to conductive/structural ground, AC receptacle must be a safety ground duplex. Pass and Seymour G6200, or equivalent.

SETUP

Steps 1-5 are for printers IIPRT02, IIPRT03 and IIPRT05. Printer IIPRT04 connections are in the color video copier system IIPRT04 section following this section. For more information, refer to the manufacturers' documentation.

- Attach one end of cable NKMR01 to the printer DB25 serial connector. Attach the other end to the OIS PEP printer port. Tighten the connector hood screws.
- Turn printer power on.
- Press the **ON LINE** button on the printer to get local (Lo) mode.
- Press and hold the **PRG** button on the printer to print the current setup.
- If the setup values in this text do not agree with the printed listing for the XLS or XCG, change the setup by pressing **1** to **9** to change the entry for that number on the listing and follow the prompts that are printed.

GENICOM 3410 XLS

The Present Configuration is:

Firmware: 512621 Resolution: MED, Printhead: 18P

1 Font

Style (507339) DP 400 CPS 2/144

CPI - 10.0

Country USA

Mode Normal

2 LPI 6

3 Forms Control

Form Length 11 0

Top Margin 0 0"

Bottom Margin - 0 0

4 Interface Control

Interface Type Serial

Input buffer length 2048

Interface Straps A

0	1	2	3
123456789	0123456789	0123456789	012
000110000	0001000000	0100000001	000

Interface Straps B

0	1	2	3
123456789	0123456789	0123456789	012
110000000	0000000000	0000000000	000

Speed 9600

Parity None

5 Margin Settings

Left Margin 0 0

Right Margin 13 6

6 Horizontal Tab Stops

None

7 Vertical Tab Stops

None

8 Printer Control Straps

Printer Straps A

0	1	2	3
123456789	0123456789	0123456789	012
100010001	0110011000	0000010001	000

Printer Straps B

0	1	2	3
123456789	0123456789	0123456789	012
000001000	1000000001	0000010000	000

9 Emulation Mode Genicom ANSI X3 64

Press the number 0 to return to normal operation
To continue modification select 1 9

GENICOM 3410 XCQ

**The present configuration is:
Firmware: 512623 Resolution MED, Printhead 18P**

```

1 Font
Style (507339) DP 400 CPS 2/144
CPI 10 0
Country USA
Mode Normal
Ribbon Type Process 4 Color

2 LPI 6

3 Forms Control
Form Length 11 0
Top Margin 0 0
Bottom Margin 0 0

4 Interface Control
Interface Type Serial
Input buffer length 2048
Interface Straps A
0 1 2 3
123456789 0123456789 0123456789 012
000110000 0001000000 0100000001 000
Interface Straps B
0 1 2 3
123456789 0123456789 0123456789 012
110000000 0000000000 0000000000 000
Speed 9600
Parity None

5 Margin Settings
Left Margin - 0 0
Right Margin 13 6

6 Horizontal Tab Stops
None

7 Vertical Tab Stops
None

8 Printer Control Straps
Printer Straps A
0 1 2 3
123456789 0123456789 0123456789 012
100010001 1110011000 0000010001 000
Printer Straps B
0 1 2 3
123456789 0123456789 0123456789 012
0000C1000 1001000001 0000010000 000

9 Emulation Mode Genicom ANSI X3 64
    
```

Press the number 0 to return to normal operation
To continue modification select 1 to 9.

Color Video Copier System

Bailey Nomenclature - IIPRT04

The IIPRT04 is used to make a color hard copy of a display on the OIS CRT screen. Do this by pressing the **COPY** button on the copier. Related products for the IIPRT04 are listed in Table 5-5

Table 5 5 Video Copier Related Products

Nomenclature	Description
1948439_1	Color Copier
1948440_1	Video Processor
6634330N10	Centronics Cable
6637356_1-25	OIS Cable
1948465_1	Spare Ink Ro
1948464_1	Spare Paper Ro
NKMC01-25	RGB Cable Assembly
1945080_4	BNC Tee Adapter

OPERATION SUMMARY

The two parts to the color video copier are the video processor and the color copier

The function of the video processor is to capture all needed information from an OIS screen in a matter of seconds. The video processor then sends this information to the color copier. This frees up the OIS screen to enable an operator to continue with his work while the color copy is actually being produced. The video processor has internal memory to store multiple screens. When multiple screens are stored by the video processor, they are printed out in the order they were stored.

The color copier is the device that makes the actual color copy. It takes approximately 45 to 60 seconds to make a color copy of an OIS screen. The copier makes three passes over the paper placing the yellow, red and blue colors on the paper separately. When each screen is printed, the copier aligns itself to make the next copy at which time the color copy just produced may be torn off at the perforation.

INSTALLATION

After unpacking both the copier and video processor place them side by side

Configure Switches

Configure the dipswitches on the rear of the video processor (Figure 5 4) The following information may be useful when configuring the dipswitches

1 Termination for the red, green and blue video signals should be 75 ohms (S1 1 through S1 6 all down)

The signal levels for the video inputs are one volt nominal (S2 1 and S2 2 down)

2 Switch positions S2 3 and S2 4 are for setting the sync These switch positions should be set to sync on the green video input (S2 3 and S2 4 both down).

3 Switch 3 sets the attenuation of our video signals The signal levels for the video inputs are one volt nominal, set these switch positions to the high gain settings (S3 1 through S3 6 all down)




Figure 5 4 Back View of the Color Video Processor

Connect RGB Cables

Connect the red, green and blue video signals from the OIS monitor to the video processor with the NKMC01 RGB cable

If an Intecolor or other color monitor is used, use BNC tee adapters to make the connections from the graphics board to the monitor and from the monitor to the video processor To do this follow these steps

1 Connect the BNC tee adapters (P/N 1945080 1) to the red green and blue connectors on the back of the monitor Make sure the termination switch set to the high impedance setting (nonresistor) Connect the RGB output from the graphics board to one side of the BNC tee adapters

- 2 Connect one end of the NKMC01 RGB cable assembly to the other side of the BNC tee adapters. Connect the other end of the NKMC01 cable to the red, green and blue inputs on the back of the video processor (Figure 5-4).

Connect Color Copier

Connect the video processor to the copier with the Centronics Parallel cable (P/N 6634330 30N25).

1. Connect one end of the Centronics cable to the signal input on the back of the copier.
2. Connect the other end of the Centronics cable to the parallel port connector on the back of the video processor.
3. Connect the OIS video processor cable from the remote port of the video processor to the OIS power entry panel relay contact that will be used to start the capture process. Which relay contact will handle this function is user configurable. This relay contact will be controlled by the print command found on the command line menu of the OIS. Bring up this menu by pressing the command line menu key on the OIS keyboard.

Connect Video Processor

To complete the installation.

1. Connect the DB9 side of the OIS video processor cable to the remote connector on the back of the video processor.
2. Connect the two lugs on the other end of the cable to the relay contact to perform this function.
3. Connect the black wire to the relay terminal labeled C (common). Connect the white wire to the relay terminal labeled NO (normally open).

Video Copier Configuration

To configure the video copier for printing:

1. Call up the *GENERAL PARAMETERS* option of the system configuration screen. Refer to the operation and configuration manual.
2. Select *Video Copier Relay No (1-12)* item on the screen, enter a number and press **Enter**.
3. Press the **RESET** button on the power entry panel to restart the console after making the change. The change will take effect after the console is back on line.

OPTIONAL HARDWARE

- 4 From the logical relay screen:
 - a Select the logical relay to be used
 - b Select the physical relay to be used
 - c Select the keyboard interface to be used (1 or 2)

Printing a Screen

To print a screen display on the copier

- 1 Press **COM'D LINE MENU** to bring up the command line menu at the bottom of the screen
- 2 Enter **C** to assign a printer
- 3 Enter **0** to enable the copier
- 4 Press **COM'D LINE MENU** to bring up the command line menu bar at the bottom of the screen
- 5 Enter **D** to print a screen
- 6 Repeat Steps 1 and 2 to reset the printer assignments.

OPERATION

To make a copy, choose the *PRINT* option from the command line menu. When the **D** key is pressed, the OIS screen is frozen for approximately five seconds. As soon as the screen is frozen, the relay contact (selected in Step 3) starting the capture is closed for a minimum of 10 microseconds. This pulls the capture line on the video processor low. A low on this line tells the video processor to start a screen capture. The video processor then pulls all needed information off the red, green and blue lines of the OIS screen to make a color copy. This takes about three seconds. After all needed information is pulled from the OIS screen, the screen is freed and the operator may continue with his work while the color copy is being produced.

Gammadata Color Video Copier System

Basic Nomenclature - PRT04 (A-size)

The IIPRT04 is used to make a color hard copy of a display on the OIS CRT screen. Do this by pressing the up arrow on the copier until the LCD display shows the number of the monitor to be copied and then pressing the **EXE** button on the copier. Related products for the IIPRT04 are listed in Table 5.6.

Table 5.6. Video Copier Related Products

Nomenclature	Description
1948440 2	Video Processor
6637356_2 xx	O/S Cabinet
1948465 2	Spare Ink Roll
1948464 2	Spare Paper Roll
NKMC01-25	RGB Cabinet Assembly
*945080_4	BNC Tee Adapter

OPERATION SUMMARY

There are two main parts to the color video copier system. These are the video processor and the color copier.

The function of the video processor is to capture all needed information from an OIS screen in a matter of seconds. The video processor then sends this information to the color copier. This frees up the OIS screen to enable an operator to continue with his work while the color copy is actually being produced. The video processor has internal memory to store multiple screens. When multiple screens are stored by the video processor, they are printed out one after another in the order in which they were stored.

The color copier is the device that makes the actual color copy. It takes approximately 45 to 60 seconds to make a color copy of an OIS screen. The copier makes three passes over the paper, placing the yellow, red and blue colors on the paper separately. When each screen is printed, the copier aligns itself to make the next copy, at which time the color copy just produced may be torn off at the perforation.



OPTIONAL HARDWARE

INSTALLATION

Unpack the copier with internal video processor. See (Figure 5 5). There is no voltage select switch.

1. Termination for the red, green and blue video signals should be 75 ohms.

The signal levels for the video inputs are one volt nominal.

2. Set the monitor to sync on the green video input.

3. Refer to the setup manual and setup map for the video copier. The signal levels for the video inputs are one volt nominal.

Connect RGB Cables

Connect the red, green and blue video signals from the OIS monitor to the video processor with the NKMC01 RGB cable.

If an Intecolor or Aydin color monitor is used, use BNC tee adapters to make the connections from the graphics board to the monitor and from the monitor to the video processor. To do this, follow these steps:

1. Connect the BNC tee adapters (Bailey Controls part number 1945080 1) to the red, green and blue connectors on the back of the monitor. Make sure the termination switch is set to the high impedance setting (nonresistor). Connect the RGB output from the graphics board to one side of the BNC tee adapters.

2. Connect one end of the NKMC01 RGB cable assembly to the other side of the BNC tee adapters. Connect the other end of the NKMC01 cable to the red, green and blue inputs on the back of the video processor (Figure 5 5).

Connect Video Processor

To complete the installation:

1. Connect the DB9 side of the OIS video processor cable to the remote connector on the back of the video processor.

2. Connect the two lugs on the other end of the cable to the relay contact to perform this function.

3. Connect the black wire to the relay terminal labeled C (common). Connect the white wire to the relay terminal labeled NO (normally open).

OPTIONAL HARDWARE

OPERATION

Copy a screen by pressing the up arrow on the copier until the LCD display shows the number of the monitor to be copied and then pressing the EXE button on the copier. The OIS screen is frozen for about five seconds. As soon as the screen is frozen, the relay contact (selected in Step 3) starting the capture is closed for a minimum of 0.5 seconds and starts a screen capture. A screen capture takes about three seconds. After all needed information is pulled from the OIS screen, the screen is freed and the operator may continue while the color copy is made.

The menu structure for the video copier is listed in Figure 5.6




Figure 5 5 Gammadata Color Copier




Figure 5 6 Video Copier Menu Structure

Streaming Tape Drive

Barley Nomenclature - DST01

The streaming tape drive peripheral consists of a 60 mega byte cartridge tape drive, interface and power supply. It is used to back up the OIS hard disk with the command **BU** and restore with the command **RU**. The backup/load process takes 40 minutes. For 85 megabyte or greater drives, midway to completion of each command, remove the first tape and insert the second, if needed. The disk controller used by the OIS also controls the tape drive.

The streaming tape unit is supplied with a Centronics D connector cable. See Figure 5.7 to attach the cable (part number 6637714.1) between the power entry panel of the IIOIS20 and the streaming tape unit Centronics D connector receptacle. The IIOIS20A/D has a connector for the D receptacle of the tape unit.

The tape drive unit contains a controller board which is configured by setting jumpers. The jumper settings are factory set and should require no further configuration. To verify the settings, see Figure 5.8.

BACKUP AND RESTORE OPERATION

1. Connect a dumb terminal to P10.
2. Connect the tape drive to the streaming tape port on the IIOIS20 and IIOIS20A/D PEP.
3. Reset the OIS, and press **ENTER** on the terminal within seven seconds after the terminal displays the **SYSTEM RESTART** message.
4. Enter the command **BU** to back up the OIS hard disk to tape, or the command **RU** to restore the hard disk from tape.

Backup tapes can be restored to different types of disk drives if the drive to be loaded has a larger capacity than the original. Refer to Table 5.6a for hard disk drive compatibility.

Table 5.6A. Hard Disk Drive Compatibility

Model	Formatted Capacity (Bytes)
Pr am V150	40, 427, 520
M croscience	58, 720, 256
Pr am V185	66, 863, 104
Maxtor XT-1085	67, 108, 864
Seagate ST4086	68, 198, 400
Pr am 519	150, 282, 240
Maxtor XT-2190	150, 282, 240

OPTIONAL HARDWARE




Figure 5.7. Streaming Tape IIDST01 Cable Connections




Figure 5.8. Streaming Tape Drive Jumper Settings

Nine Track Reel-to-Reel Tape Transport

Ba ey Nomenclature IIDMT01/ IIDMT02

The nine track reel to reel tape transport is a nine track one half inch reel to-reel tape drive. The IIDMT01 mounts in a OIS driver cabinet or IICWS01 work table base. The IIDMT02 sits on a tabletop such as IICWS01. Table 5 7 lists the parts used by the IIDMT01/ IIDMT02.

The IIDMT01 mounts in the IIOIS20A/D OIS driver cabinet. It contains the components of the base tape drive and the parts listed in Table 5 8.

The IIDMT02 consists of the parts listed in Table 5 9 in addition to the basic parts.

*Table 5 7 Reel to Reel Tape (IIDMT01/02)
Basic Parts List*

Quantity	Part Number	Description
1	6637805	Print of Draw ng
1	194776_23001	3 A Slow Blow Fuse
1	1947950 5	Power Cord
1	1948863 50	Ribbon Cable Assembly
1	1948380 1	Magnetic Tape Drive

*Table 5 8 Reel to Reel Tape (IIDMT01)
Parts List*

Quantity	Part	Description Number
12	NTLAC19000	Lock washer
12	NMPCC16002	Nut
12	NANAU16008	Screw
4	6637702_1	Mounting Plate
1	6637701_1	Support Rod
1	6637698_1	Vent Pane
2	6637703 1	Support Pane
1	6637805 1	Base Magnetic Tape Drive

*Table 5 9. Reel to Reel Tape (IIDMT02)
Parts List*

Quantity	Part Number	Description
1	1948863_50	Ribbon Cable
2	1948819_1	Magnetic Tape Unit, Tabletop Mode
3	1948604 1	Tape Reel, 2400 ft

REEL-TO-REEL TAPE UNPACKING

On the tape transport, open the hinged tape guide lid and remove the packing material (Figure 5 9) Unscrew retainers at the left and right front edges and lift the hinged transport mechanism, exposing circuit boards (Figure 5 10) Separate card frames and remove packing material from the boards Unpack CSC 100 SCSI adapter kit




Figure 5 9 Reel to Reel Tape Drive Unit

REEL-TO-REEL TAPE PREPARATION

- 1 At the right back of the M990 transport, locate a two pin, white nylon cable jack marked J9 and pass it out the open in the back of the case
- 2 In the event that no J9 connector is in the wiring harness, locate the provisioned J9 jack with one foot of white and black leads terminating in Faston lugs Clip the lugs, strip and splice the white and black leads to similarly colored wires in the harness Insulate with electrical tape (Feed connector through back of transport)




Figure 5 10. Reel to Reel Tape Transport Mechanism

- 3 Turn power on
- 4 Check for +48 VDC at white lead with respect to black () Correct as needed.
- 5 IIOIS20A/D driver cabinet applications To install the nine track transport in a IIOIS2C A or D driver cabinet use the hardware provided with the IIDMT01 to mount the rails underneath the transport, rather than on the sides, as with the NMTP02. Locate the two support panels and orient with tabs pointing inward on each side. Open transport, unbolt the rack slide hinges and transfer them to the corresponding locations on the left and right support panels Mount support panels to transport sides, through the holes where hinges are mounted.
- 6 Detach and mount the rack rear section of each slide to front and back cabinet rack rails Mount it above the shelf of the NMED01 cabinet or, use the bottom rail pattern of IICWS01 work surface enclosure.

NOTE. When manual tape mounting or service is required the transport must be hinged up in operation

OPTIONAL HARDWARE

7 Lift transport into rail engagement in cabinet (requires a minimum of two people)

SCSI INTERFACE UNIT, CSC-100

- 1 Place unit upright, and remove two screws near tapered edge Lift open hinged lid.
- 2 Locate +48 volt power cable labeled 962031 and insert connector P1 in circuit board location J4, engaging cable plug in the chassis jack clip Seat ROMs in sockets
- 3 Route the loose P2 connector through the large cut out Close the box
- 4 Locate two six inch braided straps Put a box retaining screw through each straps lug, and fasten the box again

REEL-TO-REEL TAPE SETUP

- 1 Locate two 50 pin ribbon jumpers marked 961991. Orient the pin header P2 connector of each so striped edge located at the silk screened 1/2 then insert one each into board locations J1 and J2
- 2 Orient tapered edge of CSC 100 to view LEDs at left and dipswitches to their right (Figure 5 11) Set ID switches one through four open (up) and switch five of right most switch open

REEL-TO REEL TAPE SYSTEM CONNECTIONS

- 1 Rotate power selector at back of tape transport Set to appropriate voltage and frequency. If voltage is 200 to 240 VAC. unplug the unit and pop out (screwdriver 1/4 turn coun terclockwise) adjacent fuse holder and replace fuse with 3 amp slow blow fuse provided
- 2 Use the parallel blade cord from transport s IEC 320 receptacle to a spare receptacle as available If installed in an OIS driver cabinet, use IEC320 male to female cable part number 19447950 5 and connect to power entry panel mag tape receptacle
- 3 With front panel power switch rocked and left permanently on, (system running) measure voltage at transport back J9 connector. white wire and confirm that it is +50 VDC with respect to the black wire Correct as necessary
- 4 Turn off the OIS cabinet breaker and attach the CSC 100 units part number 962031 P2 connector to transport connec tor J9




Figure 5 11. Reel to Reel Tape LED and Switch Location

- 5 Attach left and right ribbon cable P1 connectors to transport connectors P1 and P2 respectively. Cables have stripe to right at transport back. Do not cross the cables.
- 6 Dress cable tagged 962031 and transport power cable down through trough, then hook CSC 100 on back of transport.
- 7 Attach grounding/hanger straps to screws at left and right of transport. Arrangement needs to look like a swing, as installed.
- 8 Dress the end of cable part number 1948863 50 having the strain relief connector down left and front sides of the card cage, striped edge down.
- 9 Attach the other end to either connector on the back box of CSC 100, strips to right. Fully seat the connector.
- 10 Attach cable part number 1948032 31200 to SCSI port on the OIS power entry panel.
- 11 Remove fastener from squared off end of 1/2 inch tape 1200 or 2400 feet reel, and insert with tape uncoiling clockwise through hinge up doorway (Figure 5 12).

OPTIONAL HARDWARE




Figure 5 12 Loading Reel to Reel Tape

12 Fully seat tape on hub, then close door

13 Turn on power to each OIS cabinet, and immediately press transport's **Load** then **On Line** Press the OIS **Reset** button a couple of seconds after turning the breaker ON Whenever the display does not confirm a successful load, load manually by

A Grasp lower left hand door release behind face plate, squeeze and slide out transport

B Lift hood (chock drops into position)

C Thread tape through maze then (holding tachometer arm away) wrap six winds clockwise around take up hub

D Lift chock, close hood and retract transport

E While pressing **Density**, press **Load**, then press **On Line**

Manual Load six wraps around takeup hub, press **Density**, then **Load**

Optical Disk Storage

Bailey Nomenclature - DOP01

Two optical disk models are available for the IIOIS20 The IIDOP01 rack mount unit used with the IIOS20A/D driver cabinet The IIDOP02 tabletop unit used with the IIOS201/2/3 console cabinet.

The IIDOP01 is a Cherokee™ optical disk drive data system with rack mount hardware. (Cherokee P/N 8831-2) Table 5 10 lists the contents of the IIDOP01.

Table 5 10. IIDOP01 Parts List

Quantity	Part Number	Description
1	6637858	Print Of Draw ng
1	1948497 1	Optical D sk Dr ve
1	1948497_3	Optica D sk Med a
1	1947950_5	Line Cord AC
1	1948863 50	R bbon Cab e Assembly
1	6638124 1	Support Ang e
1	6638124 2	Support Ang e
2	6638125 1	Mo,nting C ps
12	NMPCC16002	Nut
12	NBJAU16010	Screw

The optical drive includes one blank double sided media cartridge Extra cartridges can be ordered with Bailey Controls part number 1948497_7.

These instructions are IMPORTANT. To avoid damage to the optical disk drive unit, please read them thoroughly before attempting installation or applying power.

NOTE: In this instruction, IIDOP01 refers the disk drive and hardware package When we refer to the disk drive as a separate unit we call the Cherokee P/N 8831 2 a disk drive unit (s ng e drive)

IIDOP01 UNPACKING

Carefully remove the disk drive unit drive from its shipping carton and verify its contents Save the shipping carton and packing material that accompanied the disk drive unit It can be used during moving and shipping to protect the unit against damage.

Table 5 11 lists the optical disk storage IIDOP01 carton contents

TM Cherokee is a trademark of the Cherokee Data System Inc

Table 5 11 Optical Disk Storage IIDOP01 Carton Contents

Contents	Description
M8831 2	Optical Disk Drive This self contained unit contains the disk drive SCSI controller and power supply in a 19 inch rack mount configuration
Operators Manual	This manual contains detailed operating and maintenance instructions for the disk drive unit
Power Cable	This cable connects the disk drive unit to a local power source
Optical Disk Media	Double sided blank disk with 320 Mbyte per side

Tools required for installation include a flat blade screw driver, a Phillips screwdriver, and a socket flat head number 4 40 wrench

IIDOP01 FEATURES

There are setup, operator and maintenance controls on the front and on the back of the optical disk drive These are the front panel controls

Power On/Off Switch

This pushbutton switch is located on the lower center of the disk drive unit Pressing the switch applies power Pressing the switch again will remove power When power is being supplied to the disk drive unit the switch is illuminated

Cartridge Release Button

This pushbutton switch is located just below the cartridge access door on the drive Depressing the switch allows you to rotate the lock/insert switch In the unlock (insert) condition, the select and ready lights flash alternately Refer to **Select/Status Lights**

Figure 5 13 shows the front view of the IIDOP01 optical disk unit

Ready/Status Light

If the green ready status indicator stays on, the optical drives in the disk drive unit has optical media loaded and is awaiting access from the host computer




Figure 5 13. IIDOP01 Optical Disk Unit Front View

Select/Status Light

The red select status light indicates that the optical drive in the disk drive unit has been selected by the host computer which may be transferring data or status information

Media Access Door

Insert or remove storage media by opening the cartridge access door in the front of the disk drive unit. Open the door by rotating the door release knob from the close position to the open position. Prior to operation, the door release knob should be in the close position for reliable drive operation. Opening or closing the door release knob does not require power to the drive.

Back Panel Features

Figure 5 14 shows the back panel of the disk drive unit.

This list contains the back panel features of the IIDOP01 disk drive unit.

- SCSI Connector
- AC Power Input Connector
- Fuse Holder
- AC Power Input Setting
- Drive Serial Number
- SCSI Address Selector
- Main AC Power ON/OFF Switch

SCSI Connector

The SCSI connector connects the host computer and the SCSI controller in the disk drive unit. The SCSI connector is located in the right rear corner of the rear panel.




Figure 5 14 IIDOP01 Optical Disk Unit Back View

Power Input Connector

The power input connector provides power connection to the disk drive unit. This connector is located next to the fuse holder at the lower left side on the rear of the disk drive unit.

Fuse Holder

The fuse holder is located inside the fuse/voltage access panel on the rear panel of the disk drive unit.

Power Input Setting

The power input setting is located inside the fuse/voltage access panel.

SCSI Address Selector

The address selector is located on the upper left corner. The SCSI address for the optical drive is assumed to be one by the system.

Drive LUN Number

The factory set disk drive logical unit number (LUN) number is zero.

Drive Serial Number

The disk drive unit serial number is located at the center of the back panel. Figure 5 14 shows the back view of the IIDOP01 Optical Disk Unit.

IIDOP01 INSTALLATION

To install the IIDOP01, first install and align the mounting bracket assembly. Table 5 12 lists the required installation materials.

Table 5 12. IIDOP01 Installation Hardware

Quantity	Description	Figure 5-14 Call Out
1	Print Drawing 6637858	
12	NBJAU16010 Screw	A
12	NMPCC16002 Nut	B
2	6638125_1 Mounting Clip	C
1	6638124_1 Support Angle	D
1	6638124_2 Support Angle	E

Rail Assembly

See Figure 5 15 to assemble the rack mount side rails (mounting bracket).

NOTE: Do not over tighten the mounting clip screws until the rails are adjusted to fit the rdes red cabinet.




Figure 5 15 Mounting Bracket Assembly

Rail Alignment and Installation

- 1 Place the rails one at a time in the cabinet and adjust the length. Do this by lining up the front and rear screw holes on the bracket to the front and rear screw holes on the cabinet. Figure 5 16 shows the screw hole location for bracket adjusting. Mark the mounting clip position on the support angle.
- 2 Remove the rail assembly from the cabinet and tighten the mounting clip screws at desired length.




Figure 5 16 IIOIS20A/D Cabinet Mounting

3 After tightening the mounting clip screws, reinstall the rails and mount it to the cabinet using screws and nuts provided

NOTE Make sure rails are at equal heights on both sides of the cabinet

4 With rails firmly in place slide the disk drive unit in the cabinet on top of the rails and fasten the rack mount handle screws to the holes in the cabinet rack

Figure 5 17 shows the optical disk unit installed

IIDOP01 CONFIGURATION

- 1 Using the grounding strap to ground yourself to the computer chassis ground
- 2 Turn off the computer main power using power down procedures
- 3 Connect one end of the ribbon cable assembly to the SCSI port on the power entry panel and the other end to the I/O connector 1 or 2 of the disk drive unit.

NOTES

- 1 Observe pin location when connecting the ribbon cable to SCSI interface board and optical disk drive
- 2 The SCSI ID selection for the disk drive unit has to be a one




Figure 5 17. IIDOP01 Optical Disk Unit Installed

4 Plug the AC line cord into the power entry panel of the computer. Termination of power is provided by the disk drive unit in all configurations.

Table 5 13 shows the SCSI ID selection jumpers

Table 5 13 SCSI ID Selection Jumpers

SCSI ID ¹	Pin 1	Pin 2	Pin 3
0	OFF	OFF	OFF
1	OFF	OFF	ON
2	OFF	ON	OFF
3	OFF	ON	ON
4	ON	OFF	OFF
5	ON	OFF	ON
6	ON	ON	OFF
7	ON	ON	ON

NOTES

1 Some replacement units require removing the case to set a summer jumper pattern on the rear most circuit board

2 This table is located at the rear of the M8831 2 *

OPTIONAL HARDWARE

IIDOP01 POWER SETTINGS

The disk drive unit has been set at the factory for United States power, 120 VAC 47 to 440 hertz. The disk drive unit may be operated on 120 VAC, 47 to 440 hertz or 240 VAC, 47 to 440 hertz by changing the input power setting.

CAUTION

Incorrectly setting the input power select may damage the disk drive unit.

ATTENTION

Un mauvais réglage de la sélection de l'alimentation d'entrée pourrait endommager l'unité de disque.

Changing the Power Setting

Change the input power setting by following these steps:

- 1 Disconnect the AC power cord at the back of the disk drive unit.
- 2 Locate the input power module at the back right corner of the disk drive unit.
- 3 The input power access panel is below the power ON/OFF switch. Using a flat blade screw driver, pry open the access panel. Remove the voltage select wheel, turn to the proper voltage and replace. The selected input voltage should be displayed.

Fuse Replacement

The disk drive unit is protected with two fuses located at the back of the disk drive unit. The fuse rating is 25C volts at 3 amps. To replace a fuse, follow these steps:

- 1 Disconnect the power cord at the back of the disk drive unit.
- 2 Locate the input power module at the back right corner of the disk drive unit.
- 3 Locate the fuse/voltage access panel located below the power ON/OFF switch. Pry open the access panel with a flat blade screwdriver.
- 4 Locate fuses below the power select wheel. Remove the defective fuses. The arrow on the fuse holder should point left.
- 5 Close the access panel.

IIDOP01 WIRING AND CABLING

1 Connect the 50 pin ribbon cable to the SCSI port on the OIS power entry panel. Connect the other end to either of the SCSI connectors on the back of the disk drive

The materials required are listed in Table 5 14

Table 5 14. Optical Disk Unit IIDOP01 Wiring Hardware

Quantity	Part Number	Description
1	1948497_1	Opt cal Disk Dr ve
1	1947950A5	AC L ne Cord
1	1948863_50	R bbon Cab e Assemb y
1		Ground ng Wr st Strap

NOTE: The disk drive unit should st be unplugged

2. Connect the SCSI terminator block to the other SCSI connector on the disk drive.

NOTE: This terminator must be instal ed for proper operat on

3. Plug the AC line cord into the power entry panel of the computer or into another AC outlet Power cords are provided for IEC320 and United States outlets. Be sure that the AC outlet matches the AC power selected on the disk drive

IIDOP01 OPERATION

Operation consists of using the disk drive unit and the stor age media Media types and how to use them in the disk drive unit are explained in this section

Power Up the Disk Drive

After you install the hardware with the steps in this section, turn power on by pressing the rocker switch on the back panel.

Optical Media

The disk drive unit can be used with either single sided or double sided media. The optical media is enclosed in a car tridge with spring loaded slides which open when the cartridge is inserted in the disk drive unit The banded end of the media cartridge is always inserted first into the optical drive In addition, there are arrows located on the cartridge indicating the proper orientation

OPTIONAL HARDWARE

Single Sided Media Single sided media permits recording on only one side of the media. The user capacity of this media is in excess of 320 megabytes. This does not include spare data tracks which are automatically allocated for use by the SCSI controller defect management microcode. Single sided media must be inserted A side up for proper orientation of the recorder surface to the optical recording head.

Double Sided Media Double sided media permits recording on both sides of the media. Each side is capable of storing in excess of 320 megabytes.

Media Storage The optical media cartridge protects the media. We recommend

1. When powering down the optical drive for extended periods of time, remove the optical media to protect it from damage.

2. The optical media cartridge should be stored in a dust free environment.

3. The optical media will withstand storage temperature of 40 to + 75 degrees centigrade. Do not store disks in extreme heat and sunlight.

4. Optical media stored in excessively cold temperature should be given several minutes to reach temperature stability before inserting it into the optical drive. This also helps eliminate condensation which may occur on an extremely cold surface.

Media Loading with Power

The media has two sides A and B. Choose which side will be used first (normally A).

If the lock/insert switch on the front panel is in the insert position, insert the optical disk cartridge (metal banded end in first) into the disk drive unit until encountering a firm stop. A fully inserted cartridge will be totally contained within the drive. Rotate the lock/insert switch to the lock position. The optical disk will recalibrate and indicate a ready status (green light on front of panel).

Should the lock/insert switch be in the lock position, press the cartridge release button. The select and ready lights will alternately flash. This indicates that the lock/insert switch has been unlocked and may be rotated counter clockwise to the insert position.

The lock/insert switch can only be rotated to the insert position while the select and ready lamps are flashing. If the lamps stop flashing before turning the switch to insert, the lock switch will again be locked in the lock position. Press cartridge release button again and rotate the lock/insert switch to insert position while the lights are flashing. This may be repeated without damage to the disk drive unit. A cartridge can now be inserted using the above procedure.

Media Unloading with Power

To unload a cartridge from the disk drive unit with power applied, press the cartridge release switch. The select and ready lights will alternately flash indicating that the lock/insert switch has been unlocked. The switch may now be rotated counter clockwise to the eject position. Rotate the switch until the cartridge is released and ejected from the disk drive unit. The lock/insert switch is locked when it is in rotated in the lock position to prevent an accidental ejection of the cartridge. The lock/insert switch may only be rotated from lock to insert when the cartridge release switch has been depressed and the select and ready lamps are flashing. If the lamps stop flashing and the lock/insert switch has not been rotated, the cartridge remains loaded and the lock/insert switch is again locked. Pressing the cartridge release switch again will unlock the lock/insert switch (select and ready flashing) and the lock switch may be rotated to the eject position ejecting the cartridge.

NOTE: If the cartridge release switch is pressed and the lock/insert switch has not been rotated, the cartridge remains loaded but the disk drive unit is in a not ready condition.

To bring the disk drive unit to a ready state (green light), press the cartridge release switch, wait until the select and ready lights flash, then press cartridge release again. The disk drive unit will recalibrate and become ready.

Media Unloading with No Power

You can remove an optical cartridge when unit power is turned off. Do this by inserting a small, round rod (paper clip will be adequate), approximately one inch through the small opening above the insert label. This releases the lock/insert switch and the switch may be rotated to the eject position. This method should only be used when power cannot be applied to the unit and removal of the cartridge is desired. The optical disk cartridge should be removed from the unit before the unit is powered down. Leaving the cartridge inserted, leaves the media exposed with the cartridge access door open.

OPTIONAL HARDWARE

IIDOP01 TROUBLESHOOTING

The troubleshooting guide in Section 6 will help answer your questions. In addition, Cherokee provides assistance at (303) 776 0721 to answer additional questions on the disk drive unit. When calling indicate that technical assistance is required and give the serial number of your disk drive unit.

IIDOP01 MAINTENANCE

The disk drive unit is designed for maintenance free operation. There is only one maintenance procedure recommended for the disk drive unit and that is to clean the input filter. This filter is located on the back panel. Remove, clean and replace the filters when they are dirty by following the procedure in Section 7.

Optical Disk Storage

Bailey Nomenclature - IIDOP02

Two optical disk models are available for the IIOIS20. The IIDOP01 rack mount unit used with the IIOS20A/D driver cabinet. The IIDOP02 tabletop unit used with the IIOS201/2/3 console cabinet.

The IIDOP02 Cherokee optical disk drive data system is a compact, tabletop configuration. It is used for archiving data, it cannot be used to back up the hard disk. Table 5-15 lists the IIDOP02 parts.

*Table 5 15 Optical Disk Storage
IIDOP02 Parts List*

Quantity	Part Number	Description
1	1948497_6	Optical Disk Drive Tabletop
1	1948758_1	SCSI Terminator
1	1947950A5	AC Line Cord
1	1948825_50	SCSI Ribbon Cable Assembly

The optical drive includes one blank double sided media cartridge. Extra cartridges can be ordered with Bailey Controls part number 1948497_7.

These instructions are **IMPORTANT**. To avoid damage to the optical disk drive unit, please read them thoroughly before attempting installation or applying power.

NOTE: In this instruction, IIDOP02 refers to the disk drive and hardware package. The Cherokee Model 612 is referred to as a disk drive unit.

IIDOP02 UNPACKING

Carefully remove the disk drive unit from its shipping carton and verify its contents.

Save the shipping carton and packing material that accompanied the disk drive unit. It can be used during moving and shipping to protect the unit against damage.

Table 5 16 lists the optical disk storage IIDOP02 carton contents.

OPTIONAL HARDWARE
Table 5 16 Optical Disk Storage IIDOP02 Carton Contents

Contents	Description
M612 Opt ca D sk Dr ve	This self contained unit contains the disk drive, SCSI controller and power supply in a 19 inch rack mount configuration
Operators Manua	This manual contains detailed operating and maintenance instructions for the disk drive unit
Power Cab e	This cable connects the disk drive unit to a local power source
Opt ca D sk Media	Double sided blank disk with 320 Mbyte per side

IIDOP02 FEATURES

There are setup, operator and maintenance controls on the front and on the back of the optical disk drive

Front Panel Controls

The front panel controls consist of the cartridge release button

Cartridge Release Button This pushbutton switch is located just below the cartridge access door on the drive. Press the switch and rotate the lock/insert switch. In the unlock (insert) condition, the select and ready lights flash alternately. Refer to **Select/Status Lights**.

Figure 5 18 shows the front panel of the IIDOP02 Optical Disk, disk drive unit.

Ready/Status Light If the green ready status indicator stays on, the optical drive in the disk drive unit has optical media loaded and is awaiting access from the host computer.

Select/Status Light The green select status light indicates that the optical drive in the disk drive unit has been selected by the host computer which may be transferring data or status information.




Figure 5 18 IIDOP02 Optical Disk Unit Front View

Back Panel Features

This list contains the back panel features of the IIDOP02 disk drive unit

- SCSI Connector
- AC Power Input Connector
- Fuse Holder
- Power On/Off Switch
- AC Power Input Setting
- Drive Serial Number
- SCSI Address Selector
- Main AC Power ON/OFF Switch

- SCSI Connector** The SCSI connector connects the host computer and the SCSI controller in the disk drive unit. The SCSI connectors are located in the left back corner of the back panel.
- Power Input Connector** The power input connector provides power connection to the disk drive unit. This connector is located below the fuse holder at the lower right side on the back of the disk drive unit.

OPTIONAL HARDWARE

- Fuse Holder** The fuse holder is located inside the fuse/voltage access panel on the back panel of the disk drive unit
- Power On/Off Switch** This pushbutton switch is located on the lower center of the disk drive unit. Pressing the switch applies power. Pressing the switch again will remove power. When power is being supplied to the disk drive unit the switch is illuminated
- Power Input Setting** The power input setting is located inside the fuse/voltage access panel
- SCSI Address Selectors** The address selector is located on the upper left corner behind a sliding metal door. Change the SCSI address by pressing the small button below the display.
- SCSI Address** The SCSI address for the optical drive is assumed to be one by the system
- Drive LUN Number** The factory set disk drive logical unit number (LUN) number is zero

Figure 5 19 shows the back panel of the IIDOP02 disk drive unit




Figure 5 19 IIDOP02 Optical Disk Unit Back View

IIDOP02 DISK DRIVE SETUP

Power Settings

The disk drive unit has been set at the factory for United States power, 120 VAC 47 to 440 hertz. The disk drive unit may be operated on 120 VAC, 47 to 440 hertz or 240 VAC 47 to 440 hertz by changing the input power setting

CAUTION	Incorrectly setting the input power select may damage the disk drive unit.
ATTENTION	Un mauvais réglage de la selection de l'alimentation d'entree pourrait endommager l'unité de disque.

Change the input power setting by following these steps

1. Disconnect the AC power cord at the back of the disk drive unit.
2. Locate the input power module at the back right corner of the disk drive unit
3. The input power access panel is below the power ON/OFF switch. Using a flat blade screw driver, pry open the access panel. Remove the voltage select wheel, turn to the proper voltage and replace. The selected input voltage should be displayed.

Fuse Replacement

The disk drive unit is protected with two fuses located at the back of the disk drive unit. The fuse rating is 250 volts at 3 amps. To replace a fuse, follow these steps:

1. Disconnect the power cord at the back of the disk drive unit
2. Locate the input power module at the back right corner of the disk drive unit.
3. Locate the fuse/voltage access panel located below the power ON/OFF switch. Using a flat blade screwdriver, pry open the access panel.
4. Locate fuses below the power select wheel. Remove the defective fuses. The arrow on the fuse holder should point left
5. Close the access panel

IIDOP02 WIRING AND CABLING

1. Use the grounding strap to ground yourself to the computer chassis ground
2. Turn off the computer main power using power down procedures

NOTE The SCSI ID selection for the disk drive unit must be set to one for applications

3. Connect the 50 pin ribbon cable to the SCSI port on the OIS power entry panel. Connect the other end to either of the SCSI connectors on the back of the disk drive

The materials required for Step 3 are listed in Table 5 17

Table 5 17 Optical Disk Unit IIDOP02 Wiring Hardware

Quantity	Part Number	Description
1	1948497 6	Optical Disk Drive Tab stop
1	1947950A5	AC Line Cord
1	1948825 50	Ribbon Cable Assembly
1		Grounding Wrist Strap

NOTE The disk drive unit should still be unplugged

4. Connect the SCSI terminator block to the other SCSI connector on the disk drive

NOTE. This terminator must be installed for proper operation

5. Plug the AC line cord into the power entry panel of the computer or into another AC outlet. Power cords are provided for IEC320 and United States outlets. Be sure that the AC outlet matches the AC power selected on the disk drive

IIDOP02 OPERATION

Operation consists of using the disk drive unit and the storage media. Media types and how to use them in the disk drive unit are explained in this section.

Power Up the Disk Drive

After You Install The Hardware With the steps in this section, turn power on by pressing the rocker switch on the back panel

Optical Media

The disk drive unit can be used with either single sided or double sided media. The optical media is enclosed in a cartridge with spring loaded slides which open when the cartridge is inserted in the disk drive unit. The banded end of the media cartridge is always inserted first into the optical drive. In addition, there are arrows located on the cartridge indicating the proper orientation.

Single Sided Media Single sided media permits recording on only one side of the media. The user capacity of this media is in excess of 320 megabytes. This does not include spare data tracks which are automatically allocated for use by the SCSI controller defect management microcode. Single sided media must be inserted A side up for proper orientation of the recorder surface to the optical recording head

Double Sided Media Double sided media permits recording on both sides of the media. Each side is capable of storing in excess of 320 meagbytes

Media Storage The optical media cartridge protects the media We recommend

- 1 When powering down the optical drive for extended periods of time Remove the optical media to protect it from damage.
- 2 The optical media cartridge should be stored in a dust free environment.
- 3 The optical media will withstand storage temperature of 40 to + 75 degrees centigrade Do not store disks in extreme heat and sunlight.
4. Optical media stored in excessively cold temperature should be given several minutes to reach temperature stability before inserting it into the optical drive This also helps eliminate condensation which may occur on an extremely cold surface

Media Loading with Power

The media has two sides A an B Choose which side will be used first (normally A)

If the lock/insert switch on the front panel is in the insert position, insert the optical disk cartridge (metal banded end in first) into the disk drive unit until encountering a firm stop. A fully inserted cartridge will be totally contained within the drive. Rotate the lock/insert switch to the lock position The optical disk will recalibrate and indicate a ready status (green light on front of panel)

Should the lock/insert switch be in the lock position, press the cartridge release button. The select and ready lights will alternately flash. This indicates that the lock/insert switch has been unlocked and may be rotated counter clockwise to the insert position.

The lock/insert switch can only be rotated to the insert position while the select and ready lamps are flashing. If the lamps stop flashing before turning the switch to insert, the lock switch will again be locked in the lock position. Press cartridge release button again and rotate the lock/insert switch to insert position while the lights are flashing. This may be repeated without damage to the disk drive unit. A cartridge can now be inserted using the above procedure.

Media Unloading with Power

To unload a cartridge from the disk drive unit with power applied, press the cartridge release switch. The select and ready lights will alternately flash indicating that the lock/insert switch has been unlocked. The switch may now be rotated counter clockwise to the eject position. Rotate the switch until the cartridge is released and ejected from the disk drive unit. The lock/insert switch is locked when it is rotated in the lock position to prevent an accidental ejection of the cartridge. The lock/insert switch may only be rotated from lock to insert when the cartridge release switch has been depressed and the select and ready lamps are flashing. If the lamps stop flashing and the lock/insert switch has not been rotated, the cartridge remains loaded and the lock/insert switch is again locked. Pressing the cartridge release switch again will unlock the lock/insert switch (select and ready flashing) and the lock switch may be rotated to the eject position ejecting the cartridge.

NOTE: If the cartridge release switch is pressed and the lock/insert switch has not been rotated, the cartridge remains loaded but the disk drive unit is in a not ready condition.

To bring the disk drive unit to a ready state (green light), press the cartridge release switch, wait until the select and ready lights flash, then press cartridge release again. The disk drive unit will recalibrate and become ready.

Media Unloading with No Power

Remove an optical cartridge when unit power is turned off. Do this by inserting a small, round rod (paper clip will be adequate), approximately one inch through the small opening above the insert label. This releases the lock/insert switch and the switch may be rotated to the eject position.

This method should only be used when power cannot be applied to the unit and removal of the cartridge is desired. The optical disk cartridge should be removed from the unit before the unit is powered down. Leaving the cartridge inserted, leaves the media exposed with the cartridge access door open.

IIDOP02 TROUBLESHOOTING

The troubleshooting guide in Section 6 will help answer your questions. In addition, Cherokee provides assistance at (303) 776-0721 to answer additional questions on the disk drive unit. When calling indicate that technical assistance is required and give the serial number of your disk drive unit.

IIDOP02 MAINTENANCE

The disk drive unit is designed for maintenance free operation. There is only one maintenance procedure recommended for the disk drive unit and that is to clean the input filter. This filter is located on the back panel. Remove, clean and replace the filters when they are dirty by following the procedure in Section 7.

Touch Screen

Bailey Nomenclature IIATS01 Lower Monitor
 Bailey Nomenclature IIATS02 Upper Monitor

A touch screen provides a means of selecting display options by touching the desired area on the monitor screen. Up to two touchscreen controller cards can be mounted onto the IIMKM01 card. The first touchscreen controller card mounts onto the component side of IIMKM01 card. The second touchscreen controller card is identical to the first and mounts onto the solder side of IIMKM01 card. Figure 5-20 shows the touch screen controller card connections. The touch screen card interprets signals from the touchscreen CRT overlay and sends them to the IIMKM01 card. One touch screen may be installed per color monitor. This option requires the addition of a touch screen and touch screen controller card.

Table 5-18 lists the parts included with the IIATS01.

Table 5-18. Touch Screen Parts

Nomenclature	Description
1948026_3	19 in Touch Screen
1948027_3	Touch Screen Controller Module
1948644_5	Extension Cable for Touch Screen on the Upper Monitor (IIATS02)

TOUCH SCREEN CONTROLLER CARD INSTALLATION

See Figure 5-21 for dipswitch settings and wiring connections of the touch screen controller card.

NOTE Before you attach the touch screen ribbon cable to the controller board, ground the capacitive charge on the touch screen to the monitor case ground.

1. Insert one end of a straight pin or 24 AWG wire into either outside touch screen cable connector contact.
2. Press the other end of the pin or wire to the monitor case ground.

NOTE Failure to perform this may damage the MOS FETS on the controller by the stored charge from the 25 kVovts anode during picture tube operation.




Figure 5-20. Touch Screen Controller Card Connections

TOUCH SCREEN INSTALLATION

Follow the directions in the touch screen installation kit

- 1 Remove the CRT by following the instructions in Section 6

WARNING

The CRT will slide out the rear of the IIOIS20 and IIOIC20 cabinet by itself when the mounting bolts are removed. Removing the rear two bolts without supporting the CRT could cause personal injury.

AVERTISSEMENT

Lorsque les boulons d'ancrage sont retirés, l'écran cathodique risque de sortir à l'arrière de l'armoire IIOIS20 et IIOIC20. Si les deux boulons d'ancrage arrière sont retirés, il faut retenir l'écran afin d'éviter toute blessure.

OPTIONAL HARDWARE




Figure 5 21 Touch Screen Controller Card Dipswitch Settings

Follow the directions in the installation kit to attach the touch screen to the face of the CRT Use the Velcro supplied in the kit

2 Connect the cable to the touch screen controller card Note that pin one on the cable has the red stripe. The touch screen controller card is attached to the IIMKMO1 card with four nylon spacers and screws.

Touch Screen Calibration

Touch Screen Controller I D. Number E271-150C, part number 1947027_3

An on line calibration utility is provided in the software

NOTE: The ROM label on the touch screen controller board must have the checksum 1448. If this checksum number is not on the ROM label, contact the nearest Bailey Controls service representative to obtain an update

Trackball

Bailey Nomenclature ATB01

The trackball option permits faster cursor positioning during normal operator control or configuration. The trackball plugs into the operator keyboard interface panel. See Figure 5 22 for cable connections.




Figure 5 22. Trackball/Mouse Connections

Mouse

Bailey Nomenclature - 1 AMS01

The mouse option permits faster cursor positioning during normal operator control or configuration. The mouse plugs into the operator keyboard interface panel located to the right of the CRT. See Figure 5-22 for cable connections.

23 06 54 04 10 07

Bailey

SECTION 6 - TROUBLESHOOTING

INTRODUCTION

This section explains how to troubleshoot the IIOIS20/IIOIC20. It contains troubleshooting tables, component tests and firmware tests.

Replace components by following the procedures in Section 8. Refer to information in Sections 4 and 5 when replacing parts. Review specific adjustments associated with replaceable parts before returning the system to normal operation. Close and secure cabinet doors after troubleshooting or replacing parts in the IIOIS20/IIOIC20 before returning the system to normal operation

Be sure to follow all warnings, cautions and notes. Put circuit boards containing MOS devices into antistatic bags when stored or shipped back to the factory. Do not repair printed circuit boards in the field. All repairs and adjustments should be performed by qualified personnel

TROUBLESHOOTING

The IIOIS20/IIOIC20 is shipped ready for operation. After completing the instructions given in Section 3, prepare the unit for service. The troubleshooting guide in Table 6.1 helps identify problems and suggest solutions

Table 6.1. Troubleshooting Guide

Symptom	Possible Problem or Solution
No power indicator on circuit	No AC power at OIS Check AC wiring on input Check AC on power entry pane Check breaker light on power entry pane
Breaker off but indicator on	Check breaker contacts Check breaker wiring Check AC input wiring
No green indicator (LED) on IIMPM0	Check power at supply Check ripple at supply Check fuses Check power at backplane Check IIMPM0 LED Check IIMPM0 jumpers Check reset line and PF. Check reset switch (faulty?) Check remaining module jumpers Check ROMs.

Table 6 1 Troubleshooting Guide (continued)

Symptom	Possible Problem or Solution
No green indicator (LED) on I MPM0 (continued)	Check I MPM0_ cables Pull out modules one by one - start with IIMG001 module, then I MSM01 module, etc
Green LED comes on but goes off quickly	Check all power points as before Check all switch and jumper settings for all modules Check SAS disk drive controller module hard disk drive floppy disk drive in combination, including all cables
No prompt or disk I/O or time out	Check SASI - OMTI etc as above Check terminal settings Check I MPM0_ /terminal cable - RS-232 drivers (1488, 1489) Check ROMS
Improper/ incomplete start up	See diagnostic message at start up for possible problems
Start up OK but no N U response	Check N U settings (checksum on port A at 19 2 kbytes) Check N U cables Check MSM01 module jumpers Try using N U diagnostic port to test I MCL01/ MLM01/ MCP01 modules
Start-up OK but no keyboard response	Check IIMSM01 module and jumpers Check all cables Check caps lock position Check IMKM01 module Check OIS configuration (keyboards/ printers) Check keyboard assignment
Start up OK no CRT picture	Check CRT AC power Check CRT fuse Check RGB cables Check MGC01 Check CRT switches (sync on green) Check 75 ohm termination
No printer response	Check AC power Check I MSM01 modules Check cables Check printer setup Check OIS configuration (printers) Check printer directories (logging) for corruption

DIAGNOSTIC POWER UP TESTS

If the troubleshooting guide fails to identify a problem in the IIOIS20, IIOIS20A or IIOIC202, follow the AC and DC power test procedures. For tabletop models, refer to the manufacturer's documentation. Check the IIOIC203 DC voltages on the DC distribution board and the AC voltages at the line input to the power entry panel

AC Power Test

NOTE: When the instructions state to apply power to the O S/O C, switch the main breaker to the ON position (see Figure 6 1). To turn off the power, switch the main circuit breaker to the OFF position

1. Turn off power to the IIOIS20, IIOIS20A or IIOIC20. Disconnect AC power to all equipment inside the console by unplugging the line cords from the back of the power entry panel
2. Apply power to the OIS/OIC by switching on the line circuit breaker located at the front of the power entry panel (PEP)
3. Use a digital voltmeter to measure the AC power at each of the outlets (J1 through J4) on the PEP. The line voltage should be 102 to 132 VAC RMS for a 120 VAC input and 224 to 252 VAC for a 240 VAC input




Figure 6 1. Main Circuit Breaker (CB1)

- 4 Use the digital voltmeter to check each outlet and insure that neutral, live and ground are wired correctly, and there are no ground faults See also Figure 4 41
- 5 Turn off the power to the OIS/OIC Verify that it removes power from all outlets
- 6 Plug the color monitor power cord into the AC socket in the rear of the PEP DO NOT plug in the main power supply yet. Apply power to the OIS/OIC Nothing will be displayed on the color monitor until the system software is loaded

DC Power Test

Necessary test equipment consists of a digital voltmeter.

- 1 Turn off power to the IIOIS20/IIOIS20A/IIOIC202

NOTE Do not disconnect the power wiring from the multibus card cage

- 2 Unplug DC power distribution cables from all peripheral devices (disk drives, disk drive controller module, ADP panel and keyboard interface board, if present) Disconnect the power cables at the distribution side of the cables.

3. Apply power to the OIS.

- 4 Verify operation of the output out of tolerance (OOT) signal by turning the main (+5 volt) power supply channel all the way down and monitor the OOT signal at pin 3 of J1 on the power supply The OOT should go from 0 volt (power good) to +5 volts (power out is not good) Verify that this causes the console to enter the reset mode Return the voltage to the normal value and verify that the OOT returns to +5 volts

NOTE. This step applies only to the OIS

- 5 Turn off the power to the OIS/OIC

NOTE Turn power off before removing or inserting multibus modules

- 6 Unplug all multibus modules from the card cage. The modules do not have to be pulled all the way out Pull them out only a few inches from the module edge connectors

- 7 Plug the power line cord for the power supply into the PEP.

8. Ensure that ALL power supply wiring is correct. Refer to Section 4, Figures 4-32, 33 and 34, and Table 4-14 for the OIS power supply. Refer to Section 4, Figures 4-36, 37 and 38, and Table 4-15 for the OIC power supply. Refer to Section 4, Table 4-15 for the OIC slide in power supply.

9. Apply power to the OIS/OIC.

10. Measure the DC voltages at the multibus card cage backplane. See Figure 4-4 for the location of the terminal blocks to measure the backplane voltages.

11. If necessary, adjust the DC voltages at the power supply (Figure 6-2).

Adjust the voltages to +0.25 VDC and 0.0 VDC of the following values, if needed. A final adjustment will be made later with the power supply under load. Measure the +5.00 VDC +12.00 VDC, and 12.00 VDC at the rear of the multibus backplane.

NOTE:

1. Unstable operation may result if the power supply voltages are not in tolerance.
2. DO NOT adjust the OL and OVP settings. These adjustments are factory set.

12. Turn off the power to the OIS/OIC. Plug in all multibus modules.

13. Reconnect all DC power distribution cables.

14. Apply power to the OIS/OIC and check the DC voltage levels again. Adjust the power supply to obtain the voltage within a tolerance of ± 0.05 volts.

MULTIBUS CARD CAGE AND SUBASSEMBLY TESTS

Multibus card cage and subassembly tests consist of running a set of software driven tests to confirm that each module or subassembly within an IIOIS20/IIOIS20A works by itself. The sequence of testing first proves that lower level parts work correctly, then these parts are used to test the rest of the system. The tests assume that the power wiring is correct, and that the DC power levels, cable routing and cable connections are correct.




Figure 6 2 IIOIS20, IIOIS20A and IIOIC202 Matr Power Supply

The equipment necessary for these tests is:

- A dumb terminal (Wyse 50, Falco 5500E or equivalent) part number: IIVTE01.
- A nine pin RS-232C cable (25 pin DB connector male to male) part number: NKMR01 25.
- A null RS 232C cable (nine pin connector with pins two and three crossed over) part number: HCBL02.

Initial Setup

Equipment set up to test the multibus.

NOTE: When a dumb terminal is connected to a multibus processor module, it will be referred to as a Monitor 68K terminal.

1. Connect a Monitor 68K terminal to the IIMPM0 (P10 on the PEP)
2. Using a standard nine conductor RS 232C cable with 25 pin D male connectors on each end, connect one end to the modem port of the terminal
3. Connect the other end to the channel A port on the IIMPM0 using P10 on the power entry panel.
4. Set up the Monitor-68K terminal for seven data bits one stop bit, no parity and 9600 baud.

Test Multibus Processor Module (IIMPM0)

1. Connect the Monitor-68K terminal to the P10 connector on the PEP. Apply power to the OIS
2. Enter the monitor mode by pressing on the keyboard within seven seconds after applying power to the OIS, otherwise the operating system will load. If this time frame is passed, reset the OIS and repeat this step.

After entering the monitor mode, the screen shows a new line and a *l.>* prompt

3. This is the processor self test. This is not a conclusive test of all features of the IIMPM0 Multibus Processor Module

Type. **PT**

If this test is successful, the monitor shows a new line and a *l'>* prompt

If the test fails, the monitor may not respond display a memory register dump (a string of alphanumeric characters appearing on the screen) or display the message, *CPU ERROR*. If the test fails, try checking all switch and jumper settings on the IIMPMO module or try a new IIMPMO. Repeat this test until the test passes.

4 This step performs a memory block test on the memory.

Type **BT 1500 7FFFFE**

Wait for a prompt or an error message. If there is an error message, replace the IIMPMO module and repeat the processor self test and the memory block test.

If successful, this test returns a prompt in about one minute. Continue when the prompt returns.

Test Multibus Graphics Controller Module (IIMGC01)

Connect the Monitor 68K terminal to P10 on the power entry panel. Press on the terminal. If this test is successful, the monitor shows a new line and a *!>* prompt.

NOTE. Since the switch settings differ on module one and two, they are NOT interchangeable.

Test Multibus Graphics Controller Module One (IIMGC01)

This procedure describes self test status for the multibus graphics controller. Use these commands to test the first multibus graphics controller module. To start the self test on the first IIMGC01 module:

Type **VT 0**
DM 3F90000

Within about six to seven seconds, the OIS monitor will display a series of blue, then green stripes. The self test returns a prompt if it is successful. If the self test fails, the message *Self Test Failed* will be displayed.

NOTE. Ignore the message *MEM ACCESS ERROR*.

Refer to Table 6-2 for error codes. If the test fails, replace the card.

Table 6-2 Multibus Graphics Controller Module Self Test Status

Code	Meaning	Action
10	Illegal command	Verify syntax and enter again
11	Stack overflow	Reset O/S and test again
12	Stack underflow	Reset O/S and test again
13	Self-test OK	Test complete, continue with the next test
14	Program error	Reset O/S and test again
15	Circular buffer full	Reset O/S and test again
16	Reset completed	Test again
17	Illegal tracking command	Verify syntax and enter again
18	Illegal nking command	Reset O/S and test again
19	Illegal rubberband command	Verify syntax and enter again
1A	Doing self-test	Test in progress
1B	Self-test fail	Test again
1C	CPU timeout	Reset O/S and test again

If the code 1B appears a second time, repeat the IIMGC01 test after checking jumpers and wire wraps of each multibus graphics controller module.

NOTE: After the second consecutive failure, replace the module

Test Optional Multibus Graphics Controller Module Two (IIMGC01)

This procedure describes self test status for the multibus graphics controller. Use these commands to test the optional second multibus graphics controller module. To start the self test on the first IIMGC01 module

Type. VT 1

DM 3F90001

Within about six to seven seconds, the OIS monitor will display a series of blue, then green stripes. The self test returns a prompt if it is successful. If the self test fails, the message: *Self Test Failed* will be displayed.

NOTE: Ignore the message *MEM ACCESS ERROR*

Refer to Table 6 2 for a description of any error codes. If the test fails, replace card

TROUBLESHOOTING

Test Multibus Serial Interface Module (IIMSM01)

- 1 Connect the Monitor 68K terminal to the P10 connector on the power entry panel Press **Enter** on the keyboard A I:> prompt will appear on the screen
- 2 Check for the presence of a multibus serial interface module by looking at memory locations in the area of each port (about 256 bytes of memory) Ability to access all ports shows that the serial interface module is properly addressed.
- 3 Multibus serial interface module test This test displays a list of ASCII characters The same pattern is displayed for each part of the test

Press **Enter** (the monitor displays a I > prompt)

Type		For
DM 1FA0000 100	Enter	Port 0
DM 1FA2000 100	Enter	Port 1
DM 1FA4000 100	Enter	Port 2
DM 1FA6000 100	Enter	Port 3
DM 1FA8000 100	Enter	Port 4
DM 1FAA000 100	Enter	Port 5
DM 1FAC000 100	Enter	Port 6
DM 1FAE000 100	Enter	Port 7

Test Disk System Functions

This nondestructive test returns a I:> prompt on a new line if successful If the test fails, one of the character codes in Table 6 3 is displayed on the monitor screen

On success of this test, the monitor displays a directory listing, one screen at a time If this test fails note the error, reset the OIS, press **Enter**, and repeat the directory read tests

- 1 To start the hard disk sector tests:

Press **Enter** (the monitor displays a I'> prompt)

Type **DT 0** (hard disk sector 0 test) and **Enter**

- 2 To start the floppy disk sector tests

Insert a floppy disk into the floppy disk drive

Type **DT 1** (floppy disk sector 0 test) and **Enter**

This nondestructive test returns a `I>` prompt on a new line if successful. If the test fails, one of the character codes in Table 6 3 is displayed on the monitor screen

On success of this test, the monitor displays a directory listing, one screen at a time. If this test fails, the monitor displays the error messages in Table 6 3 Note the error, reset the OIS, press `[Enter]`, and repeat the directory read tests

If the test fails again check the connections to the floppy disk drive, hard disk drive, hard disk controller card, connecting cables, or the SASI card

3. To start the directory reads test. Further verify disk system operation by listing the directory for each storage device

Press `[Enter]` (the monitor displays a `I>` prompt)

Type `DI 0` (hard disk drive directory) and `[Enter]`

Insert SYS1 disk into the floppy disk drive.

Type `DI 1` (floppy disk drive directory) and `[Enter]`

A listing of file names appears with a prompt for more entries Press `[Enter]` for more entries

If the disk system test fails, there is a problem on the hard disk drive. Replace the storage device

Table 6 3. Disk Read Test Error Codes

Code	Meaning
02	Read error on the hard disk (The controller is communicating)
22	Read error on floppy disk (The controller is communicating)
FF	Data error on disks Time out error on disk I/O (Check the power supply and connectors)
1F	System (bus controller, disk controller, or disk drive) error (Check the power supply and connectors)
Volume not initialized	Directory volume not established yet (This is not a problem at this time)

NOTES

1 If error code 02 or 22 is displayed an error message can be called up for more information. Type RS0 for error code 02 and type RS1 for error code 22. Look up the four byte error message that is displayed in the OMT disk drive manufacturer's manual for more information about the error.

2 Error codes 02 and 22 indicate that the controller is communicating. Error codes 02 and 22 indicate that the power supply or device connections need to be checked.

EPROM DIAGNOSTICS

The OIS supports diagnostic system tests run with a terminal. The tests are located in the EPROM on the OIS multibus processor module. The key functions listed in Table 6.4 are control commands for the diagnostic tests.

Commands can also be chained together when separated by semicolons (;).

Chaining the clock test command with other tests provides a timer. Single tests can be chained together.

To run the ROM based diagnostics, connect a Monitor 68K terminal to P10 on the power entry panel, then press the OIS reset button. The message

SYSTEM RESTARTED
ENTER MONITOR BY PRESSING <RETURN>
OTHERWISE MTOS WILL AUTOLOAD IN 7 SECONDS.

will be displayed on the terminal screen. Press **[Enter]** within seven seconds to enter the Monitor 68K terminal program. A **! >** prompt will appear on the terminal. Type **DG** and press **[Enter]** to enter the diagnostic mode. Answer the questions about the OIS configuration.

Table 6.4 Control Commands for Advanced Diagnostics

Function	Purpose
[Esc]	Exits advanced diagnostics and returns to monitor level program.
[Ctrl]-A	Aborts current test.
[Ctrl]-C	Copies successive characters of previous input line.
[Ctrl]-R	Reprints previous command input line.
[Ctrl]-S	Suspends current test, hit any key to continue.
/R	Repeats the test until error or the test is aborted ([Ctrl]-A).
,	Separates a sequence of tests.
\	Continues command inputs onto next line.
[]	Indicates optional parameters.

Command Syntax

All commands consists of a two character command (upper case) and a series of operands. The operands may be optional. If an operand is enclosed in < >, it is required and if enclosed in [..], it is optional. Where <drive> is referred to, the valid entries are

- 0 - SASI/OMTI hard disk
 - PRIAM V155
 - PRIAM V185
 - PRIAM 519/MAXTOR XT2190
 - SEAGATE ST4086
 - MICROSCIENCE 4090
 - MAXTOR XT4085
- 1 - SASI/OMTI floppy disk
 - TEAC FD 55GFR 141 U
 - NEC FD 1157C
- 2 Cipher magnetic tape drive
- 3 Cherokee optical disk

Command Mode

The mode states where the command can be executed. The terminal begins in the monitor mode. Commands which may be executed in this mode have monitor written in the mode column.

Advanced diagnostic commands may be executed in DG mode. Enter this mode by typing **DG** in monitor mode, press **Enter** and follow the prompts. Press **Esc** to exit the DG mode and return to monitor mode, refer to Table 6-5. System error codes are listed in Tables 6-6 to 6-12. Table 6-10 contains the NIU error codes in decimal format. Refer to the enhanced computer interface unit programmer's reference manual for further information.

NOTE: If DG does not respond, check the disk system or put the multi bus modules one at a time and try again.

TROUBLESHOOTING



Table 6 5 Command Syntax Description

Command Syntax	Mode	Description
BT <start addr> <end addr>	DG	Read/write test of continuous segment of memory
BU	Monitor	Load streaming tape from hard disk
C	DG	C U/N U test
CL	DG	Clear the diagnostic setup and start diagnostic again
CM <addr1> <length> <addr2>	Monitor	Compare two blocks of memory
CV <dec ma num> or CV 0 <hex num>	Monitor	Convert decimal and hexadecimal integers
DF	Monitor	Duplicate floppy User's prompted for input
DG	Monitor	Start Bailey Controls OIS NVRAM based advanced diagnostics
D <drive num> [USN]	Monitor	Directory listing of files for specified device and JUSN. The hard disk's drive number 0 and the floppy disk's drive number 1
DM [<addr> [num of bytes]]	Monitor	Display memory starting at specified location
DM	Monitor	Display next 16 bytes
DM <address>	Monitor	Display next 16 bytes at starting address
DM <address> <num of bytes>	Monitor	Display next <num of bytes> at starting address
DP <disk type>	DG	Disk parameters Refer to F0 command for disk type
DT <drive>	Monitor	Disk read test for sector 00
EL	DG	Error log for hard disk Run this test after the WT test
FO <device>	Monitor	Format specified system device. This command formats either floppy disks or the hard disk. If device 0 (hard disk) is specified, then a menu of different disk types is displayed. Select the disk type used. Currently, this menu is displayed: 1 - PR I AM V155 2 - PR AM V185 3 - PR I AM 519/MAXTOR XT2190 4 - SEAGATE ST4086 5 - M CROSCIENCE 4090 6 - MAXTOR XT4085 When the system is done formatting the hard disk, it goes to the RT (replace track) mode and asks for the cylinder address and the head address (in decimal). It then assigns an alternate track table and informs when it is complete. To exit, press <u>Enter</u> with no input to the head or cylinder field. The system then returns to the CFG mode. Upon completion of the CF command, the system returns to the command line prompt.
GO [<addr>] or GO [/* <addr>]	Monitor	Starts execution of a program
GT <board [test]>	DG	Graphics test <board> = 0 or 1 [test] = 1 to 5
HE [command name]	ALL	Help displays information on parameters, etc. for a selected command or a command.

Table 6 5 Command Syntax Description (continued)

Command Syntax	Mode	Description
HT	Monitor	Causes monitor to enter host transparent mode
T	DG	Interrupt test
KK <keyboard>	DG	Keyboard key test
KL <keyboard>	DG	Keyboard LED test
KR <keyboard [relay mask]>	DG	Keyboard relay test
KS <keyboard>	DG	Keyboard sound test
LF <addr> <filename> <drive> [USN]	Monitor	Loads file under specified drive/USN into memory
LO <addr> <num sectors> <start sector> <drive>	Monitor	Load contiguous memory image to disk
LT <pcu> <module number>	DG	Loop test
MB <source addr> <num of blocks> <destination addr>	Monitor	Move blocks of memory (256 bytes each) from one location to another
MT	DG	Invokes start up or restart of MTOS operating system
MT	Monitor	Invokes start up or restart of MTOS operating system
MV <source addr> <length> <destination addr>	Monitor	Move blocks of memory
OT	DG	Optical disk test
PT	Monitor	Processor test
PU <start addr> <length>	Monitor	Down load (punch) processor S records to host computer
RC	DG	ROM checksum
RE	Monitor	Upload (read) processor S records from host computer
RM <start addr> <end addr>	DG	Long memory test
RS <device> 0 = hard disk 1 = floppy disk	Monitor	Request sense error message from disk controller for given file system device. This command returns four bytes of sense information in hex format, for either the floppy or hard disk. Compare the first byte of the error message to the first byte of the error message in the disk controller error code table.
RT <drive> <bad track addr> <alternate track addr>	Monitor	Maps a ternate (replacement tracks) around known bad tracks on hard disk. This command prompts the user for bad cylinder and head address (must be entered in decimal format). It then automatically assigns an alternate track and prompts the user for the next bad cylinder address. If <u>Enter</u> is entered a one for either prompt RT exits back to the command line.

TROUBLESHOOTING

Table 6 5 Command Syntax Description (continued)

Command Syntax	Mode	Description
RU	Monitor	Restore hard disk from streaming tape
SA <addr> <num sectors> <start sector> <drive>	Monitor	Save contiguous image to disk
SB <board> <port> [C]	DG	Serial board test [C] = use loopback connector
SC	DG	SAS /disk drive controller card test
SF <addr> <filename> <device> [USN]	Monitor	Saves memory data to file under specified device/USN
SM [size] <addr> <data>	Monitor	Store values at memory locations. Mode can be changed to one of the following B byte size storage (8 bits) default W word size storage (16 bits) L long word storage (32 bits)
ST	DG	SAS interface adapter test
TD	Monitor	Trace display. Prints the current values of all processor user registers PC SR USP SSP D0 to D7 A0 to A7
UT	Monitor	Enter a power level of utility commands. A menu of utility commands is displayed. Select a utility. Currently on, disable/enable (toggle) on chip cache is allowed
VT <device>	Monitor	Cache graphics controller self test. The device select 0 or 1 for graphics controller 1 or 2 respectively. Disable chip cache. n UT before doing VT
WT <device> <disk type> <tests> <test type> [A]	DG	Winchester test. Tests the hard disk <device> = 0 (hard disk) <disk type> = 1, 2, 3 or 4 (refer to F0 command) <tests> = number of times to perform the test <test type> = D destructive N nondestructive [A] = replace with alternate NOTE: The WT destructive test deletes the data on the hard disk. Backup data before performing this test. Upon completion of this test, perform the CF (configure) command initialize the OIS then reload files from the backup

Table 6 6. File System Error Codes

Hexadecimal Error Code	Error Description
\$00	No error
\$01	Logical/physical end of file volume on.
\$02	Timeout occurred before initiating service
\$03	Device reported hard error in data block.
\$04	Device reported hard error in file allocation block (FAB)
\$05	Device reported error in directory, bit map or volume D sectors
\$06	Device type not compatible with this command
\$07	Device reported timeout error
\$08	Invalid command
\$09	Invalid logical unit
\$0A	No file channels available
\$0B	No units are available
\$0C	Logical unit not assigned
\$0D	File has been reserved against request
\$0E	Device has been reserved against request
\$0F	Invalid option.
\$10	Incompatible option.
\$11	Invalid file description
\$12	Attempt to create a file that already exists
\$13	File not found
\$14	Device not found in D T table
\$15	Attempt to write to a file opened for read or vice versa
\$16	Error in logical record format
\$17	Invalid record format.
\$18	Invalid key
\$19	Key length error
\$1A	Insufficient medium space (device full).
\$1B	Insufficient buffer space
\$1C	End of directory
\$1D	Key not found
\$1E	Key already exists.
\$1F	Buffer overflow
\$20	Mount volume on
\$21	Invalid volume id smount
\$22	Attempt to open or dismount while files open
\$23	Open files on volume
\$24	Attempt to free a channel with pending requests
\$25	Unit has been reserved so open files can be aborted
\$26	Internal error.
\$27	File must be reserved
\$28	Unit must be reserved
\$29	Invalid time unit for PAUf IN coordination
\$2A	Illegal coordination mode given
\$2B	Size conflict during write
\$2C	Variable length record length of 0
\$2D	Inconsistent lock option
\$2E	Attempt to close while no files open
\$2F	No internal queue block available
\$30	Mismatch of label or sequence number

Table 6 6 File System Error Codes (continued)

Hexadecimal Error Code	Error Description
\$41	Device error (hard error)
\$42	Disk controller error
\$43	Seek error
\$44	Write error
\$45	Exclusive device access denied
\$46	Can not open device.
\$47	Illegal operation code
\$48	Illegal request
\$49	Timeout error for O/S time out of request /O routine
\$4A	Bad LUN number
\$4B	Illegal disk address
\$4C	Illegal memory address
\$4D	No LUN for host
\$4F	Reset command successfully completed
\$50	Hash overflow buffer supplied
\$51	Write protection error
\$5F	Disk controller time out
\$60	Check condition (sense bytes returned in sense data buffer)
\$61	Signal that host issuing a command never had exclusive access
\$62	Units offline
\$63	Interface device (SCSI board) not present or functioning
\$64	A track on a device was not formatted completely
\$65	An unexpected SASI PIO status was returned
\$101	The maximum number of files is open
\$102	The requested record length is too big for UNIX buffers
\$103	Invalid path name format
\$104	Invalid type supplied
\$105	Asked for sequential file, file is contiguous
\$106	Requested sequential record size is different from existing file
\$107	Attempt to append at end of contiguous file

Table 6 7 Disk Controller Error Codes

Hexadecimal Error Code	Error Description
\$0000	No error
\$0100	No index signal
\$0200	No seek complete.
\$0300	Write fault
\$0400	Drive not ready
\$0500	Drive not selected
\$0600	No track zero found
\$0700	Multiple drives selected
\$0500	Cartridge changed
\$0D00	Operation in progress

Table 6 7. Disk Controller Error Codes (continued)

Hexadecimal Error Code	Error Description
\$1000	Tape exception
\$1100	Uncorrectable error in data field
\$1300	No address mark in data field.
\$1400	No record found.
\$1500	Seek error
\$1700	Write protected
\$1800	Correctable ECC error
\$1900	Bad track flag set
\$1A00	Incorrect interleave factor.
\$1C00	Unable to read alternate track data
\$1E00	Illegal direct access to alternate track
\$1F00	Tape drive failure.
\$2000	Invalid command
\$2100	Illegal parameters.
\$2200	Illegal function for drive type.
\$2300	Volume overflow
\$3000	Power up diagnostic error.
\$3100	FDC 765 error
\$9100	Uncorrectable error in data field
\$9300	No address mark in data field
\$9400	No record found
\$9500	Seek error
\$9700	Write protected
\$9800	Correctable ECC error
\$9900	Bad track flag set
\$9A00	Incorrect interleave factor
\$9C00	Unable to read alternate track data
\$9E00	Illegal direct access to alternate track

Table 6 8. UNIX I/O Error Codes

Hexadecimal Error Code	Error Description
\$01	Modified buffer could not be written
\$02	Could not close file.
\$04	Could not dismount file
\$08	Could not close file because End Of Tape was encountered.
\$101	The maximum number of files are open.
\$102	The requested length is too big for UNIX
\$103	Invalid path name format
\$104	Invalid type supplied
\$105	Asked for sequential files contiguous
\$106	Requested sequential record size is different from existing file
\$107	Attempt to append to a contiguous file at end of file

TROUBLESHOOTING

Table 6 9 Tape File Error Codes

Hexadecimal Error Code	Error Description
\$201	Attempt to mount or initialize while volume is mounted
\$202	Attempt to dismount or open while no volume is mounted
\$203	Attempt to initialize volume with invalid BPI density
\$204	Attempt to dismount when task hadn't mounted
\$205	End of tape (EOT) encountered before operation was completed
\$206	Tape file system internal error
\$207	Device busy - can not perform mount or open
\$208	Volume is write protected.
\$209	Size of file created does not match the original create file parameter, file will be deleted on close (for internal use)
\$20A	(for internal use)
\$20E	(for internal use)
\$20C	EOV marks exist, no recovery action taken
\$20D	Directory full - reached maximum number of files
\$280	Unexpected sense data format
\$281	Target managed to recover an error condition
\$282	Unit not ready
\$283	Command terminated due to flaw in medium or error in recorded data
\$284	Target detected nonrecoverable hardware error
\$285	Legal request
\$286	Unit attention, medium may have been changed
\$287	Data protect
\$288	Block check, reading block block
\$289	Incorrect block length

Table 6 10 NIU Error Codes

Hexadecimal Error Code	Error Description
0	No error
1	Waiting for loop.
2	Improper format.
3	Legal command
4	Index already established
5	Block already established at another index (Loop PCU, MOD and Block are all the same as another tag)
6	Command too long
7	Bad reply from MLM
8	Export used as Import
9	Repeat NIU restart command
10	Undefined index

Table 6 10. NIU Error Codes (continued)

Hexadecimal Error Code	Error Description
11	Memory full.
12	Host communication error
13	MLM not responding.
14	Import used as export
15	Timeout of loop response
16	Number out of range
17	Illegal key.
18	Need a restart command
19	Module status used as import
20	Message active on loop
21	Import or export used as module status
22	Except on report specifications lost
23	No message queued, dequeue received
24	Reply too large
25	Illegal station mode command
26	Illegal module number in command
27	Time out between bytes in command
28	Index already established by another node
29	Point type incompatible with command
30	Watchdog timeout.
31	Checksum compare error
32	Destination node offline
33	Call up command required
34	NIU error
35	NIU busy
36	MCP offline.
37	Conflict with monitor mode
38	Point type incorrect
39	Destination ring offline
40	Destination node busy
41	Destination ring busy
100	Undefined message type for target module
101	Busy - cannot respond at this time
102	Mode for command does not agree with current module mode.
103	Message data out of range
104	Invalid block number.
105	Undefined block number - block is valid but not configured.
106	Block not readable - block number is valid but has no readable parameters.
107	Invalid function code for target module
108	Function code and block number not compatible on target module
109	Insufficient memory to write block in nonvolatile ROM and/or RAM
110	Module not responding

TROUBLESHOOTING

Table 6-11. IIMCP01 Failure LED Codes

MCP Code	LED Number							Error Condition	
	8	7	6	5	4	3	2		1
12	0	0	0	1	0	0	1	0	MLM not responding to MCP commands ROM checksum error (socket U23 or U24) Expander bus message failure
13	0	0	0	1	0	0	1	1	
14	0	0	0	1	0	1	0	0	
15	0	0	0	1	0	1	0	1	Loop failure check for break in circuit MLM loop back test failure Internal software error
16	0	0	0	1	0	1	1	1	
21	0	0	1	0	x	x	x	x	
31	0	0	1	1	0	0	0	1	Memory or CPU failure Address or bus error Illegal instruction
32	0	0	1	1	0	0	1	0	
33	0	0	1	1	0	0	1	1	
35	0	0	1	1	0	1	0	1	Spurious exception Divide by 0/check/format error MLM not configured for MCP operation (MLM switch 2, position 1 needs to be ON)
36	0	0	1	1	0	1	1	0	
38	0	0	1	1	1	0	0	0	
39	0	0	1	1	1	0	0	1	Duplicate node number on loop (MLM switch 4) MLM to MCP handshake failure Stop pushbutton actuated
3E	0	0	1	1	1	1	1	0	
3F	0	0	1	1	1	1	1	1	

NOTE: The LED representing the least significant bit is the bottom LED on the MCP and on the MLM module.

Table 6-12. IIMLM01 Failure LED Codes

MLM Code	LED Number							Error Condition	
	8	7	6	5	4	3	2		1
13	0	0	0	1	0	0	1	1	ROM checksum error (socket U23 or U24) Memory or CPU failure Address or bus error
31	0	0	1	1	0	0	0	1	
32	0	0	1	1	0	0	1	0	
33	0	0	1	1	0	0	1	1	Illegal instruction Trace/privilege violation Spurious exception
34	0	0	1	1	0	1	0	0	
35	0	0	1	1	0	1	0	1	
36	0	0	1	1	0	1	1	0	Divide by 0/check/format error Any trap instruction MLM not configured for MCP operation (MLM switch 2, position 1 needs to be ON)
37	0	0	1	1	0	1	1	1	
38	0	0	1	1	1	0	0	0	
3E	0	0	1	1	1	1	1	0	MLM to host handshake failure

Optical Disk Unit Troubleshooting

The troubleshooting suggestions in Table 6 13 will help answer most questions In addition, Cherokee provides assistance at (303) 776 0721 to answer additional questions on the disk drive unit. When calling, indicate that technical assistance is required and give the serial number of your disk drive unit.

Table 6 13. Optical Disk Unit IIDOP02 Troubleshooting Table

Symptom	Possible Cause/ Corrective Action
Unit will not power up	Check for blown fuse refer to the installation on section Check for power at the power entry panel Check AC input power setting, refer to the installation on section
A cartridge is loaded and the unit does not indicate a ready status (green light)	Press the cartridge release, wait until select and ready lights flash Press cartridge release again the unit should return to ready status Turn power off to unit then turn power back on Wait several seconds for unit to return to ready status
Ready and select lights are on with a cartridge loaded	Press the cartridge release switch wait until unit indicates ready This is a normal condition when the optical disk is being written to or read by the OS
Constant unit select indicator on (red light)	This may occur when the unit is accessed but does not have a cartridge loaded Insert a cartridge, rotate lock/insert switch to the lock position Wait until unit is ready and press the cartridge release switch again
Disk drive unit cannot be accessed from host computer	(drive-not ready) Check the cable connections. Check the drive power, and read status
Cannot unload cartridge when select and ready flashing	With select and ready lights flashing, rotate lock/insert switch slightly clockwise from the lock position on then counter clockwise to the insert position Turn unit power off, insert rod approximately one inch into the left of the eject label While holding rod in place rotate the lock/insert switch to the insert position
App cat on diagnostics will not run	Check SCSI interface to disk drive unit SCSI cable seated Check ready status of disk drive unit
Drive has media loaded with constant select (green light) and will not go into a ready condition (green light)	Shut off power and manually eject the optical cartridge as described in Cannot Unload Cartridge When Select & Ready Flashing Inspect the media to insure it is double sided Single sided media inserted as to expose the nondata surface to read/write will cause the device to be continually busy as it attempts to locate the non data track which is nonexistent Turn the media to the correct side (A up) and insert. This condition may occur when track zero has been overwritten and cannot be read, or the surface of the media in disk drive unit is unreadable

SECTION 7 - MAINTENANCE

INTRODUCTION

This section contains a preventive maintenance schedule for the OIS/OIC and for the optical disk archiving unit

Be sure to follow all warnings, cautions and notes. Put boards containing MOS devices into antistatic bags when stored or shipped back to the factory. Do not repair printed circuit boards in the field. All repairs and adjustments should be performed by qualified personnel

PREVENTIVE MAINTENANCE

Refer to Table 7 1 for suggested preventive maintenance procedures. Specific steps to do these procedures are found in the vendor information supplied with the unit

Table 7 1. OIS/OIC Preventive Maintenance

Component	Frequency	
	Monthly	Annually
Floppy Disk Drive		Clean, inspect and check alignment ¹
Printer	Inspect, Clean and Lubricate	Adjust printer per manufacturers instructions
Fan Assembly	Clean Filter	Rinse filter with water, blow dry and reinstall
Power Supplies	—	Check and adjust power supply ² if necessary
Touch Screen and CRT Setup	—	Inspect and check alignment ³

NOTE

1 Adjust the floppy disk drive using the procedure in the manufacturers' documentation

2 Adjust power supplies on O S20 I O S20A and IOIC202 only using the procedure in Section 6

3 Adjust the touch screen using the procedure in Section 5

Optical Disk Unit Maintenance

The disk drive unit is designed for maintenance free operation. There is only one maintenance procedure recommended for the disk drive unit and that is to clean the input filter. This filter is located on the back panel. Remove, clean and replace the filters when they are dirty by following certain steps

MAINTENANCE

Filter Maintenance

- 1 Locate the air intake on the back panel.
 - 2 Grasp the snap on type filter assembly from behind and carefully pull it away from the unit
 - 3 Clean the filter element with a solution of water and liquid detergent and allow to dry or use high pressure air
 - 4 Replace the filter assembly into the disk drive unit
-

Additional Maintenance

The disk drive unit requires operator action for.

Fuse replacement
Primary power setting
Air filter replacement

For other maintenance actions the disk drive unit should be returned to the factory

SECTION 8 - REPLACEMENT PROCEDURES

INTRODUCTION

This section explains how to replace multibus card cage modules and the units in the IIOIS20/IIOIC20 Operator Interface Station. There are no special tools required

MODULE REPLACEMENT

If a module in the multibus card cage is faulty, replace it with a new one DO NOT try to repair the module Replacing components may affect the module performance This procedure explains how to remove a module from an IIOIS20/IIOIC202 and an IIOIS20A/D

CAUTION

Failure to turn off the main power circuit breaker before removing or inserting modules into the module rack may result in equipment failure.

ATTENTION

Si l'on omet d'eteindre l'interrupteur du circuit d'alimentation principal avant de retirer les cartes ou de les inserer dans le porte-cartes, l'equipment pourrait faire default.

1. Open the cabinet door on the front of the cabinet and turn off the main power circuit breaker
- 2 To unseat a module, carefully lift the card removal tabs shown in Figure 8-1.




Figure 8 1. Multibus Module Removal

REPLACEMENT PROCEDURES

- 3 Carefully slide the module out of the multibus card cage. Be sure not to loosen cables from the modules next to the one being removed
- 4 Configure the replacement module switch and jumper settings. Be sure they are set the same as the original module.
- 5 In the same slot assignment as the original module, align the replacement module beneath the slot number on the guide rail in the multibus card cage
- 6 Insert the multibus modules into the upper and lower guide rails. Carefully slide the module in until the front panel is flush with the top and bottom of the multibus card cage frame. Press on the module removal tabs shown in Figure 8.1 to fully insert the module into the multibus card cage back plane
- 7 Close and secure the cabinet door. Return to normal operation

PART REPLACEMENT

Color Monitor for IIOIS20/IIOIC202

Ba ey Part Number - 1948623 6

See Figure 8-2 when using this procedure. Refer to the manufacturers' documentation for IIOIC20 tabletop models

- 1 In the front of the cabinet, turn off the main circuit breaker on the power entry panel (PEP) to shut off power to the OIS/OIC. Check the power indicator to see if power is removed from the system.
2. Unplug the optional touch screen cable from the touch screen controller card The touch screen controller card is connected to the Multibus Keyboard Module (IIMKM01)
- 3 In the front of the cabinet above the card cage, remove the air plenum (6638577A1) filter assembly by removing the four screws on the front. Slide the assembly out the front of the cabinet
4. In the front of the cabinet of some models, above the card cage, remove the two, $\frac{7}{16}$ inch bolts under the CRT shelf that hold the front of the CRT mounting tray to the cabinet.




Figure 8-2. Color Monitor Removal for IIOIS20/IIOIC202

REPLACEMENT PROCEDURES

5 In the back of the cabinet, remove the power cord and RGB cable from the back of the monitor. Secure the RGB cable out of the way.

WARNING

The CRT will slide out the rear of the cabinet by itself when the mounting bolts are removed. The CRT weighs about 27 kg (60 pounds) and can cause bodily injury if it is allowed to slide out by itself. Support the CRT before removing the rear two bolts.

AVERTISSEMENT

Lorsque les boulons d'ancrage sont retirés, l'écran cathodique risque de sortir à l'arrière de l'armoire IIOIS20 et IIOIC20. Si les deux boulons d'ancrage arrière sont retirés, il faut retenir l'écran afin d'éviter toute blessure.

6 Remove the bolt on each side of the CRT mounting tray at the rear of the CRT. These bolts attach the tray to the cabinet shelf.

7 After removal, place the CRT and tray onto a solid, flat surface.

8 Remove the optional touch screen and protect it from fingerprints and dust.

9 Protect the screen of the CRT and set the CRT screen down on the protected surface.

10. Remove the CRT from the mounting tray by removing the four screws under the tray.

REPLACEMENT PROCEDURES

Color Monitor for IIOIC203

Bailey Part Number - 1948623 1

See Figure 8 3 when using this procedure Refer to the manufacturers' documentation for IIOIC20 tabletop models

1. In the front of the cabinet, turn off the main circuit breaker on the PEP to shut off power to the OIC Check the power indicator to see if power is removed from the system
2. Open the back door above the air conditioner Remove the two screws fastening the CRT mounting tray to the support rails
3. Slide the CRT out of the cabinet. The CRT weighs about 27 kilograms (60 pounds) Be sure it is well supported




Figure 8 3. Color Monitor Removal for IIOIC203

REPLACEMENT PROCEDURES



Disk Drive Controller Card for IIOIS20

Bailey Part Number 1948013 1

See Figure 8 4 when using this procedure

- 1 In the front of the cabinet, turn off the main circuit breaker on the PEP to shut off power to the OIS. Check the power indicator to see if power is removed from the system
- 2 In the back of the cabinet, disconnect the ribbon cables from the disk controller card
- 3 Loosen the controller board attaching screws. Carefully lift off the controller board. Do not lose the spacers between the board and mounting posts




Figure 8 4 Disk Drive Controller Card Removal for IIOIS20

REPLACEMENT PROCEDURES

Disk Drive Controller Card for IIOIS20A

Bailey Part Number - 1948013_1

See Figure 8 5 when using this procedure

- 1 In the front of the cabinet, turn off the main circuit breaker on the PEP to shut off power to the OIS Check the power indicator to see if power is removed from the system
2. In the back of the cabinet, disconnect the ribbon cables from the disk controller card.
- 3 Loosen the controller board attaching screws Carefully lift off the controller board. Do not lose the spacers between the board and mounting posts




Figure 8 5 Disk Drive Controller Card Removal for IIOIC20A

REPLACEMENT PROCEDURES



Hard Disk Drive for IIOIS20

Bailey Part Number - 1948002 2

See Figure 8 6 when using this procedure.

- 1 Remove the disk drive controller card Use the procedure in this section
- 2 Disconnect all power and ribbon cables to the hard disk drive
- 3 Remove the two screws securing the hard disk drive to the cabinet Lift the drive out of the cabinet.




Figure 8 6 Hard Disk Drive Removal for IIOIS20

REPLACEMENT PROCEDURES

Hard Disk Drive for IIOIS20A

Bay Part Number - 1948002 2

See Figure 8 7 when using this procedure.

- 1 Remove the disk drive controller card Use the procedure in this section.
- 2 Disconnect all power and ribbon cables to the hard disk drive.
- 3 Remove the two screws securing the hard disk drive to the cabinet. Lift the drive out of the cabinet




Figure 8 7 Hard Disk Drive Removal for IIOIS20A

REPLACEMENT PROCEDURES



Fan Assembly for IIOIS20/IIOIC202

Bailey Part Number - 1947419 7

ArF ter 1990006 1

See Figure 8 8 when using this procedure

- 1 In the front of the cabinet, turn off the main circuit breaker on the power entry panel to shut off power to the OIS/OIC Check the power indicator to see if power is re moved from the system
- 2 In the back of the cabinet, cut and remove cable ties securing the fan assembly power cord. Fan assembly 1 is removed in Step 3 and fan assembly 2 is removed in Step 4.
- 3 Fan assembly 1 is located under multibus card cage slots 1 8 In the back of the cabinet, remove the two screws on either side of the fan assembly and slide the fan assembly out
- 4 Fan assembly 2 is located under multibus card cage slots 8 16 In the back of the cabinet, remove the hard disk as described previously in this section and fan assembly 1 as described in Step 3




Figure 8 8 Fan Assembly Removal for IIOIS20/IIOIC202

REPLACEMENT PROCEDURES

Remove the two screws on either side of the fan assembly and slide the fan assembly out to the right around the hard disk mounting bracket.

5 Disassemble the fan subassembly by removing the four long screws.

NOTES:

1. Be sure the arrow on the fan being installed points in the direction of the air flow. The fan blows downward pulling air out of the module card cage through the bottom.
2. Be sure the red striped conductor of the power cord is connected to the positive (+) terminal of the fan.

REPLACEMENT PROCEDURES



Fan Assembly for IIOIS20A

Bailey Part Number 1947419_7
 A R F ter 1990006 1

See Figure 8 9 when using this procedure

- 1 In the front of the cabinet, turn off the main circuit breaker on the power entry panel to shut off power to the OIS Check the power indicator to see if power is removed from the system.
- 2 In the back of the cabinet, cut and remove cable ties securing the fan assembly power cord Fan assembly 1 is removed in Step 3 and fan assembly 2 is removed in Step 4
- 3 Fan assembly 1 is located under multibus card cage slots 1 & 8 In the back of the cabinet, remove the two screws on either side of the fan assembly and slide the fan assembly out
4. Remove the two screws on either side of the fan assembly and slide the fan assembly out




Figure 8 9 Fan Assembly Removal for IIOIS20A

REPLACEMENT PROCEDURES

5 Disassemble the fan subassembly by removing the four long screws

NOTES:

1. Be sure the arrow on the fan being installed points in the direction of the air flow. The fan blows downward pulling air out of the module card cage through the bottom.
2. Be sure the red striped conductor of the power cord is connected to the positive (+) terminal of the fan.

REPLACEMENT PROCEDURES

Floppy Disk Drive for IIOIS20

Bay Part Number 1948018_1

See Figure 8 10 when using this procedure

- 1 In the front of the cabinet, turn off the main circuit breaker on the PEP to shut off power to the OIS Check the power indicator to see if power is removed from the system
- 2 In the rear of the cabinet, partially remove the power supply Remove the two screws on the bottom of the power supply and slide it out of the back of the cabinet Cut the cable ties as needed to set the supply on the floor out of the way
- 3 Unplug the operator keyboard, mouse and units connected to the front of the operator keyboard interface panel
- 4 Remove the peripheral power cables to the floppy disk drive from the DC distribution board
- 5 Remove all of the cables from the rear of the operator keyboard interface panel and floppy drive unit
- 6 Remove the two screws holding the floppy drive tail brace to the left wall of the cabinet




Figure 8 10 Floppy Disk Drive Removal for IIOIS20

REPLACEMENT PROCEDURES

7. Remove the two screws holding the bottom of the operator keyboard interface panel to the back side of the CRT bezel. There are no screws on top or on the sides of the panel.

8. Carefully remove the operator keyboard interface panel containing the floppy drive out the rear of the cabinet.

9. Remove the four screws on the sides of the floppy drive and separate the bracket from the floppy drive. The drive will slide out through the front of the keyboard interface panel.

REPLACEMENT PROCEDURES**Floppy Disk Drive for IIOIS20A**

Bailey Part Number 1948018_1

See Figure 8 11 when using this procedure

- 1 In the front of the cabinet, turn off the main circuit breaker on the PEP to shut off power to the OIS. Check the power indicator to see if power is removed from the system.
- 2 Remove the two screws holding the floppy drive faceplate to the front panel of the power entry panel
- 3 Carefully slide the drive out through the front of the panel
4. Remove and label the cables connected to the drive.




Figure 8 11 Floppy Disk Drive Removal for IIOIS20A

REPLACEMENT PROCEDURES

Multibus Card Cage for IIOIS20/IIOIC202

Bay Part Number 6637801_2

See Figure 8 12 when using this procedure

1. In the front of the cabinet, turn off the main circuit breaker on the PEP to shut off power to the OIS/OIC. Check the power indicator to see if power is removed from the system.
2. In the back of the cabinet, disconnect all cables and wiring from the back of the card cage.
3. Remove the four screws at the front of the card cage (two on each side).
4. Slide the cage out of the front of the cabinet.




Figure 8 12. Multibus Card Cage Removal for IIOIS20/IIOIC202

REPLACEMENT PROCEDURES

Multibus Card Cage for IIOIS20A

Bailey Part Number 6637801 2

See Figure 8 13 when using this procedure

- 1 In the front of the cabinet, turn off the main circuit breaker on the PEP to shut off power to the OIS Check the power indicator to see if power is removed from the system
- 2 In the back of the cabinet, disconnect all cables and wiring from the back of the card cage
- 3 Remove the four screws at the front of the card cage (two on each side)
- 4 Slide the cage out of the front of the cabinet




Figure 8 13. Multibus Card Cage Removal for IIOIS20A

REPLACEMENT PROCEDURES

Power Entry Panel for IIOIS20/IIOIC202

Bailey Part Number - 6638353_1 (for IIOIS20)
Bailey Part Number - 6638353_2 (for O C202)

See Figure 8-14 when using this procedure.

1. In the front of the cabinet, turn off the main circuit breaker on the PEP to shut off power to the OIS/OIC. Check the power indicator to see if power is removed from the system.
2. Shut down AC line power to OIS/OIC (plant breaker) so that the AC line may be disconnected safely.
3. In the front of the cabinet, remove all cables from the front of the PEP (RS 232, SCSI, alarm contact wires, and AC input)
4. In the back of the cabinet, remove AC cables from the outlets on the PEP
5. Remove all signal cables from the multibus modules that go to the back of the PEP. Leave the cables on the PEP. The new PEP comes with cables.
6. In the front of the cabinet, remove the five screws from around the edges of the PEP. Slide the PEP out the front of the cabinet.




Figure 8 14. Power Entry Panel (PEP) Removal for IIOIS20/IIOIC202

REPLACEMENT PROCEDURES



Power Entry Panel for IIOIS20A

Bailey Part Number 6638960_2

See Figure 8 15 when using this procedure

- 1 In the front of the cabinet, turn off the main circuit breaker on the PEP to shut off power to the OIS. Check the power indicator to see if power is removed from the system.
- 2 Shut down AC line power to OIS (plant breaker) so that the AC line may be disconnected safely.
- 3 Remove all cables from the front of the power entry panel (RS 232, SCSI, alarm contact wires and AC input).
- 4 Remove AC cables from the outlets on the back of the PEP.
- 5 Remove all signal cables from the multibus modules that go to the back of the PEP.




Figure 8 15. Power Entry Panel (PEP) Removal for IIOIS20A

REPLACEMENT PROCEDURES

6. In the front of the cabinet, remove the four screws from around the edges of the PEP. In the back of the cabinet, remove the four screws holding the two mounting brackets to each side of the cabinet. Do not take the mounting brackets off the back of the PEP. They support the back of the PEP during removal and installation.

7. Slide the PEP out the front of the cabinet. Be careful the PEP weighs about 27 kilograms (60 pounds).

REPLACEMENT PROCEDURES

Power Entry Panel for IIOIC203

Bailey Part Number 6639503 1

See Figure 8 16 when using this procedure

- 1 In the front of the cabinet, turn off the main circuit breaker on the PEP to shut off power to the OIC Check the power indicator to see if power is removed from the system.
- 2 Shut down AC line power to OIC (plant breaker) so that the AC line may be disconnected safely
- 3 Remove all cables from the front and top of the power entry panel (RGB cable, IIMKM01 cable and AC input)
- 4 Remove AC cables from the outlets on the PEP




Figure 8 16 Power Entry Panel (PEP) Removal for IIOIC203

REPLACEMENT PROCEDURES

- 5 Remove the two screws from the PEP end of the bracket supporting the front of the PEP. If the cabinet end of the bracket is removed, seal the mounting screws with Dow Corning[®] 732[™] RTV clear sealant or equivalent
6. In the front of the cabinet, remove the four screws from around the back edges of the PEP
- 7 Slide the PEP out the front of the cabinet. Be careful the PEP weighs about 23 kilograms (50 pounds)

[®] Dow Corning is a registered trademark of Dow Corning Corporation
[™] 732 is a trademark of Dow Corning Corporation

REPLACEMENT PROCEDURES

Main Power Supply for I/OIS20/I/OIC202

Bailey Part Number 1948565A1

See Figure 8 17 when using this procedure.

- 1 Shut off power to the OIS/OIC
- 2 Remove the power supply plug from the socket on the PEP.
- 3 Mark and disconnect the wires between the power supply, DC distribution board and multibus card cage backplane
4. Remove the two nuts holding the power supply bracket to the CRT mounting platform and slide the unit out the rear of the cabinet




Figure 8 17 Main Power Supply Removal for I/OIS20/I/OIC202

REPLACEMENT PROCEDURES

Slide In Power Supply for IIOIC202

Bailey Part Number - 6639225 1

See Figure 8 18 when using this procedure

- 1 Open the front door and shut off power to the OIC
- 2 Remove the power supply plug from the socket on the PEP
3. Remove the bolts fastening the power supply to the multi bus card cage backplane
4. Slide the unit out the front of the cabinet.




Figure 8 18 Slide In Power Supply Removal for IIOIC202

REPLACEMENT PROCEDURES



Main Power Supply for IIOIS20A

Bailey Part Number - 1948565 1

See Figure 8 19 when using this procedure

- 1 Shut off power to the OIS
- 2 Remove the power supply plug from the socket on the PEP
- 3 Mark and disconnect the wires between the power supply, DC distribution board and multibus card cage backplane
- 4 In the back of the cabinet, remove the two screws holding the power supply bracket to the PEP and slide the unit out the rear of the cabinet




Figure 8 19 Main Power Supply Removal for IIOIS20A

REPLACEMENT PROCEDURES

Main Power Supply for IIOIC203

Ba ley Part Number - 1948564_1

See Figure 8-20 when using this procedure.

- 1 Follow the procedure for removing the IIOIC203 power entry panel in this section
2. Remove the IIMKM01 circuit board. Do not lose the two nonconductive washers for each standoff
- 3 To remove the cover from the top of the PEP, remove the nine screws shown in Figure 8-20 and disconnect the power distribution board connector
- 4 Mark and disconnect the wires between the power supply and incoming AC

NOTE: Check that the power distrib on board connector to the power supply is aligned correctly when replacing the cover

5. Remove the four screws holding the power supply to the center support wall of the PEP




Figure 8 20 Main Power Supply Removal for IIOIC203

SECTION 9 - SUPPORT SERVICES

INTRODUCTION

Bailey Controls is always ready to assist in the operation and repair of its products. Send requests for sales or application services to your nearest sales or service office. Bailey Controls can also provide installation, repair and maintenance contract services.

REPLACEMENT PARTS AND ORDERING INSTRUCTIONS

Order replacement parts through a Bailey Controls sales or service office. We request that the following information be provided when ordering parts

- 1 Part description, part number and quantity.
- 2 Model and serial number (if applicable) and ratings of the assembly the part has been ordered for.
3. Publication number and reference used in identifying the part

When ordering parts, use part numbers and part descriptions from renewal parts sections of equipment manuals. Parts with no commercial description must be ordered from your nearest sales or service office. Recommended spare parts lists, including prices on standard assemblies are available through your nearest sales or service office.

TRAINING

Bailey Controls has a modern training center, equipped to provide service and repair instruction, which is available for training of customer personnel. Order specific information regarding course content and scheduling from your nearest sales/service representative.

TECHNICAL DOCUMENTATION

Price and delivery of additional copies of this publication can be obtained through your nearest sales or service office.

SPARE PARTS

Table 9-1 lists the recommended spare parts for the OIS. Bailey Controls suggests a stock supply of one item each to minimize the duration and cost of down time.

SUPPORT SERVICES



Table 9 1. Recommended Spare Parts List

Replacement Part		Where Used						
Description	Nomenclature	OIS		OIC				
		20	20A 20D	201	202	203	204	205
Air Filter	1950006 1	X	X		X			
Annunc ator/D sp ay Pane (tabletop)	I ADP01	X		X	X		X	X
B ack and White Pr nter	I PRT02	X	X					
Color Mon tor (19 inch)	1948623 6	X		X	X	X	X	
Co or Mon tor (33 nch)	1948014 7							X
Disk D rve Contro ler Module	1948013 1	X	X					
Fan	1947419 7	X	X		X			
Floppy D sk Dr ve	1948018 1	X	X					
Fuse, 1 A (for IMCL01)	194776_11001	X	X					
Fuse, 2 A Fast Act ng (for operator keyboard interface board)	1948182 22001	X	X	X	X	X	X	
Hard D sk Dr ve	1948002 1	X	X					
Keyboard Assembly	6638514 1	X		X	X	X	X	X
Keyboard, QWERTY Aux lary Eng neering Keyboard	IIAKB01	X		X	X	X	X	X
Mu tibus Commun cat on Loop Modu e	I MCL01	X	X					
Mu tibus Commun cat ons Processor Module	I MCP0_	X	X					
Multibus Keyboard Module	IIMKM01	X		X	X	X	X	X
Multibus Graph cs Contro ller Module	IIMGC01	X	X					
Mu tibus Loop Module	IIML M01	X	X					
Mu tibus Processor Modu e	IIMP01	X	X					
Multibus Senal Interface Module	IIMSM01	X	X					
Power Supply	1948564_1				X			
Power Supply	1948564_2			X		X	X	
Power Supp y	1948565_1	X	X					
Power Supply (slide in supply)	6638225 1				X			
SASI Modu e	1948023 1	X	X					
Streaming Tape (archival storage)	IIDST01	X	X					
Touch Screen	IIATS01	X		X	X		X	

APPENDIX A - QUICK REFERENCE INFORMATION

INTRODUCTION

This section provides a source for reference information. It contains the cable connections for the IIOIS20, IIOIC202 and IIOIC203.

IIOIS20/IIOIC20 WIRING CONNECTIONS AND CABLING

The OIS/OIC is internally wired when it is shipped. Connect the communication loop cables, AC power and any peripheral devices. AC power is connected to TB1 on the power entry panel (PEP). Communication loop cables connect to the IIMCLO1 module in the multibus card cage. Peripheral devices connect to the front of the PEP or to the keyboard interface panel. Refer to Section 4 and Section 5 for specific instructions on installing and configuring peripheral devices and replacement components.

Table A 1 lists the color codes for wiring the IIOIS20 IIOIS20A/D and IIOIC202/3. Table A 2 contains a list of IIOIS20 cables and their connections. These connections also apply to the IIOIS20A/D except for the operator interface peripheral devices such as the keyboard and CRT. The complete IIOIS20A wiring table is listed in Section 3.

IIOIS20 cable connections are shown in Figure A-1. IIOIC202 cable connections are shown in Figure A-2. IIOIC203 cable connections are shown in Figure A 3.

Table A 1. IIOIS20/IIOIC20 Wiring Color Codes

Color	Function
Brown Blue Green/Yellow	AC Hot AC Neutral AC Common
Brown White/Green Violet	+5 VDC DC Common 12 VDC
White/Violet Green White	+12 VDC Sense + Sense

QUICK REFERENCE INFORMATION



Table A 2 IIOIS20 Cable Connections

Cable No.	Cable Name	Connect From	Connect To
6637599_1	AC Power	J1 on PEP	AC High on Main Power Supply AC Low on Main Power Supply Ground on Main Power Supply
1947950 1	AC Power	J2 on PEP	CRT1 AC Power Connector
1947950 5	AC Power	J3 on PEP	CRT2 AC Power Connector
6638712_1	PF1 Sense	J1 on Power Supply	TB1 on Backplane P3 on IMKM01
6638718 1	Power	+12/ 12 on Power Supply	Terminal Strip on DC Distribution Board
6638708 1	Power	TB2 on Backplane	Terminal Strip on DC Distribution Board
6638711 1	Power	CH1+, CH1 on Power Supply	TB3, TB4, TB5, TB6 on Backplane
6638719 1	Reset Cable	Reset switch on PEP	P4 on IMKM01
6637776 2	Wrist Ground	Juser	Wrist connect on on PEP
6637460 50N42	Disk Drive	J8 on Disk Controller	Streaming tape port module on PEP
6637460 50N42	Disk Drive	J43 on MCP01	SCSI Port on PEP
6638716 1	RS 232 Cable	J6 on IMCP01 (top half) (bottom half)	to P10 on PEP to P9 on PEP
6638715 1	RS 232 Cable	Lower connector on P1 P4 on PEP	IMSM01
6638715_1	RS 232 Cable	Upper Connector on P5-P8 on PEP	IMSM01
6638720_1	Lowboy Bright	3 Pin Connector on Rear of Monitor	CRT Bezel Brightness CRT Bezel Contrast Degaussing Sw on PEP
6638720_2	Highboy Bright	9 Pin Connector on Rear of Monitor	CRT Bezel Brightness CRT Bezel Contrast Degaussing Switch on PEP
MKM01	RGB cable	on IMGC01	RGB on Monitor
6637597_31200	Upper RGB Video	on IMGC01	RGB on Monitor
6637597_24100	Lower RGB Video	on MGC01	RGB on Monitor
66374512 26N72	I/O Distribution	P5 on MKM01	P1 on Keyboard /O Distribution Board

QUICK REFERENCE INFORMATION

Table A 2. IIOIS20 Cable Connections (continued)

Cable No.	Cable Name	Connect From	Connect To
6634512_26N72	/O Distribut on	P6 on IIMKM01	Rear of Terminal Block on PEP
6638713_1	Peripheral Power	J2 on Keyboard /O Distribut on Board	P3 on DC Distribut on Board on Main Power Supply
6638713_2	Peripheral Power	P1 on ADP Board	P4 on DC Distribut on Board on Main Power Supply
6638713_3	Peripheral Power	Floppy Drive	P2 on DC Distribut on Board on Main Power Supply
6634329_34N48	Floppy Signal	J7 on Disk Controller	J1 on Floppy Drive
6638849_1	ADP Signal	P7 on IIMKM01	P8 on Keyboard I/O Distribut on Board P2 on ADP Pane
6632686_50_1	Disk Data	J1 on Disk Controller	J1 on SASI module (Processor)
6634329_20N8	Hard Drive Data	J4 on Disk Controller	J2 on Hard Disk Drive
6634329_34N12	Hard Drive Data	J2 on Disk Controller	J1 on Hard Disk Drive
6638713_4	Peripheral Power	on Hard Disk	Front DC Distribut on Board on Main Power Supply
6638713_5	Peripheral Power	J10 on Disk Controller	F6 on DC Distribut on Board on Main Power Supply
6638717_1	PF1 Sense	J2 on Main Power Supply	F7 on DC Distribut on Board on Main Power Supply
6634512_26N2	Internal /O	P4 on MCP01	F4 on IMLM01
6634512_26N2	Internal /O	P3 on IIMCL01	P3 on IMLM01
NKMR02_3	9 25 RS-232	P5 on MCP01	P4 on PEP
NKMR02_3	9 25 RS 232	P9 on IIMKM01	P1 on PEP
1948644_5	Touch Screen Extension	Touch Screen on Upper CRT	5 Pin on Touch Screen Disk Controller Module

QUICK REFERENCE INFORMATION




Figure A 1 IIOIS20 Cable Connections




Figure A 2 I/OIC202 Cable Connections

Index

A		F	
AC power	3-13, 3-34, 4-61	Fan assembly for IOIS20/ OIC202	8-10
AC power test	6-3	Fan assembly for IOIS20A	8-12
AC wiring, O S20	3 14	Floppy disk drive - NEC	4 32
Annunciator display panel (ADP)	4-28	Floppy disk drive - TEAC	4-31
		Floppy disk drive for IOIS20	8-14
		Floppy disk drive for IOIS20A	8-16
B		G	
Backup and restore to tape	5-19	Gammadata color video copier system	5-14
		Genicom 3410 XCQ	5-10
		Genicom 3410 XLS	5 9
C		H	
Cable connections O S20	3-10	Hard disk drive - CONTROL DATA	
Cable connections peripheral devices	3-13	85 megabyte	4-34
Cabling O S20	3-7	Hard disk drive - MAXTOR 85 megabyte	4-36
Cabling O S20A/D	3-7	Hard disk drive - PR AM V185A	
Cabling reel-to-reel tape	5-24	85 megabyte	4-33
Cabling printer	5-8	Hard disk drive - Seagate 85 megabyte	4-35
Color graphics module second	5-4	Hard disk drive for IOIS20	8 8
Color monitor	4 25, 5-5	Hard disk drive for IOIS20A	8 9
Color monitor for O C203	8-5		
Color monitor for O S20/ O C202	8-3	I	
Color video copier system	5-11	IIDOP01 installation	5-31
Command mode	6-13	IIDOP01 power settings	5 34
Command syntax	6-13	IIDOP01 troubleshooting	5-38
Communication levels O C/O S	1-2	IIDOP02 parts list	5-39
Communication loop connections . . .	3-11	IDOP02 troubleshooting	5-47
		IDOP02 wiring and cabling	5-44
D		IMCP01 failure LED codes	6 22
DC power test	6-4	MLM01 failure LED codes	6 22
Dagnostic power up tests	6-3	IOIS20 anchoring dimensions	3 5
Disk drive controller board	4-27	IOIS20 cabinet dimensions	3 4
Disk drive controller card for O S20	8-6	IO S20/IOIC20 wiring connections	
Disk drive controller card for O S20A	8-7	and cabling	A-1
Double sided media	5 36, 5-45	Interface panel, keyboard	4-22
E			
Engineering keyboard	5-7		
EPROM diagnostics	6-12		

Index (continued)

L		O
LED failure codes MCP01	6 22	
FD failure codes MLMO1	6-22	
M		
Main power supply for O C203	8 27	
Main power supply for O S20/ O C202	8 24	
Main power supply for IO S20A	8 26	
Main power supply O C202	4 54	
Main power supply IO S20 and IOIS20A/D	4-49	
Manual		
Contents	1-15	
Glossary	1 18	
Intended user	1 1	
Nomenclature	1 20	
Overview	1 1	
Media storage	5 36 5 45	
Module replacement	8 1	
Mouse	5 53	
Multibus	2 4	
Multibus card cage	4 3	
For O S20/ O C202	8 17	
For O S20A	8 18	
Tests	6 5	
Multibus communication module	4 21	
Multibus graphics controller module	4 8	
Multibus hardware	4 2	
Communication module	4 21	
Graphics controller	4 8	
Keyboard module	4-9	
Loop module	4-16	
Module installation	4 6	
Multibus card cage	4-3	
Processor module	4 15	
Reset module	4 11	
SAS disk bus interface	4 14	
Serial interface module	4-12	
Multibus module removal	4 7 8 1	
N		
Nine track reel to reel tape transport	5 21	
O		
O C20		
AC connections	4-40, 4-59	
Applications	1-1	
Block diagram	2 3	
Communication levels	1-2	
Console component locations	1 10	
Console front and rear views	1 10	
Console hardware	1 9	
Environmental cabinet component locations	1 11	
Environmental cabinet front and rear views	1 11	
Environmental cabinet hardware	1-10	
Functional operation	2-3	
Hardware overview	1 7	
Installation summary	1-16	
Logic power	2 4	
Nomenclature	1-20	
O C mode s	1 7	
Optional hardware	1-14	
Panel mounted component locations	1 12	
Panel mounted hardware	1 11	
Panel mounted mode front and rear views	1 12	
Panning and installation	3-2	
Preoperating adjustments	3-35	
Reference documents	1-16	
Related equipment	1 16	
Safety considerations	3 3	
Specification	3 1	
Specification	1-24	
Standard hardware	1 14	
Tab stop (19 inch) front and rear views	1 9	
Tab stop (19 inch) hardware	1-9, 1 12	
Tab stop (37 inch) front and rear views	1 13	
Unpacking and inspection	3-2	
Wiring codes	3-22	
O C201		
AC power	3-34	
Anchoring dimensions	3 30	
Cabinet dimensions	3 17	
Cable connections	3-30	
Case dimensions	3-17	
Chassis connections	3-34	
O C201 keyboard interface panel	4-22	
Physical description	3-16	

Index (continued)

Preoperating adjustments	3-35
Setup and physical installation	3-16
Wiring color codes	3-22
Wiring connections and cabling	3-17, 3-30
O C201/2/3	
Anchoring dimensions	3-19
Cabinet dimensions	3-18
OIC202	
AC connections	4-61
AC input terminal	3-27
AC power	3-25
AC wiring	3-26
Cable connections	3-23
O C202 keyboard interface panel	4-22
PEP, AC wiring	3-35
Physical description	3-17
Preoperating adjustments	3-35
Setup and physical installation	3-17
Wiring color codes	3-22
O C203	
AC connections	4-61
AC power	3-28
Anchoring dimensions	3-21
Cabinet dimensions	3-20
Cable connections	3-28
Keyboard interface panel	4-22
Physical description	3-20
Power entry panel (PEP)	3-30
Preoperating adjustments	3-35
Setup and physical installation	3-20
Wiring color codes	3-22
Wiring connections and cabling	3-28
OIC204	
AC power	3-30
Cable connections	3-30
Chassis connections	3-34
Mounting dimensions	3-22
OIC204 keyboard interface panel	4-22
Physical description	3-21
Preoperating adjustments	3-35
Setup and physical installation	3-21
Wiring color codes	3-22
Wiring connections and cabling	3-22, 3-30
O C205	
Keyboard interface panel	4-22
Preoperating adjustments	3-35
OIS Description	1-1

OIS20	
AC input terminal	3-15
AC power	3-13
AC wiring	3-14
Anchoring dimensions	3-5
Applications	1-1
Block diagram	2-2
Cable connections	3-10
Communication levels	1-2
Communication loop connections	3-11
Console component locations	1-4
Console hardware	1-3
Driver cabinet components location	1-6
Driver cabinet front view	1-5
Driver cabinet hardware	1-5
Functional operation	2-1
Hardware overview	1-2
Logic power	2-4
Multibus	2-4
Multibus card cage modules	1-6
Nomenclature	1-20
Optional hardware	1-14
PEP, AC connections	4-61
PEP, AC wiring	3-35
Physical description	3-3
Planning an installation	3-2
Preoperating adjustments	3-35
Reference documents	1-16
Related equipment	1-16
Safety considerations	3-3
Special handling	3-1
Specifications	1-22
Standard hardware	1-14
Unpacking and inspection	3-2
Wiring color codes	3-9
Wiring connections and cabling	3-7
O S201	
Console front and rear views	1-4
OIS202	
Setup and physical installation	3-3
OIS20A/D	
AC input terminal	3-15
AC power	3-13
AC wiring	3-14
Anchoring dimensions	3-9
Cable connections	3-10
Communication loop connections	3-11

Index (continued)

PEP AC connect ons	4 53
PEP AC wiring	3-35
Peripheral device connect ons	3 13
Physical descript on	3-6
Preoperating adjustments	3 35
Setup and physical installation	3-6
Wiring codes	3 9
Wiring connect ons and cab ng	3 7
Operator interface hardware	
Color video copier	5 14
Operator keyboard	4-24
Optical disk	
Back pane features	5 41
Front panel controls	5 40
Storage	5 27 5 39
Un t troubleshooting	6 23
Opt onal hardware	5-2

P

Part replacement	8-3
Peripheral device connect ons	3 13
Planning an installation	3 2
Power entry pane for O C203	8-22
Power entry pane for IO S20/ O C202	8 19
Power entry pane for IO S20A	8 20
Power entry pane for the side n power supply O C202	4 45
Power entry pane IO C202	4 37
Power entry pane O S20	4 37
Power entry pane O S20A/D	4-41
Power supply O C202 side n	4 58
Power supply, OIC203	8-
Power supply, O C20A	4 54
Power supply, O C202	4 22
Power supply, OIC20 and OIS20A/D	4-57
Preoperating adjustments	3 35
Preventive maintenance	7 1
Printer	5 8
Printer cables	5 8

R

Ree to ree tape connect ons	5 24
Ree to ree tape setup	5 24
Replacement parts and ordering	

Instructions	9-1
Replacement modules	8-1

S

Safety considerations	3-3
SAS disk bus interface adapter	4 14
Second color graphics module	5 4
Setup	5 8
Single sided media	5-36 5 45
Side n power supply for O C202	8-25
Side n power supply, O C202	4 58
Spare parts	9 1
Special handling	3-1
Standard hardware	4-1
Streaming tape drive	5-19
System hardware	4 22

T

Tabletop annunciator display pane (ADP)	5 2
Technical documentation	9 1
Test disk system functions	6 10
Test multibus graphics controller module (MGC01)	6-8
Test multibus processor module (MPM0)	6-7
Test multibus serial interface module (MSM01)	6 10
Touch screen	5-48
Touch screen installation	5 49
Trackba	5 52
Traning	9-1
Troubeshoot ng	6 1

U

Unit replacement	8-3
------------------	-----

V

Video copier installation	5 11
Video copier switches	5 12
Video copier system	5-11

Index (continued)

W			
Wiring code or codes, O C		3-22	OIC202 3-22
Wiring code or codes, O S		3-9	O C203 3-28
Wiring connections and coding,			O C204 3-30
OIC20		3-30	O S20 3-7
O C201		3-17, 3-22, 3-30	O S20A/D 3-7
			Wiring, printer 5-8
			Wiring, Reel-to-reel tape 5-24

23 07 06 04 10 07

Bailey



Visit *Elsag Bailey* on the World Wide Web at <http://www.bailey.com>

Our worldwide staff of professionals ready to meet *your* needs for process automation
For the location nearest you please contact the appropriate regional office

AMERICAS

29801 Euclid Avenue
Wickliffe, Ohio USA 44092
Telephone 1 216 585 8500
Telex 1 216 585 8756

ASIA/PACIFIC

152 Beach Road
Gateway East #20-04
Singapore 189721
Telephone 65 391 0800
Telex 65 292 9011

EUROPE, AFRICA, MIDDLE EAST

Via Puccinella
16154 Genoa Italy
Telephone 39 10 6582 943
Telex 39 10 6582 941

GERMANY

Graefstrasse 97
D 60487 Frankfurt/Main
Germany
Telephone 49 69 799 0
Telex 49 69 799 2406

